

A			
Accessories and Modifications....	142	Additional Information About	
Accessories.....	142	Your SRS.....	43
Additional Safety Precautions..	143	Additional Safety Precautions....	46
Modifications.....	143	How the Automatic Seat Belt	
ACCESSORY (Ignition Key		Tensioners Work.....	44
Position).....	68	How Your Airbags Work.....	43
Accessory Power Socket.....	90	How Your SRS Indicator Light	
Adding		Works.....	45
Automatic Transmission		SRS Components.....	43
Fluid.....	203	Additives, Engine Oil.....	194
Brake Fluid.....	206	Adjustments	
Clutch Fluid.....	207	Headlights.....	226
Engine Coolant.....	197	Head Restraints.....	77
Engine Oil.....	193	Mirrors.....	83
Manual Transmission Fluid.....	204	Seats.....	75
Power Steering Fluid.....	207	Steering Wheel.....	62
Rear Differential Fluid.....	205	Airbag (SRS).....	7
Windshield Washer Fluid.....	202	Air Cleaner Element.....	208
Additional Information About		Air Conditioning.....	96
Your Seat Belts.....	40	Maintenance.....	215
Lap Belt.....	41	Usage.....	96
Lap/Shoulder Belt.....	40	Air Conditioning Filter.....	216
Seat Belt Maintenance.....	41	Air Outlets (Vents).....	98
Seat Belt System Components...	40	Air Pressure, Tires.....	217
		Normal Driving.....	218
		Alcohol in Gasoline.....	279
		Antifreeze.....	197
		Anti-lock Brakes (ABS)	
		Indicator Light.....	53, 163
		Operation.....	161
		Anti-theft Steering Column	
		Lock.....	68
		Appearance Care.....	237
		Ashtrays.....	91
		Audio System.....	104
		Automatic Speed Control.....	64
		Automatic Transmission.....	154
		Capacity, Fluid.....	274
		Checking Fluid Level.....	203
		Shifting.....	154
		Shift Lever Position Indicator..	154
		Shift Lever Positions.....	154
		Shift Lock Release.....	158

CONTINUED

Index

B

Battery

- Charging System
 - Indicator..... 52, 261
 - Jump Starting..... 256
 - Maintenance..... 211
 - Specifications..... 275
- Before Driving..... 135
- Belts, Seat..... 6
- Beverage Holder..... 86
- Body Repair..... 244
- Brakes
 - Anti-lock System (ABS)..... 161
 - Break-in, New Linings 136
 - Fluid..... 206
 - Light, Burned-out..... 228
 - Parking..... 84
 - System Indicator..... 52, 263
 - Wear Indicators..... 160
- Brakes, ABS
 - Operation..... 161
 - System Indicator..... 53, 163
- Braking System..... 160
- Break-in, New Car..... 136
- Brightness Control, Instruments... 59

- Brights, Headlights..... 58
- Built-in Table..... 87
- Bulb Replacement
 - Back-up Lights..... 230
 - Brake Lights..... 230
 - Cargo Area Light..... 234
 - Ceiling Light..... 234
 - Front Parking Lights..... 229
 - Front Side Marker Lights..... 229
 - Headlights..... 228
 - High-mount Brake Light..... 233
 - Interior Light..... 234
 - License Plate Lights..... 231
 - Rear Side Marker Lights..... 232
 - Specifications..... 275
 - Spotlight..... 234
 - Turn Signal Lights..... 229
- Bulbs, Halogen..... 228

C

- Cables, Jump Starting With..... 256
- Capacities Chart..... 274
- Carbon Monoxide Hazard..... 47
- Cargo Area Light..... 93
- Cargo Floor Pockets..... 89

- Cargo Hooks..... 91
- Carrying Cargo..... 144
- Cassette Player
 - Care..... 112, 133
 - Operation..... 110, 130
- CAUTION, Explanation of..... ii
- CD Changer..... 113, 126
- CD Player..... 113, 124
- Center Pocket..... 89
- Center Table..... 85
- Certification Label..... 272
- Chains..... 223
- Change Oil
 - How to..... 195
 - When to..... 184
- Changing a Flat Tire..... 246
- Changing Engine Coolant..... 199
- Charging System Indicator.... 52, 261
- Checking
 - Automatic Transmission
 - Fluid..... 230
 - Battery Condition..... 211
 - Brake Fluid..... 206
 - Clutch Fluid..... 207
 - Drive Belts..... 216
 - Engine Coolant..... 140

Engine Oil.....	139	Checking.....	140	Engine Oil.....	139
Fuses.....	264	Proper Solution.....	197	Directional Signals.....	59
Manual Transmission Fluid	204	Replacing.....	199	Disabled, Towing Your Car If.....	269
Power Steering Fluid.....	207	Temperature Gauge.....	55	Disc Brake Wear Indicators.....	160
Rear Differential Fluid.....	205	Corrosion Protection.....	243	Disposal of Used Oil.....	196
Checklist, Before Driving.....	149	Crankcase Emission Control		Doors	
Childproof Door Locks.....	73	System.....	281	Locking and Unlocking.....	68
Child Safety.....	17	Cruise Control Operation.....	64	Power Door Locks.....	69
Cleaner, Air.....	208	Customer Relations Office.....	286	DOT Tire Quality Grading.....	277
Cleaning				Downshifting, 5-speed Manual	
Aluminum Wheels.....	239	D		Transmission.....	152
Carpeting.....	241	DANGER, Explanation of.....	ii	Drive Belts.....	216
Exterior.....	238	Dashboard.....	50	Driving.....	147
Fabric.....	241	Daytime Running Lights.....	58	Economy.....	141
Interior.....	241	Dead Battery, What to Do.....	256	In Bad Weather.....	164
Seat Belts.....	242	Defects, Reporting Safety.....	290	In Foreign Countries.....	280
Vinyl.....	241	Defog and Defrost.....	101	Driving Guidelines.....	148
Windows.....	242	Defogger, Rear Window.....	61		
Clock, Setting the	85	Defrosting the Windows.....	101		
Clutch Fluid.....	207	DEXRON® III Automatic			
CO in the Exhaust.....	281	Transmission Fluid.....	203		
Cold Weather, Starting in.....	151	Dimensions.....	274		
Consumer Information*.....	285	Dimming the Headlights.....	58		
Controls, Instruments and.....	49	Dipstick			
Coolant		Automatic Transmission.....	203		
Adding.....	197				

CONTINUED

Index

E

Economy, Fuel.....	141
Emergencies on the Road.....	245
Battery, Jump Starting.....	256
Brake System Indicator.....	263
Changing a Flat Tire.....	246
Charging System Indicator.....	261
Checking the Fuses.....	265
Low Oil Pressure Indicator.....	260
Malfunction Indicator Lamp....	262
Overheated Engine.....	258
Emergency Brake.....	84
Emergency Flashers.....	61
Emission Controls.....	281
Engine	
Coolant Temperature Gauge	55
Malfunction Indicator Lamp.....	52, 262
Oil Pressure Indicator.....	52, 260
Oil, What Kind to Use.....	193
Overheating.....	258
Specifications.....	274
Ethanol in Gasoline	279
Evaporative Emission Controls....	281
Exhaust Fumes.....	47

Expectant Mothers, Use of Seat Belts by.....	17
Exterior, Cleaning the.....	238

F

Fabric, Cleaning.....	241
Fan, Interior.....	96
Features, Comfort and Convenience.....	95
Filling the Fuel Tank.....	137
Filters	
Air.....	208
Air Conditioning.....	216
Oil.....	195
5-speed Manual Transmission	
Checking Fluid Level.....	204
Shifting the.....	152
Flashers, Hazard Warning.....	61
Flat Tire, Changing a.....	246
Fluids	
Automatic Transmission.....	203
Brake.....	206
Clutch.....	207
Manual Transmission.....	204
Power Steering.....	207

Rear Differential.....	205
Windshield Washer.....	202
FM Stereo Radio	
Reception.....	108, 122
Folding Rear Seat.....	80
Foreign Countries, Driving in.....	280
Four-way Flashers.....	61
Front End, Towing by	
Emergency Wrecker.....	269
Fuel.....	136
Fill Door and Cap.....	137
Gauge.....	55
Octane Requirement.....	136
Oxygenated.....	279
Reserve Indicator.....	53
Tank, Filling the.....	137
Fuses, Checking the.....	264

G

Gas Mileage, Improving.....	141
Gasohol.....	279
Gasoline.....	136
Fuel Reserve Indicator.....	53
Gauge.....	55
Octane Requirement.....	136

Tank, Filling the.....	137
Gas Station Procedures.....	137
Gauges	
Engine Coolant Temperature ...	55
Fuel.....	55
Gearshift Lever Positions	
Automatic Transmission.....	152
5-speed Manual	
Transmission.....	154
Glass Cleaning.....	242
Glove Box.....	75

H

Halogen Headlight Bulbs.....	228
Hazard Warning Flashers.....	61
Headlights	
Aiming.....	226
Daytime Running Lights.....	58
High Beam Indicator.....	53
High Beams, Turning on.....	58
Low Beams, Turning on.....	58
Reminder Beeper.....	58
Replacing Halogen Bulbs	228
Turning on.....	58
Head Restraints.....	77

Heating and Cooling.....	96
High Altitude, Starting at.....	151
High-Low Beam Switch	58
High-mount Brake Light.....	233
Hood, Opening the	138
Horn.....	57
Hot Coolant, Warning about.....	197
Hydraulic Clutch.....	207
Hydroplaning.....	165

I

Identification Number, Vehicle....	272
If Your Car Has to be Towed.....	269
Ignition	
Keys.....	67
Switch.....	67
Timing Control System.....	282
Important Safety Precautions	4
Indicator Lights. Instrument	
Panel.....	51
Infant Restraint.....	27
Inflation, Proper Tire	217
High Speed Driving.....	277
Normal Driving.....	218
Inside Mirror.....	83

Inspection, Tire.....	219
Instrument Panel.....	51
Instrument Panel Brightness.....	59
Interior Cleaning.....	241
Interior Light.....	92
Introduction.....	i

J

Jacking up the Vehicle.....	249
Jack, Tire.....	246
Jump Starting.....	256

K

Keys.....	67
-----------	----

L

Label, Certification.....	272
Lane Change, Signaling.....	59
Lap Belt.....	41
Lap/Shoulder Belts.....	40
Leaking of Exhaust into Car.....	47

CONTINUED