

Use these links (and links throughout this manual) to navigate through this reference.  
For a printed owner's manual, click on authorized manuals or go to [www.helminc.com](http://www.helminc.com).

## Table of Contents

---

Refer to [1999 TL Owner's Manual](#) for more information.

Introduction.....	2
System Controls.....	4
System Start-up.....	6
Main Menu.....	7
Selecting By Address.....	8
Selecting By Intersection.....	13
Selecting By Phone No. (POI).....	19
Selecting By Places.....	20
Outlying Areas.....	25
Selecting A Previous Destination..	26
Selecting By Map Input.....	27
Traveling To Your Destination.....	30
The Map Screen.....	34
Going Off the Route.....	36
Modifying the Route.....	36
Selecting By Personal Addresses..	38
Entering a PIN.....	38
Entering Personal Addresses.....	39
Updating a Personal Address.....	43
Selecting a Personal Address as a Destination.....	44
System Setup.....	46
System Security.....	51
System Limitations.....	52
Customer Assistance.....	54
Climate Control System.....	60