

# TECHNOLOGY REFERENCE GUIDE



[owners.honda.com](http://owners.honda.com)

2012 Honda CR-V EX-L with Navigation  
Technology Reference Guide

©2011 American Honda Motor Co., Inc. — All Rights Reserved

Printed in Japan

31T08T00  
00X31-T08-T001




2012 CR-V EX-L  
with Navigation

## TECHNOLOGY REFERENCE GUIDE

The Technology Reference Guide is designed to help you get acquainted with your new Honda and provide basic instructions on some of its technology and convenience features. This guide covers the CR-V EX-L with Navigation.

This guide is not intended as a substitute for the Owner's Manual. For complete information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual.

Auto Door Locks .....	2
Instrument Panel Indicators .....	4
Eco Assist System™.....	6
Tire Pressure Monitoring System (TPMS).....	7
Multi-Information Display (MID) .....	8
Voice Recognition.....	10
Navigation.....	16
Bluetooth® HandsFreeLink® (HFL).....	20




SMS Text Messaging.....	24
iPod® or USB Flash Drive .....	26
Bluetooth® Audio .....	27
Pandora®.....	28
Multi-View Rear Camera .....	29
Owner Link.....	30
Safety Reminder .....	31
Fuel Recommendation.....	31

## AUTO DOOR LOCKS

### Default Lock/Unlock Setting


#### Default Lock Setting

All doors and the tailgate are preset to lock when your vehicle reaches about 10 mph.



#### Default Unlock Setting

Only the driver's door is preset to unlock when you shift into Park (P).



### Programmable Auto Door Lock/Unlock Settings

Below are the options you can choose. See *Auto Door Locking/Unlocking* in your Owner's Manual for instructions on programming these settings.

AUTO DOOR LOCK			AUTO DOOR UNLOCK		
Auto Lock (all doors)	 When you reach 10 mph	 When you shift out of Park	Auto Unlock (all doors)	 When you turn the ignition OFF	 When you shift into Park
Turn off Auto Lock	 Operate manually		Auto Unlock (only driver's door)	 When you turn the ignition OFF	 When you shift into Park
Turn off Auto Unlock	 Operate manually		Turn off Auto Unlock	 Operate manually	

Program how and when the vehicle doors automatically lock and unlock.

### Programming the Auto Door Unlock Setting

Press the (+/-) buttons on the steering wheel to scroll through the menu options. Press SOURCE to select an option. See [page 9](#) for more information on the multi-information display and its controls.


#### 1. Press MENU.



#### 2. Select Customize Settings.



#### 3. Select Door Setup.



#### 4. Select Auto Door Unlock.



#### 5. Select All Doors with Shift to P.



#### 6. Press MENU to exit.



## INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information.



### Malfunction Indicators

If an indicator remains on, there may be a problem; see your dealer

	Charging system		EPS (electric power steering)
	Low brake fluid, Brake system		Malfunction indicator lamp (check engine light)
	Low oil pressure		VSA® (vehicle stability assist)
	SRS (supplemental restraint system)		TPMS (tire pressure monitoring system)
	Transmission (blinking)		E-DPS* (all-wheel drive)
	ABS (anti-lock brake system)		DRL (Daytime running lights)

### Condition Indicators

Action is needed by driver

	Parking brake on: Release		Seat belt reminder: Fasten seat belt(s)
--	------------------------------	--	--

	Door/Tailgate open: <b>Close door(s) / tailgate</b>		Low fuel: <b>Refill</b>
	Low tire pressure: <b>Add air</b>		Maintenance Minder™: <b>Make service appointment</b>
	All-Wheel Drive* (blinks): <b>Pull over and idle</b>		

### On/Off Indicators

	PASSENGER AIRBAG <b>OFF</b> (next to multi-information display)		Immobilizer (blinks): improperly coded key; <b>use correct key</b>
	SIDE AIRBAG <b>OFF</b>		1st detent: parking lights <b>on</b> 2nd detent: headlights <b>on</b>
	VSA® <b>OFF</b>		Turn signals/hazards <b>on</b>
	CRUISE MAIN <b>on</b>		Fog lights <b>on</b>
	CRUISE CONTROL <b>on</b>		High beams <b>on</b>
	ECON Mode <b>on</b>		

\* if equipped

## ECO ASSIST SYSTEM


When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system may be affected to achieve maximum fuel economy.

### ECON Button

1. Press **ECON** to turn the system on.



2. The **ECON** mode indicator comes on.




3. Press **ECON** again to turn the system off.



### Ambient Meter

Indicates instant fuel efficiency using color-coded bars.



## TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

### How It Works



Each tire valve stem contains a TPMS sensor.



When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on.

**TPMS**


If the TPMS indicator appears, there may be a problem with the system. See your dealer.

### What to Do

1. **Visually inspect** the tires for damage.
2. **Use** a tire air pressure gauge to check which tire(s) have low pressure.



3. **Inflate** the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.



## MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.


### Accessing the MID



Press the Display button to change the main displays.



### Main Displays



### Steering Wheel Controls


Use the steering wheel controls to navigate through the Vehicle Menu.



**(+) Button:**  
Press to scroll upward.

**(◀) Button:**  
Press to go back to the previous display.

**(-) Button:**  
Press to scroll downward.



**SOURCE Button:**  
Press to enter your selection.

**(▶) Button:**  
Press to go to the next display.

**MENU Button:**  
Press to go to the Vehicle Menu for customization and other settings.



## VOICE RECOGNITION

To keep your eyes on the road and hands on the wheel, use voice commands for hands-free calling, navigation, and audio. For a full list of commands, **say** "Information" and "Voice Info."

### Key Functions by Voice Command

Control four different systems with the steering wheel buttons and the ceiling microphone.


**To prevent driver distraction, certain manual and touch screen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.**



**Pick-Up button:** Answer an incoming call, or go directly to the Phone screen.

**Hang-Up/Back button:** End a call, decline an incoming call, or cancel a selection.

**Talk button:** Give navigation, HFL, audio, or climate control commands.



### Voice Command Tips

- **Press and release** the Talk button, wait for a beep, then give a command.
- All available voice commands are highlighted in blue when you press the Talk button.
- For a list of available commands, **press and release** the Talk button and **say** "Help" at any time.
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.
- The system also uses a touch screen display. You can select options or icons by touching them on the screen. This is limited while the vehicle is moving.

### NAVIGATION p. 16



### BLUETOOTH® HANDSFREELINK® p. 20



### AUDIO p. 15



### CLIMATE CONTROL p. 15




## Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Talk button before you give a command.

### Locate Points of Interest

**Say** a command like “Display restaurant” to see restaurant icons appear on the map.



**Say** a command like “Display gas station” to see gas station icons appear on the map.




Press and release the Talk button before you give a command.

### Get Navigation Route Information

After a destination is entered, **say** “How far to the destination?” to hear the remaining distance.



**Say** “Display entire route” to see the routing method the system mapped for your destination.




Press and release the Talk button before you give a command.

### Make Audio Selections

**Say** a command like “Radio 97.1 FM” to select that station.



**Say** a command like “CD play track 1” to hear that song on a currently inserted CD.



Press and release the Talk button before you give a command.

### Adjust the Vehicle's Climate Setting

**Say** a command like “Air conditioner on” to start the air conditioning system.



**Say** a command like “Fan speed 4” to adjust the fan speed.





## Commonly Used Voice Commands (continued)


Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Talk button before you give a command.

### General Commands

(Accepted on most screens to change displays)

- Display map
- Display menu
- Display information
- Display audio
- What time is it?
- Next/previous (to change pages)
- Left/right (to change tabs)
- Up/down (to scroll lists up to three pages)



### Find Place Commands

(Accepted on Map screen)


- Find nearest:
  - ATM
  - Honda dealer
  - gas station
  - airport
  - Mexican restaurant
  - hospital
  - bank
  - post office



### Navigation Commands

(Accepted on Map screen)


- How long/far to the destination?
- Display destination map
- Display entire route



### Display Commands

(Accepted on Map screen)

- Display/Hide:
  - ATM
  - gas station
  - restaurant
  - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location



Press and release the Talk button before you give a command.

### Audio Commands

(Accepted on most screens)

- Audio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- DISC/USB/iPod play
- DISC/USB/iPod skip forward/back
- Auxiliary (AUX) play



### Phone Commands

(Accepted on Phone screen)

- Dial
- Speed Dial 1 (or 2)
- Redial
- Phonebook
- Phone setup
- (Accepted on any screen)
- Dial by number
- Dial by voice tag



### Climate Control Commands

(Accepted on most screens)


- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57-87)
- Temperature max hot/cold



### Help Commands

(Accepted on most screens)

- Help (list of available commands for current screen)
- Voice command help - from INFO screen (list of all available navigation and audio commands)



## NAVIGATION







Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

### Entering a Destination Using Voice Commands

Set a destination using a street address. For other destination options, see the Navigation Manual.

Press and release the Talk button before you give a command.

1. **Say** "Display menu." **Say** "Address."
2. **Say** "Street," then **say** the street name on the next screen. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).
3. A list of street names appears. **Say** the number next to the street you want to select.
4. **Say** the entire street address number. For example, "1-2-3-4." If necessary, **say** "OK" to proceed.
5. If the street address is in more than one city, a list of city names appears. **Say** the number next to the city you want to select.
6. The system displays the "Calculate route to" screen. **Say** "Set as destination" to set the route.





**NOTE:** If menu options are grayed out, they are only available using voice commands. It is recommended that you enter your destination before driving or when the vehicle is stopped.

### Map Screen Legend



### Turn-by-Turn Directions

Shows a more detailed view of the next maneuvers during route guidance on the multi-information display. See your Owner's Manual for instructions on how to turn this feature on or off.



## Using the Find Nearest Command

Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Talk button before you give a command.


1. From the map screen, say "Find nearest ATM."




3. Say the number next to the destination you want to select.



2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.



4. The system displays the "Calculate route to" screen. Say "Set as destination" to set the route.





## FM Traffic

Provides continuously updated information, including traffic speed, incidents, and construction in major metro areas. Works in cities where a clear FM traffic signal is available.

Press and release the Talk button before you give a command.

### Displaying Traffic Information

Say "Display traffic" to view traffic flow and icons.



**Heavy traffic**

**Moderate traffic**

### Traffic Icons



Incident



Road closed



Construction




Weather

**NOTE:** Traffic flow and incident icons are only displayed on map scales of 5 miles (8 km) or less.


### Traffic Rerouting

The system can automatically provide detours around traffic or incidents when a destination is set.


1. Say "Display traffic list" to view a list of incidents on your route.




3. Say "Avoid," and the incident list returns.



2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



4. Say "Reroute" to set the new route.



## BLUETOOTH® HANDSFREELINK® (HFL)

Place and receive phone calls through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if your phone is compatible.


**To prevent driver distraction, certain manual and touch screen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.**

### How to Use HFL

**Pick-Up button:** Answer an incoming call, or go directly to the Phone screen.

**Hang-Up/Back button:** End a call, decline an incoming call, or cancel a selection.

**Talk button:** Give HFL commands.




### Pairing Your Phone


Use this pairing method when no phone has ever been paired to the system. You can only pair your Bluetooth-compatible phone when the vehicle is stopped.

Press and release the Talk button before you give a command.


1. **Press** the Pick-Up button to access the Phone screen. A prompt appears. **Say** "Yes."



2. Make sure your phone is in discovery mode, and **say** "OK."



3. HFL searches for your phone. **Select** it when it appears on the list. **Go** to step 4.




*If your phone does not appear:*

**Select** "Find Another Phone" and **search** for a HandsFreeLink device from your phone. **Connect** to HFL. **Go** to step 4.



4. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.




### Pairing Your Phone (continued)

Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.


Press and release the Talk button before you give a command.

1. **Press** the Pick-Up button to go to the Phone screen.




If a prompt appears asking to connect to a phone, **say** "No" and go to step 2.


2. **Say** "Phone setup."



3. **Say** "Bluetooth setup add select a phone."




4. **Say** "Search."




5. Make sure your phone is in Discovery mode, and **say** "OK."




6. HFL searches for your phone. **Say** the number next to the phone when it appears on the list.



*If your phone does not appear:*  
**Say** "Find Another Phone" and **search** for HandsFreeLink from your phone. **Connect** to HFL.



7. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.






## Dialing a Number

Enter a 10-digit phone number to call.

Press and release the Talk button before you give a command.


1. **Press** the Pick-Up button to go to the Phone screen.




3. **Say** the entire phone number, then say "Dial" to call.



2. **Say** "Dial."




4. The call is connected and heard through the vehicle speakers.




## Receiving a Call


1. A notification is heard and the incoming phone number appears on the navigation screen.



3. **Press** the Hang-Up button to end or decline the call.



2. **Press** the Pick-Up button to accept the call.




## Using the Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system.

Press and release the Talk button before you give a command.


1. **Press** the Pick-Up button to go to the Phone screen.




3. **Scroll** through the list to find the name and number you want to call. **Say** "Dial," or **press** the Pick-Up button to call.



2. **Say** "Phonebook."



4. The call is connected and heard through the vehicle speakers.




## Using Speed Dial


Up to 15 numbers can be stored with voice tags (see your Navigation Manual for instructions).

Press and release the Talk button before you give a command.


1. **Press** the Pick-Up button to go to the Phone screen.




If an entry has a stored voice tag, **say** "Dial by voice tag," followed by the voice tag name and "Dial" from any screen.



2. **Say** "Speed Dial 1" (or "Speed Dial 2") and the number next to the entry. For example, "One." **Say** "Call," or **press** the Pick-Up button to call.



3. The call is connected and heard through the vehicle speakers.







## SMS TEXT MESSAGING

Receive and send text messages from your paired and linked Message Access Profile (MAP)-compatible phone. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to see if this feature is compatible on your phone. Standard message rates apply. This feature is limited while the vehicle is moving.

### Receiving Text Messages

Press and release the Talk button before you give a command.




1. A notification appears on the navigation screen when you receive a text message.
2. **Say "Read"** to open the message. The message is displayed, and the system reads it aloud.



### Displaying Messages

Press and release the Talk button before you give a command.



1. **Press** the Pick-Up button to go to the Phone menu.
3. **Say** the number next to the message you want. The message is displayed, and the system reads it aloud.





### Replying to Text Messages

Press and release the Talk button before you give a command.

1. With the message open, **say "Reply."**
3. **Say "Send"** to send the message.




2. **Say** the corresponding number of one of the six available reply messages.
4. A notification appears after the message is sent.



### Calling the Sender

Press and release the Talk button before you give a command.

1. With the message open, **say "Call."**
2. HFL begins dialing the number.





## iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

### Connecting Devices and Playing Audio Files

1. **Pull out** the USB adapter cable from the center console.
2. **Connect** the USB adapter cable to your iPod dock connector or flash drive.
3. **Press** SOURCE or CD/XM until iPod or USB mode appears. Audio begins to play.
4. **Press** (⏮) or (⏭) to change tracks, or **press** (⏪) or (⏩) on the steering wheel.




iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

## BLUETOOTH® AUDIO\*




Play stored or streaming audio from your compatible phone through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if this feature is available on your phone.

### Playing Bluetooth Audio Files

1. Make sure your phone is on and paired to Bluetooth® HandsFreeLink® (see [page 20](#)).
2. **Press** SOURCE or CD/XM until Bluetooth Audio mode appears.
3. From your phone, **open** the desired audio player or app and begin playing. Sound is redirected to the audio system.
4. **Press** (⏮) or (⏭) to change tracks, or **press** (⏪) or (⏩) on the steering wheel\*.



3. From your phone, **open** the desired audio player or app and begin playing. Sound is redirected to the audio system.



#### Notes:

- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional Bluetooth settings on your phone for playback.
- The play/pause function may not be supported on all phones.



\*not supported on all phones

## PANDORA®

Play and operate Pandora® streaming radio from your iPhone® through your vehicle's audio system. Standard data rates apply.

### Playing Pandora

1. **Pull out** the USB adapter cable from the center console. **Connect** your phone using a USB dock connector.
2. **Open** Pandora from your phone. **Press** SOURCE or CD/XM until Pandora mode appears and streaming begins.
3. From the audio screen, select items such as Station List, Like/Dislike, and Pause/Resume.\*



2. **Open** Pandora from your phone. **Press** SOURCE or CD/XM until Pandora mode appears and streaming begins.



#### Notes:

- If Pandora is not selected from your phone, iPod music is played.
- Press the Home button on your iPhone to switch from Pandora to iPod. To play Pandora again, you must reopen the app from your phone.
- If you cannot operate Pandora through the audio system, it may be streaming through Bluetooth® Audio. Make sure Pandora mode on your audio system is selected.

\*Menu functions not available on all phones


iPhone is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries.

## MULTI-VIEW REAR CAMERA

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

### How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the navigation display.
- The rearview display turns off when you shift out of Reverse.



### Parking Guide Lines

- Yellow parking guide lines also appear to help you judge distance. They can be turned on or off.
- **Press and hold** CANCEL until the guide lines turn on or off. They remain off until you turn them on again.



### Switching Views


There are three rearview modes: wide (default view), normal, and top down.

- **Select** the corresponding icon to change views.
- **Press** ZOOM (▲) or (▼) to adjust the screen brightness.



## OWNER LINK


Owner Link allows you to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information. Register at [owners.honda.com](http://owners.honda.com) to ensure that you continue to enjoy the experience of owning a Honda.



### REGISTRATION

Questions about registration?  
[FIND HELP HERE.](#)

After registration, you can always click "My Profile" to edit or update your information.



◆ = required field

Note: Username and password are case sensitive.

◆ first name ◆ last name

◆ username ◆ password (min. 6 char.) ◆ confirm password

◆ email address

◆ confirm email address

VIN or Hull Identification Number (VIN)

promo :

[Need help with registration?](#)

Please Note: E-mail spam filters may block our e-mails from being delivered. If you have a spam blocker, please set it to accept e-mails from "ownerlink@ebizmail.honda.com".

[Where can I find my VIN?](#)  
[Benefits of entering VIN](#)

## SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

## FUEL RECOMMENDATION

- Only use unleaded gasoline of 87 octane or higher.
- Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emissions control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- "TOPTIER Detergent Gasoline" meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines. In most cases, qualifying gasoline retailers will identify their gasoline as having met "TOPTIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. This helps avoid build-up of deposits in your engine and emission control system. Because the level of detergency and harmful metallic additives (such as MMT) in gasoline vary in the market, Honda endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. For more information, visit [www.toptiergas.com](http://www.toptiergas.com).
- For further important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit Owner Link at [owners.honda.com](http://owners.honda.com).