TECHNOLOGY
REFERENCE
GUIDE





owners.honda.com

TECHNOLOGY REFERENCE GUIDE

The Technology Reference Guide is designed to help you get acquainted with your new Honda and provide basic instructions on some of its technology and convenience features. This guide covers the CR-V EX, EX-L, and EX-L with Rear Entertainment System (RES).

This guide is not intended as a substitute for the Owner's Manual. For complete information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual.

EX-L with RES shown throughout guide

Auto Door Locks	2
Instrument Panel Indicators	4
Eco Assist System [™]	6
Tire Pressure Monitoring System (TPMS)	7
Multi-Information Display (MID)	8
Multi-View Rear Camera	10
Bluetooth® HandsFreeLink® (HFL)	11
SMS Text Messaging	16



iPod® or USB Flash Drive	18
Bluetooth® Audio	19
Pandora®	20
Rear Entertainment System (RES)	21
Owner Link	22
Safety Reminder	23
Fuel Recommendation	

AUTO DOOR LOCKS

Default Lock/Unlock Setting

Default Lock Setting

All doors and the tailgate are preset to lock when your vehicle reaches about 10 mph.









Programmable Auto Door Lock/Unlock Settings

Below are the options you can choose. See Auto Door Locking/Unlocking in your Owner's Manual for instructions on programming these settings.

AUTO DOOR LOCK

Auto Lock (all doors)

Turn off

Auto Lock



reach 10 mph







When you shift out of Park

Operate manually

AUTO DOOR UNLOCK

Auto Unlock (all doors)















Turn off **Auto Unlock**

door)



Program how and when the vehicle doors automatically lock and unlock.

Programming the Auto Door Unlock Setting

Press the (+/-) buttons on the steering wheel to scroll through the menu options. Press SOURCE to select an option. See page 9 for more information on the multiinformation display and its controls.

I. Press MENU.



2. Select Customize Settings.



3. **Select** Door Setup.



4. Select Auto Door Unlock.



5. Select All Doors with Shift to P.



6. Press MENU to exit.



INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information.



Malfunction Indicators If an indicator remains on, there may be a problem; see your dealer



Charging system



EPS (electric power steering)



Low brake fluid, Brake system



Malfunction indicator lamp (check engine light)



Low oil pressure



VSA® (vehicle stability assist)



SRS (supplemental restraint system)



TPMS (tire pressure monitoring system)



Transmission (blinking)



E-DPS* (all-wheel drive)



ABS (anti-lock brake system)



DRL (Daytime running lights)

Condition Indicators Action is needed by driver



Parking brake on: **Release**



Seat belt reminder: Fasten seat belt(s)



Door/Tailgate open: Close door(s) / tailgate



Low tire pressure: Add air



All-Wheel Drive* (blinks): **Pull over and idle**



Low fuel: Refill



Maintenance MinderTM: **Make service appointment**

On/Off Indicators



PASSENGER AIRBAG **OFF** (next to multi-information display)



SIDE AIRBAG OFF



VSA® OFF



CRUISE MAIN on



CRUISE CONTROL on



ECON Mode on



Immobilizer
Flashes: improperly coded key;
use correct key



1st detent: parking lights on 2nd detent: headlights on



Turn signals/hazards on



Fog lights on



High beams **on**

* if equipped

ECO ASSIST SYSTEM

When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system may be affected to achieve maximum fuel economy.

ECON Button

I. **Press ECON** to turn the system on.



2.The **ECON** mode indicator comes on.



3. **Press ECON** again to turn the system off.



Ambient Meter

Indicates instant fuel efficiency using color-coded bars.







TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

How It Works





Each tire valve stem contains a TPMS sensor.





When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on.



If the TPMS indicator appears, there may be a problem with the system. See your dealer.

What to Do

- I. Visually inspect the tires for damage.
- 2. **Use** a tire air pressure gauge to check which tire(s) have low pressure.



3. Inflate the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.








 \sim 7

MULTI-INFORMATION DISPLAY (MID)





Consists of several displays that provide you with useful information.



MULTI-VIEW REAR CAMERA

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the multi-information display.
- · Yellow parking guide lines also appear to help you judge distance.
- The rearview display turns off when you shift out of Reverse.



Switching Views

There are three rearview modes: wide (default view), normal, and top down. Press the selector knob to toggle between views.



Wide (default)





BLUETOOTH® HANDSFREELINK® (HFL)

Place and receive phone calls through your vehicle's audio system. Visit handsfreelink.honda.com to check if your phone is compatible.

To prevent driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving. Stop or pull over to perform the function.

How to Use HFL

Pick-Up button: Answer an incoming call or go directly to the Phone screen.

Hang-Up/Back button: End a call, decline an incoming call, or cancel a selection.

Talk button: Make a call using a stored voice tag.-





Use these two buttons to navigate through the HFL menus.

Audio selector knob: ~ Rotate to scroll through selections and press to make a selection.



Back button: Press to cancel an operation or return to the previous screen.

Pairing Your Phone

Use this pairing method when no phone has ever been paired to the system. You can only pair your Bluetooth-compatible phone when the vehicle is stopped.

Use the audio selector knob to make and enter selections.

 Press the Pick-Up button to access the Phone screen. A prompt appears. Select Yes.



2. Make sure your phone is in discovery mode. **Select** OK.



3. HFL searches for your phone. **Select** it when it appears on the list. **Go** to step 4.



If your phone does not appear:

Select Phone Not Found, and search for HandsFreeLink from your phone. Connect to HFL. Go to step 4.





 HFL gives you a four-digit code. Enter it on your phone when prompted. The phone is now paired.



Pairing Your Phone (continued)

Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

Use the audio selector knob to make and enter selections.

1. **Press** the Pick-Up button to access the Phone screen.



If a prompt appears asking to connect to a phone, **select**No and continue to step 2.

2. **Select** Phone setup.



3. Select Connection.



4. Select Add a New Phone.



5. **Select** an empty location for the phone.



6. Make sure your phone is in Discovery mode, and **select** OK.





HFL searches for your phone.
 Select your phone when it appears on the list.



If your phone does not appear:

Select "Phone Not Found?" and **search** for HandsFreeLink from your **phone. Connect** to HFL. **Go** to step 8.



8. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.



Dialing a Number

Enter a 10-digit phone number to call. This feature is inoperable when the vehicle is moving.

Use the audio selector knob to make and enter selections.

1. **Press** the Pick-Up button to go to the Phone screen.



2. Select Dial.



 Enter the phone number.
 Select the green Dial icon or press the Pick-Up button to call.



4. The call is connected and heard through the vehicle speakers.



Receiving a Call

 A notification is heard and the incoming phone number appears on the multiinformation display.



2. **Press** the Pick-Up button to accept the call.



3. **Press** the Hang-Up button to end or decline the call.



Using the Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system. This feature is inoperable when the vehicle is moving.

Use the audio selector knob to make and enter selections.

1. **Press** the Pick-Up button to go to the Phone screen.



2. Select Phonebook.



3. **Scroll** through the list to find the name and number you want to call, and **select** it.



4. The call is connected and heard through the vehicle speakers.



Using Speed Dial


When a speed dial entry is stored with a voice tag, you can make a call using voice commands at any time. See your Owner's Manual for more information.

Press and release the Talk button before you give a command.

 Press the Talk button. The system asks which name you want to call.



2. Say the stored voice tag name.



3. The call is connected and heard through the vehicle speakers.



SMS TEXT MESSAGING

Receive and send text messages from your paired and linked Message Access Profile (MAP)-compatible phone. Visit handsfreelink.honda.com to see if this feature is compatible on your phone. Standard message rates apply. This feature is limited while the vehicle is moving.

Receiving Text Messages

Use the audio selector knob to make and enter selections

I. A notification appears on the multi-information display. **Select** Yes to open the message.




2. The message is displayed, and the system reads it aloud.



Displaying Messages

Use the audio selector knob to make and enter selections

1. **Press** PHONE or the Pick-Up button to go to the Phone menu.



 Select Text Message. The 20 most recent text messages from your phone are displayed.




3. **Select** a message to open it and hear it read aloud.



Replying to Text Messages

Use the audio selector knob to make and enter selections


I. With the message open, **press** the selector knob to enter the Text Message menu.



2. Select Reply.



3. **Select** one of the six available reply messages.



4. **Select** Yes to send the message.



Calling the Sender

Use the audio selector knob to make and enter selections

 With the message open, press the selector knob to enter the Text Message menu.



2. Select Call.



3. HFL begins dialing the number.



iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Connecting Devices and Playing Audio Files

1. **Pull out** the USB adapter cable from the center console.





2. **Connect** the USB connector to your iPod dock connector or flash drive.





 Press SOURCE or AUX until iPod or USB mode appears. Audio begins to play.







4. **Press** the (⋈) or (⋈) buttons to change tracks, or **press** (◄) or (▶) on the steering wheel.









iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

BLUFTOOTH® AUDIO*

Play stored or streaming audio from your compatible phone through your vehicle's audio system. Visit handsfreelink.honda.com to check if this feature is available on your phone.

Playing *Bluetooth* Audio Files

- Make sure your phone is on and paired to HandsFreeLink (see page 12).
- 2. **Press** SOURCE or AUX until Bluetooth Audio mode appears.





 From your phone, open the desired audio player or app and begin playing. Sound is redirected to the audio system.



4. **Press** the (⋈) or (⋈) buttons to change tracks, or **press** (◄) or (▶) on the steering wheel*.









Notes:

- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional *Bluetooth* settings on your phone for playback.
- The play/pause function may not be supported on all phones.

*not supported on all phones

PANDORA®

Play and operate Pandora® streaming radio from your iPhone® through your vehicle's audio system. Standard data rates apply.

Playing Pandora

 Pull out the USB adapter cable from the center console.
 Connect your phone using a USB dock connector.





 Open Pandora from your phone. Press SOURCE or AUX until Pandora mode appears and streaming begins.








3. **Press** the selector knob to enter the Pandora menu.



4. You can select items such as the Station List, SKIP, Like/Dislike, and Pause/Resume.*



Notes:

- If Pandora is not selected from your phone, iPod music is played.
- Press the Home button on your iPhone to switch from Pandora to iPod. To play Pandora again, you must reopen the app from your phone.
- If you cannot operate Pandora through the audio system, it may be streaming through Bluetooth® Audio. Make sure Pandora mode on your audio system is selected.

*Menu functions not available on all phones iPhone is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries.

REAR ENTERTAINMENT SYSTEM (RES) (if equipped)

With the rear entertainment system and headphones, rear passengers can enjoy a different entertainment source than the front seat occupants.

Rear Entertainment System



Pivot the earpieces to turn on or off. Wireless headphones only work in the rear seats.





Press OPEN to release the screen.



Extend the screen until it locks into place.



Operating the RES

I. **Press** REAR POWER in the center console. **Open** the overhead screen.





3. Use the remote control to navigate the DVD or CD.



Insert a DVD or CD in the center console slot. Playback begins automatically.



Note: To hear the RES source from all speakers, **press** AUX on the audio panel.

NWNFRIINK

Owner Link allows you to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information. Register at *owners.honda.com* to ensure that you continue to enjoy the experience of owning a Honda.



SAFFTY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

FIIFI RECOMMENDATION

- Only use unleaded gasoline of 87 octane or higher.
- Some gasoline in North America contains MMT, a manganese-based fuel additive.
 Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emissions control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- "TOP TIER Detergent Gasoline" meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines. In most cases, qualifying gasoline retailers will identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. This helps avoid build-up of deposits in your engine and emission control system. Because the level of detergency and harmful metallic additives (such as MMT) in gasoline vary in the market, Honda endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. For more information, visit www.toptiergas.com.
- For further important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit Owner Link at owners.honda.com.

 $\frac{22}{2}$