

TECHNOLOGY
REFERENCE
GUIDE



CR-V

owners.honda.com

31T0AA20
00X31-T0A-A201

2014 Honda CR-V LX, EX, EX-L, and EX-L with RES
Technology Reference Guide
©2013 American Honda Motor Co., Inc. — All Rights Reserved

Printed in U.S.A.




2014

TECHNOLOGY REFERENCE GUIDE

This Technology Reference Guide is designed to help you get acquainted with your 2014 Honda CR-V LX, EX, EX-L, or EX-L with Rear Entertainment System and provide basic instructions on some of its technology and convenience features.

This guide is not intended to be a substitute for the Owner's Manual. For more detailed information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual.

EX-L with RES shown throughout guide



Instrument Panel Indicators	2
Eco Assist™	4
Tire Pressure Monitoring System (TPMS).....	5
Intelligent Multi-Information Display (i-MID)	6
Auto Door Locks	8
One-Touch Turn Signal.....	9
Multi-View Rear Camera	10
Bluetooth® HandsFreeLink® (HFL)	11

SMS Text Messaging	15
iPod® or USB Flash Drive	16
Bluetooth® Audio	17
Pandora®	18
Rear Entertainment System (RES)*	19
Honda Owners	20
Safety Reminder	20
Fuel Recommendation.....	21

*if equipped













INSTRUMENT PANEL INDICATORS







Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information. See your Owner's Manual for more information.



Malfunction Indicators

If an indicator remains on, there may be a problem; see your dealer

 Charging system	 Electric power steering (EPS)
 Low brake fluid, Brake system	 Malfunction indicator lamp (check engine light)
 Low oil pressure	 Vehicle Stability Assist® (VSA)
 Supplemental restraint system (SRS)	 Tire Pressure Monitoring System (TPMS) (blinks and stays on)
 Transmission (blinking)	 All-Wheel Drive (AWD) system*
 Anti-lock Brake System (ABS)	 Daytime running lights (DRL)



 Door/Tailgate open: Close door(s) / tailgate	 Low fuel: Refill
 Low tire pressure: Add air or calibrate system	 Maintenance Minder™: Make service appt
 All-Wheel Drive* (blinks): Pull over and idle	 Immobilizer (blinks): Use other vehicle key and see dealer

On/Off Indicators

 PASSENGER AIRBAG OFF (next to i-MID)	 Exterior lights on
 SIDE AIRBAG OFF	 Turn signals/hazards on
 VSA OFF	 Fog lights* on
 CRUISE MAIN on	 High beams on
 CRUISE CONTROL on	 ECON mode on

Condition Indicators

Action is needed by driver

 Parking brake on: Release	 Seat belt reminder: Fasten seat belt(s)
--	---

*if equipped

ECO ASSIST™


When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system are adjusted to maximize fuel efficiency.

ECON Button

1. Press **ECON** to turn the system on.



2. The **ECON** mode indicator comes on.




3. Press **ECON** again to turn the system off.



Ambient Meter


Indicates real-time fuel efficiency using color-coded bars.



TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

How It Works



When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on.


What to Do

1. Visually inspect the tires for damage.
2. Use a tire air pressure gauge to check which tire(s) have low pressure.
3. Inflate the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.



TPMS Calibration

Any time you inflate, change, or rotate one or more of the tires, you must calibrate the system.




1. Make sure the shift lever is in Park (P) and the vehicle is on.
2. Press and hold the TPMS button until the low tire pressure indicator blinks twice.

Calibration begins and will finish automatically.

INTELLIGENT MULTI-INFORMATION DISPLAY (i-MID)

Consists of several displays that provide you with useful information.


Accessing the i-MID



Press the Display button to change the main displays.



Main Displays



Steering Wheel Controls


Use the steering wheel controls to navigate through the Vehicle Menu.



(+) Button:
Press to scroll upward.

(◀) Button:
Press to go back to the previous display.

(-) Button:
Press to scroll downward.



SOURCE Button:
Press to enter your selection.

(▶) Button:
Press to go to the next display.

MENU Button:
Press to go to the Vehicle Menu for customization and other settings.

AUTO DOOR LOCKS

Default Lock/Unlock Setting



Default Lock Setting

All doors and the tailgate are preset to lock when your vehicle reaches about 10 mph.

Default Unlock Setting

Only the driver's door is preset to unlock when you shift into Park (P).

Programmable Auto Door Lock/Unlock Settings

Below are the options you can choose. See *Auto Door Locking/Unlocking* in your Owner's Manual for instructions on programming these settings.

AUTO DOOR LOCK		AUTO DOOR UNLOCK		
Auto Lock	 When you reach 10 mph	 When you shift out of Park	 When you turn the ignition OFF	 When you shift into Park
Turn off Auto Lock	 Operate manually		 When you turn the ignition OFF	 When you shift into Park
Turn off Auto Unlock	 Operate manually		 When you turn the ignition OFF	 When you shift into Park

Program how and when the vehicle doors automatically lock and unlock.

Programming the Auto Door Unlock Setting

Press the (+/-) buttons on the steering wheel to scroll through the menu options. Press SOURCE to select an option. See [page 6-7](#) for more information on the i-MID and its controls.

1. Press MENU.



2. Select Customize Settings.



3. Select Door Setup.



4. Select Auto Door Unlock.



5. Select All Doors with Shift to P.



6. Press MENU to exit.



Note: The driver's and front passenger's door can be opened by pulling the inner front door handle, regardless of the setting. Changing the setting to "All Doors" is useful for rear passengers.

ONE-TOUCH TURN SIGNAL

Use this quick and convenient method to signal a lane change.

How It Works

- Lightly push the turn signal lever up or down for a three-blink sequence.
- For a continuous signal, push the lever up or down until it locks into place.



MULTI-VIEW REAR CAMERA

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the i-MID.
- Yellow parking guidelines also appear to help you judge distance.
- The rearview display turns off when you shift out of Reverse.



Switching Views

There are three rearview modes: wide, normal, and top down. Press the selector knob to toggle between views.



Wide (default)



Normal



Top Down



BLUETOOTH® HANDSFREE LINK® (HFL)

Place and receive phone calls through your vehicle's audio system. Visit handsfreelink.honda.com to check if your phone is compatible.

To reduce the potential for driver distraction, certain functions may be inoperable or grayed out while the vehicle is moving. Stop or pull over to perform the function.

How to Use HFL





Pick-Up button: Answer an incoming call or go directly to the Phone screen.



Hang-Up/Back button: End a call, decline an incoming call, or cancel a selection.



Talk button: Make a call using a stored voice tag.



Use these buttons to navigate through the HFL menus.

Selector knob: Rotate to scroll through selections and press to make a selection.



Back button: Press to cancel an operation or return to the previous screen.

PHONE button: Go directly to the Phone screen.

Pairing Your Phone

Use this pairing method when no phone has ever been paired to the system. You can pair your compatible phone only when the vehicle is stopped.


Use the selector knob to make and enter selections.

1. Press PHONE to go to the Phone screen. A prompt appears. Select Yes.
2. Make sure your phone is in discovery mode. Select OK.
3. HFL searches for your phone. Select it when it appears on the list.

If your phone does not appear:

Select Phone Not Found, and search for HandsFreeLink from your phone. Connect to HFL.

4. HFL gives you a four-digit code. Enter it on your phone when prompted. The phone is now paired.



Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.




Use the selector knob to make and enter selections.

1. Press PHONE to go to the Phone screen. If a prompt appears asking to connect to a phone, select No.
2. Select Phone setup.
3. Select Connection.
4. Select Add a New Phone.
5. Select an empty location for the phone.
6. Make sure your phone is in discovery mode. Select OK.
7. HFL searches for your phone. Select it when it appears on the list.

If your phone does not appear:

Select Phone Not Found, and search for HandsFreeLink from your phone. Connect to HFL.

8. HFL gives you a four-digit code. Enter it on your phone when prompted. The phone is now paired.




Dialing a Number

Enter a 10-digit phone number to call. This feature is inoperable when the vehicle is moving.

Use the selector knob to make and enter selections.

1. Press PHONE to go to the Phone screen.
2. Select Dial.
3. Enter the phone number.
4. Select the green Dial icon to begin the call.




Using the Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system. This feature is inoperable when the vehicle is moving.

Use the selector knob to make and enter selections.

1. Press PHONE to go to the Phone screen.
2. Select Phonebook.
3. Scroll through the list to find the name and number you want.
4. Select the entry to begin the call.





Using Speed Dial

Store up to 15 numbers for quick calling.

Use the selector knob to make and enter selections.


1. Press PHONE to go to the Phone screen.
2. Select Speed Dial.
3. Scroll through the list to find the entry you want.
4. Select the entry to begin the call.




When a speed dial entry is stored with a voice tag, you can make a call using voice commands at any time. Press the  (Talk) button and follow the prompts. See your Owner's Manual for more information.


Receiving a Call


A notification is heard and the following screen appears:



Press the  (Pick-Up) button to answer the call.



Press the  (Hang-Up) button to end or decline the call.




SMS TEXT MESSAGING

Receive and send text messages from your paired and linked compatible phone. Visit handsfreelink.honda.com to see if this feature is compatible with your phone. Standard message rates apply. This feature is limited while the vehicle is moving.

Receiving Text Messages

Use the selector knob to make and enter selections.


1. A notification appears on the i-MID. Select Yes to open the message.
2. The message is displayed, and the system reads it aloud.



Replying to Text Messages

Use the selector knob to make and enter selections.


1. With the message open, press the selector knob to enter the Text Message Menu.
2. Select Reply.
3. Select one of the six available reply messages.
4. Select Yes to send the message.



Calling the Sender

Use the selector knob to make and enter selections.

1. With the message open, press the selector knob to enter the Text Message Menu.
2. Select Call to begin the call.




iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.


Connecting Devices and Playing Audio

1. Pull out the USB adapter cable from the center console.





Connect the USB connector to your iPod dock connector or flash drive.

2. Press SOURCE or AUX until iPod or USB mode appears. Audio begins to play.



3. Press (⏮) (⏭) or (⏪) (⏩) to change tracks.



Note: Connect your device only when your vehicle is stopped.

iPod is a trademark of Apple, Inc.

BLUETOOTH® AUDIO

Play stored or streaming audio files from your compatible phone through your vehicle's audio system. Visit handsfreelink.honda.com to check if this feature is compatible with your phone.

Playing Bluetooth Audio

1. Make sure your phone is on and paired to Bluetooth® HandsFreeLink® (see page 12).






3. From your phone, open the desired audio player or app and begin playing. Sound is redirected to the audio system.

Make sure the volume on your phone is properly adjusted.

Notes:

- You may need to enable additional settings on your phone for playback.
- Remote audio controls and the play/pause function may not be supported on all phones.
- Operate your phone only when your vehicle is stopped.

4. Press (⏮) (⏭) or (⏪) (⏩) to change tracks.




PANDORA®

Play and operate Pandora from your iPhone® through your vehicle's audio system. Standard data rates apply.

Playing Pandora

1. Pull out the USB adapter cable from the center console.




Connect your iPhone using a USB dock connector.


2. Open Pandora from your phone. Press SOURCE or AUX until Pandora mode appears and streaming begins.



3. Press the selector knob to enter the Pandora menu.



4. You can select items such as the Station List, Skip, Like/Dislike, and Pause/Resume.



Notes:

- If Pandora is not launched from your phone, iPod music is played.
- Press the Home button on your iPhone to switch from Pandora to iPod. To play Pandora again, you must reopen the app from your phone.
- If you cannot operate Pandora through the audio system, it may be streaming through Bluetooth® Audio. Make sure Pandora mode on your audio system is selected. If Pandora still does not operate, you may have to reconnect the cable.
- Connect your device only when your vehicle is stopped.

iPhone is a trademark of Apple, Inc.


REAR ENTERTAINMENT SYSTEM (RES) (if equipped)

Rear passengers can enjoy a different audio or entertainment source than the front seat occupants.

Rear Entertainment System



Press OPEN to release the screen.



Extend the screen until it locks into place.



Pivot the earpieces to turn the wireless headphones on or off. Wireless headphones work only in the rear seats.



Operating the RES

1. Press REAR POWER in the center console. Open the overhead screen.



3. Use the remote control to navigate the DVD or CD.



2. Insert a DVD or CD in the center console slot. Playback begins automatically.



Note: To hear the RES source from all speakers, press AUX on the audio panel until RES mode appears.

HONDA OWNERS

Visit owners.honda.com and register to explore features and technologies specific to your vehicle, obtain and update maintenance and service records, manage your financial services account, and access other useful information. For added convenience, Honda Owners can also be accessed on a mobile device.



SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant. See your Owner's Manual for more information.

FUEL RECOMMENDATION

Use of unleaded gasoline of 87 octane or higher is recommended.

- Honda recommends TOP TIER Detergent Gasoline where available.
- Do NOT use gasoline containing more than 15% ethanol.
- Do NOT use gasoline containing methanol.
- Do NOT use gasoline containing MMT.
- See your Owner's Manual for more information.

Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emission control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under your new vehicle warranty.

TOP TIER Detergent Gasoline (recommended) never contains MMT and has detergent additives to keep your engine clean. For further information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit owners.honda.com.