

TECHNOLOGY  
REFERENCE  
GUIDE



[owners.honda.com](http://owners.honda.com)

31TK8010  
00X31-TK8-D101

2012 Honda Odyssey Touring and Touring Elite  
Technology Reference Guide  
©2011 American Honda Motor Co., Inc. — All Rights Reserved

Printed in U.S.A.




2012 ODYSSEY TOURING  
and TOURING ELITE

# TECHNOLOGY REFERENCE GUIDE

The Technology Reference Guide is designed to help you get acquainted with your new Honda and provide basic instructions on some of its technology and convenience features. This guide covers the Odyssey Touring and Touring Elite.

This guide is not intended as a substitute for the Owner's Manual. For complete information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual.



Auto Door Locks .....	2
Instrument Panel Indicators .....	4
Multi-Information Display (MID) .....	6
Tire Pressure Monitoring System (TPMS).....	8
Driving Position Memory System (DPMS).....	9
Multi-View Rear Camera .....	10
Reverse Tilt Door Mirrors .....	11
Cool Box .....	12
HomeLink®.....	13
Voice Recognition.....	14
Navigation.....	20
FM Traffic .....	22

Bluetooth® HandsFreeLink® (HFL).....	23
Bluetooth® Audio .....	27
iPod® or USB Flash Drive.....	28
Hard Disc Drive (HDD) Audio .....	29
Song By Voice™ (SBV) .....	30
Rear Entertainment System (RES) .....	32
Ultrawide Rear Entertainment System (Elite only).....	34
Parking Sensor System .....	37
Blind Spot Information (BSI) System (Elite only).....	38
Owner Link.....	39
Safety Reminder .....	40
Fuel Recommendation.....	40

## AUTO DOOR LOCKS

### Default Lock/Unlock Setting


#### Default Lock Setting

All doors and the tailgate are preset to lock when your vehicle reaches about 10 mph.



#### Default Unlock Setting

Only the driver's door is preset to unlock when you shift into Park (P).



### Programmable Auto Door Lock/Unlock Settings

Below are the options you can choose. See *Auto Door Locking/Unlocking* in your Owner's Manual for instructions on programming these settings.

AUTO DOOR LOCK		AUTO DOOR UNLOCK	
<b>Auto Lock</b>	<p>When you reach 10 mph</p> <p>When you shift out of Park</p>	<b>Auto Unlock (all doors)</b>	<p>When you turn the ignition OFF</p> <p>When you shift into Park</p>
<b>Turn off Auto Lock</b>	<p>Operate manually</p>	<b>Auto Unlock (only driver's door)</b>	<p>When you turn the ignition OFF</p> <p>When you shift into Park</p>
		<b>Turn off Auto Unlock</b>	<p>Operate manually</p>

Program how and when the vehicle doors and the tailgate automatically lock and unlock.

### Programming the Auto Door Unlock Setting

Press either Info (▲/▼) button on the steering wheel to toggle to the "CUSTOMIZE SETTINGS" display on the MID, then press the SEL/RESET button to activate the menu.

1. Select "CHANGE SETTINGS:"



2. Select "DOOR SETUP:"



3. Select "AUTO DOOR UNLOCK."



4. Select "ALL DOORS WITH SHIFT TO P."




5. The display returns to the "AUTO DOOR UNLOCK" menu.











## INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information.



### Malfunction Indicators

If an indicator remains on, there may be a problem; see your dealer













 Charging system	 ABS (anti-lock brake system)
 Low brake fluid, brake system	 Malfunction lamp (check engine light)
 Low oil pressure	 VSA® (vehicle stability assist)
 SRS (supplemental restraint system)	 BSI (blind spot information system)*

### Condition Indicators

Action is needed by driver

 Parking brake on: <b>Release</b>	 Seat belt reminder: <b>Fasten seat belt(s)</b>
 Door/Tailgate open: <b>Close door(s)/tailgate</b>	 Low fuel: <b>Refill</b>
 Low tire pressure: <b>Add air</b>	 System message indicator: <b>See MID</b>

### On/Off Indicators


 PASSENGER AIRBAG OFF (located on center panel)	 Fuel economy on
 SIDE AIRBAG OFF	 Immobilizer Flashes: improperly coded key; <b>use correct key</b>
 VSA OFF	 Headlights on
 BSI* on	 Turn signals/hazards on
 CRUISE MAIN on	 High beams on
 CRUISE CONTROL on	
 Fog lights on	

\*Touring Elite only

## MULTI-INFORMATION DISPLAY (MID)

Displays various information and messages to help you maintain your vehicle.

### Accessing the Multi-Information Display




When you start the engine, the MID shows your last active selection from the previous drive cycle.




To toggle between the different displays:


- **Press** either Info button for the upper display.
- **Press** the SEL/RESET button for the lower display, to switch from Trip A to Trip B on the upper display, or to access lower displays.



### MID Upper Displays



### MID Lower Segment




## TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

### How It Works



Each tire valve stem contains a TPMS sensor.




When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on and a message appears on the MID.

### What to Do

1. **Visually inspect** the tires for damage.
2. **Use** a tire air pressure gauge to check which tire(s) have low pressure.



3. **Inflate** the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.



## DRIVING POSITION MEMORY SYSTEM (DPMS)

Store a driver's seat and mirror position into memory for each keyless remote.

### Programming DPMS


1. **Turn** the ignition switch to ON (II). **Shift** into Park (P).



3. **Press** the SET button. You will hear a beep.



2. **Adjust** the seat and outside mirrors to your preferred settings.



4. **Press** the memory button corresponding to the remote (1 or 2) you are using. You will hear two beeps.



**Note:** A stored memory position is linked to the corresponding keyless remote (1 or 2). Each item begins to adjust when you unlock the driver's door with the remote and enter the vehicle.

## MULTI-VIEW REAR CAMERA

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

### How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the navigation display.
- Yellow parking guide lines also appear to help you judge distance.
- The rearview display turns off when you shift out of Reverse.



### Adjusting the View

#### Turning the Guide Lines On or Off

Press and hold CANCEL for about 3 seconds.



#### Switching Views

There are three rearview modes: wide, normal, and top down.

- Press ENTER to toggle between views.
- Rotate the Interface Dial to adjust the screen brightness.



## REVERSE TILT DOOR MIRRORS

When you shift into Reverse (R), you can tilt either door mirror down slightly to improve your view as you parallel park. Shifting out of Reverse returns the tilted mirror to its original position.

### How It Works



- To tilt the driver's door mirror, **move** the mirror selector switch to the left (L) position.
- To tilt the passenger's door mirror, **move** the mirror selector switch to the right (R) position.
- To turn the feature off, **move** the switch to the middle position.



## COOL BOX

Store beverages in a conveniently located box to keep them cool.

### How It Works



- **Store** up to four 20-ounce bottles or six 12-ounce cans. Keep already cold drinks from becoming warm.
- **Press** the COOL BOX button to turn it on or off. A green indicator light appears when the Cool Box is on. Cold air from the air conditioning system flows into and circulates within the box.




### Usage Tips

- The Cool Box is not a refrigerator or cooler. It does not cool down warm drinks.
- Do not use ice.
- Do not store perishable items inside for an extended amount of time.
- Keep the box closed for best results.
- The box cannot be removed for cleaning.
- Because the air conditioning system is always on when the Cool Box is in use, fuel economy may be slightly reduced.
- If the ignition switch is turned to LOCK (0), the box maintains its temperature for one hour.

## HOMELINK®

The HomeLink Universal Transceiver can be programmed to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

### Training a Button



If you have any problems programming HomeLink, see the owner's manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit [www.homelink.com](http://www.homelink.com).



## VOICE RECOGNITION

To keep your eyes on the road and hands on the wheel, use voice commands for hands-free calling, navigation, audio, and climate control. For a full list of commands, say "Information" and "Voice Command Help."

### Key Functions by Voice Command

Control four different systems with the steering wheel buttons and the ceiling microphone.




**Pick-Up button:** Answer an incoming call, or go directly to the Phone screen.

**Talk button:** Give HFL, navigation, audio, or climate control commands.

**Back button:** Cancel a command and return to the previous screen.

**Hang-Up button:** End a call or decline a call.



### Voice Command Tips

- To hear a list of available commands at any time, press and release the Talk button, then say "Help."
- When using the Talk button, wait for a beep, then give a command.
- When the Talk button is pressed, all available voice commands are highlighted in blue.
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.

### NAVIGATION p. 20



### BLUETOOTH® HANDSFREELINK® p. 23



### AUDIO p. 19



### CLIMATE p. 19



## Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Talk button before you give a command.

### Locate Points of Interest

**Say** a command like “Display restaurant” to see restaurant icons appear on the map.



**Say** a command like “Display gas stations” to see gas station icons appear on the map.




Press and release the Talk button before you give a command.

### Get Navigation Route Information

After a destination is entered, **say** “How far to the destination?” to hear the remaining distance.



**Say** “Display entire route” to see the routing method the system mapped for your destination.




Press and release the Talk button before you give a command.

### Make Audio Selections

**Say** a command like “Radio 97.1 FM” to select that station.



**Say** a command like “DISC play track 1” to hear that song on a currently inserted CD.



Press and release the Talk button before you give a command.

### Adjust the Vehicle's Climate Setting

**Say** a command like “Air conditioner on” to start the air conditioning system.



**Say** a command like “Fan speed 4” to adjust the fan speed.



## Commonly Used Voice Commands (continued)

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Talk button before you give a command.


### General Commands (Accepted on most screens to change displays)

- Display map
- Display menu
- Display phone
- Information
- Display audio screen
- What time is it?




### Find Place Commands (Accepted on Map screen)

- Find nearest:
  - ATM
  - Honda dealer
  - gas station
  - airport
  - Mexican restaurant
  - hospital
  - bank
  - post office



### Navigation Commands (Accepted on Map screen)

- How long/far to the destination?
- Display destination map
- Display entire route



### Display Commands (Accepted on Map screen)

- Display (or hide):
  - ATM
  - gas station
  - restaurant
  - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location



Press and release the Talk button before you give a command.

### Audio Commands (Accepted on most screens)

- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM preset 1/2/3/4/5/6
- DISC play
- DISC play track #
- DISC skip forward/back
- iPod/USB/HDD play



### Setup Commands (Accepted on Setup screen)

- Brightness up/down
- Volume up/down/min/max/off
- Interface Dial Feedback off/auto/on




### Climate Control Commands (Accepted on most screens)

- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57-87)
- Temperature max hot/cold



### Help Commands (Accepted on most screens)

- Help (list of available commands for current screen)
- Voice command help (from INFO screen - list of all available navigation, audio, and climate control commands)







# NAVIGATION

## Entering a Destination Using Voice Commands

Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the Talk button before you give a command.

1. Say "Display menu." Say "Address."
2. Say "Street," then say the street name on the next screen. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).
3. A list of street names appears. Say the number next to the street you want.
4. Say the entire street address number. For example, "1-2-3-4." If necessary, say "OK" to proceed.
5. If the street address is in more than one city, a list of city names appears. Say the number next to the city you want to select.
6. The system displays the "Calculate route to" screen. Say "OK" to set the route.



Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

## Using the "Find Nearest" Command

Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Talk button before you give a command.


1. From the map screen, say "Find nearest ATM."
2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.
3. Say the number next to the destination you want to select.
4. The system calculates and displays the route.



2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.



## Map Screen Legend




## FM Traffic

Provides continuously updated info, including traffic speed, incidents, and construction in major metro areas. Works in cities where a clear FM traffic signal is available.

Press and release the Talk button before you give a command.

### Displaying Traffic Information

Say "Display traffic" to view traffic flow and icons.



Heavy traffic

Moderate traffic

Occasionally, a green line may appear indicating free-flow traffic.

**NOTE:** Traffic flow and incident icons are only displayed on map scales of 5 miles (8 km) or less.

### Incident Icons:



Incident



Road closed



Congestion



Weather




Construction

### Traffic Rerouting

The system can automatically provide detours around traffic or incidents when a destination is set.

1. Say "Display traffic incidents" to view a list of incidents on your route.




2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



3. Say "Avoid" and the incident list returns.



4. Say "Reroute" to set the new route.



## BLUETOOTH® HANDSFREELINK® (HFL)

Place and receive phone calls through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if your phone is compatible.

### How to Use HFL

**Pick-Up button:** Answer an incoming call, or go directly to the Phone screen.

**Talk button:** Give HFL commands.

**Back button:** Cancel a command and return to the previous screen.

**Hang-Up button:** End a call or decline a call.




### Pairing Your Phone


Use this pairing method when no phone has ever been paired to the system. You can only pair your Bluetooth-compatible phone when the vehicle is stopped.

Press and release the Talk button before you give a command.


1. Press the Pick-Up button to access the Phone screen. A prompt appears. Say "Yes."



2. Make sure your phone is in discovery mode, and say "OK."



3. HFL searches for your phone. Select it when it appears on the list. Go to step 4.



If your phone does not appear:

Select "Phone Not Found?" and search for a HandsFreeLink device from your phone. Connect to HFL. Go to step 4.



4. HFL gives you a four-digit code. Enter it on your phone when prompted. Say "OK" to complete.




## Pairing Your Phone (continued)

Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.



Press and release the Talk button before you give a command.

1. **Press** the Pick-Up button to access the Phone screen.
6. Make sure your phone is in Discovery mode, and **say** "OK."



If a prompt appears asking to connect to a phone, **say** "No" and continue to step 2.

2. **Say** "Phone setup."




3. **Say** "Connection."



If your phone does not appear:

**Say** "Find Another Phone" and **search** for HandsFreeLink from your phone. **Connect** to HFL.




4. **Say** "Add New Phone."



8. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.



5. **Say** the number of the location (1-6) to add the phone.



## Making a Call

### Dialing a Number



Press and release the Talk button before you give a command.

1. **Press** the Pick-Up button to access the Phone screen.
3. **Say** the entire phone number.



2. **Say** "Dial."



4. **Say** "Dial" to begin the call.



### Using the Imported Phonebook\*



Press and release the Talk button before you give a command.

1. **Press** the Pick-Up button to access the Phone screen.
3. **Scroll** the list to find the name you want to call.



2. **Say** "Phonebook."

4. **Say** the number of the entry to begin the call.




\*Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if this feature is available on your phone.


## Using Speed Dial and Voice Tags

Press and release the Talk button before you give a command.


1. **Press** the Pick-Up button to access the Phone screen.




If an entry has a stored voice tag, say “Dial by voice tag,” followed by the voice tag name and “Dial” from any screen.



2. **Say** the number next to one of the first four entries. For example, “One.” For the complete list of speed dial entries, say “More speed dial.”



3. The call is connected and heard through the speakers.




**Note:** See your Owner's Manual for instructions on storing speed dial entries and voice tags.


## Receiving a Call

1. When you receive an incoming call, you hear a notification and see one of the following pop-up messages:


On the Phone screen



On the navigation map screen



On the audio screen



2. **Press** the Pick-Up button to accept the call.



3. **Press** the Hang-Up button to end or decline the call.



## BLUETOOTH® AUDIO

Play audio files from your compatible phone through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if this feature is available on your phone.


## Playing Bluetooth Audio Files

1. Make sure your phone is on and paired to HandsFreeLink (see [page 23](#)).

2. **Press** USB/AUX until “Bluetooth Audio” appears.



3. From your phone, **open** the desired audio player or app and begin playing. Sound is redirected to the audio system.



### Notes:


- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional *Bluetooth* settings on your phone for playback.
- The play/pause function and remote audio controls may not be supported on all phones.

## iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

### Connecting Devices and Playing Audio Files

1. **Open** the glove box, and **pull out** the USB adapter cable.



3. **Press** USB/AUX to begin playing.



2. **Connect** the USB connector to your iPod dock connector or flash drive.



4. To change tracks, **rotate** the interface dial or **press** the SKIP (⏭) or (⏮) buttons.



iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

## HARD DISC DRIVE (HDD) AUDIO

Record CDs onto your vehicle's hard disc drive. Songs are automatically recorded once a CD is inserted into the disc slot.

### Playing HDD Audio Files


1. **Press** AUDIO.



3. The first song of the last recorded album plays. To change tracks, **rotate** the interface dial or **press** the SKIP (⏭) or (⏮) buttons.




2. **Press** HDD.




### Searching for Music


1. **Push** the interface dial up to select MUSIC SEARCH.



3. **Select** a track and press ENTER to begin playing.



2. **Select** one of the categories.





## SONG BY VOICE™ (SBV) (IPOD®/HDD)

Play songs from your iPod and HDD from most navigation/audio screens by using simple voice commands.

### Playing Audio Files Using Voice Commands


Press and release the Talk button before you give a command.

#### Using the "Play" Command

Say "iPod search" or "HDD search."



Say "Play" and one of the options on the Search Mode screen. For example, say "Play Artist XYZ."



if exact match found

if exact match not found


The system provides voice feedback and lists possible matches.



Say the number of the corresponding selection you wish to play. For example, say "Four."



The system plays the selection and returns to the Search Mode screen.



### Playing Audio Files Using Voice Commands (continued)

Press and release the Talk button before you give a command.

#### Using the "List" Command

Say "iPod search" or "HDD search."




Say "List" and one of the options on the Search Mode screen. For example, say "List Artist XYZ."




if exact match found

if exact match not found


A list of tracks from the selected artist displays.




The system provides voice feedback and lists possible matches.



Say the number of the artist. For example, say "Four."



Say the number of your selection. For example, say "One."




The system plays the selection and returns to the Search Mode screen.



## REAR ENTERTAINMENT SYSTEM (RES)

With the rear entertainment system and headphones, rear passengers can enjoy a different entertainment source than the front seat occupants.

### RES Front Panel Controls



### Rear Entertainment System



**Pull down** the bottom edge of the screen to open it.



**Extend** the screen until it locks into place.




**Pivot** the earpieces to turn on or off. Wireless headphones work only in the rear seats.




Wired headphones may also be used.

### Operating the RES from the Front

1. **Press REAR POWER.** Rear passengers will hear audio through the headphones.
2. **Press REAR SOURCE.** Select an entertainment source for the rear passengers.
3. **Press REAR SOURCE** again to return to the front audio controls.




2. **Press REAR SOURCE.** Select an entertainment source for the rear passengers.



### Operating the RES from the Rear

1. **Press REAR POWER** on the front audio panel. **Open** the overhead screen.
2. **Press DVD/AUX, CD/CDL, XM, or FM/AM.**
3. **Press** the (▲) (▼) (◀) (▶) buttons to navigate the menu options. **Press ENTER** to select an option.
4. The rear control panel can be detached and used as a remote control. **Press** the release button to remove it.




2. **Press DVD/AUX, CD/CDL, XM, or FM/AM.**



## ULTRAWIDE REAR ENTERTAINMENT SYSTEM (RES) (ELITE only)

With the rear entertainment system and headphones, rear passengers can enjoy a different entertainment source than the front seat occupants.

### RES Front Panel Controls



### Operating the RES from the Front

1. **Press REAR POWER.** Rear passengers will hear audio through the headphones.
3. **Press REAR SOURCE** again to return to the front audio controls.



2. **Press REAR SOURCE.** Select an entertainment source for the rear passengers.



### Rear Entertainment System



**Press OPEN** to release the overhead screen.



**Extend** the screen until it locks into place.



**Pivot** the earpieces to turn on or off. Wireless headphones work only in the rear seats.



Wired headphones may also be used.

### Operating the RES from the Rear

1. **Press REAR POWER** from the front audio panel. **Press OPEN** and open the screen.
3. **Press** the (▲) (▼) (◀) (▶) buttons to navigate the menu options. **Press ENTER** to select an option.



2. **Press SOURCE** to select an entertainment source.




## Operating the Dual Screen Mode

Play two different entertainment sources side by side on the ultrawide rear screen.



One screen can play an entertainment source from the front audio system (FM, HDD, DVD, etc.). The other screen can play an entertainment source from rear AUX or HDMI input (external DVD player, video game console, etc.).

1. **Press DUAL.**
2. **Follow** the on-screen prompts to select which side the media source plays on.



## Changing the Sound Source

While in dual screen mode, you can switch the sound source of the wireless headphones between the left and right screens.



**Slide** the tab to L for the left side or R for the right side.


## PARKING SENSOR SYSTEM

Warns you of the proximity between your vehicle and nearby surrounding objects when parking or backing up.

### How It Works

When the system senses an object, an indicator appears on the MID and center display screen and a beep sounds. As you get closer to the object, the beep rate increases.


Corner sensors



Within approx. 2 ft.



Rear center sensors




Within approx. 3.5 ft.



### Turning the System On and Off

**Press** the parking sensor button. A light appears when the system is on.




## BLIND SPOT INFORMATION SYSTEM (BSI) (ELITE only)

Assists you in determining if there are detected vehicles in your blind spots.

### How It Works


A radar sensor on each corner of the rear bumper alerts you when it detects a vehicle in your left or right blind spots.



When a vehicle is detected in your blind spot, the blind spot indicator turns on and stays lit until the area is clear.



When your turn signal is on and a vehicle is detected, the blind spot indicator blinks until the area is clear or the turn signal is off.




Left BSI indicator shown

### Turning the System On and Off

Press and hold the BSI OFF button on the dashboard to turn BSI off or on.



A message briefly appears on the MID screen showing the system status.



## OWNER LINK

Owner Link allows you to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information. Register at [owners.honda.com](http://owners.honda.com) to ensure that you continue to enjoy the experience of owning a Honda.

**HONDA | OWNER LINK**

WELCOME TO OWNER LINK

**MEMBER | BENEFITS**

**MANAGE YOUR VEHICLE**

- View recall information
- View service information
- Schedule service
- Buy Genuine Parts/Accessories
- Receive special offers
- Retrieve Radio/Navit Code
- Locate a Recognized Body Shop in your area

**MEMBER LOGIN**

Registered with another Honda site? Log in with your username and password. Note: Username and password are case sensitive.

Username: \_\_\_\_\_ Password: \_\_\_\_\_ **LOGIN**

Remember my username

[Forgot your username or password?](#)  
[Having trouble logging in?](#)

**NEW REGISTRATION**

Register and start on Owner Link. It's fast, it's free!

Are you a **Honda** owner? **Register for Owner Link**

Are you an **Acura** owner? **Register for My Acura**

**MANAGE YOUR FINANCIAL SERVICES ACCOUNT**

- Get secure online access to your lease or finance account, including statements, account history and free electronic bill payment.

Learn to use your Honda's advanced Features: Videos and Interactive modules. **Find out more**

**REGISTRATION**

Questions about registration? [FIND HELP HERE.](#)

After registration, you can always click "My Profile" to edit or update your information.

**VeriSign Secured** VERIFYP

Note: Username and password are case sensitive.

◆ first name  ◆ last name

◆ username  ◆ password (min. 6 char.)  ◆ confirm password

◆ email address  **Please Note:** E-mail spam filters may block our e-mails from being delivered. If you have a spam blocker, please set it to accept e-mails from "ownerlink@ebizmail.honda.com".

◆ confirm email address

VIN or Hull Identification Number (HIN)

◆ Where can I find my VIN? [Benefits of entering VIN](#)

promo :

**SUBMIT** **CANCEL**

## SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

## FUEL RECOMMENDATION

- Only use unleaded gasoline of 87 octane or higher.
- Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emission control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- "TOPTIER Detergent Gasoline" meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines. In most cases, qualifying gasoline retailers will identify their gasoline as having met "TOPTIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. This helps avoid build-up of deposits in your engine and emission control system. Because the level of detergency and harmful metallic additives (such as MMT) in gasoline vary in the market, Honda endorses the use of "TOPTIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. For more information, visit [www.toptiergas.com](http://www.toptiergas.com).
- For further important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit Owner Link at [owners.honda.com](http://owners.honda.com).