

TSX

owners.acura.com

31TL7Q30
00X31-TL7-Q300

2014 Acura TSX Sport Wagon Advanced Technology Guide
©2013 American Honda Motor Co., Inc. — All Rights Reserved

Printed in Japan



2014 **ADVANCED TECHNOLOGY GUIDE**

ADVANCED TECHNOLOGY GUIDE

This Advanced Technology Guide is designed to help you get acquainted with your 2014 Acura TSX Sport Wagon and provide basic instructions on some of its technology and convenience features.

This guide is not intended to be a substitute for the Owner's Manual. For more detailed information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual or Navigation Manual.

As with the Owner's Manual, this guide covers all trim levels of the Acura TSX Sport Wagon. Therefore, you may find descriptions of equipment and features that are not on your particular vehicle.

**VOICE
RECOGNITION** p. 12

NAVIGATION p. 16

**MULTI-INFORMATION
DISPLAY** p. 4

**BLUETOOTH®
HANDSFREELINK®** p. 21

AUDIO p. 28



Technology Package shown


Instrument Panel Indicators.....	2
Multi-Information Display (MID)	4
Driving Position Memory System (DPMS)	8
Reverse Tilt Door Mirror.....	9
Rearview Camera*	9
HomeLink®.....	10
Power Tailgate*	11
Voice Recognition	12
Navigation*	16
AcuraLink® Messages*	20

Bluetooth® HandsFreeLink®	21
iPod® or USB Flash Drive	28
Hard Disc Drive (HDD) Audio*	29
Song By Voice™ (SBV)*	30
Bluetooth® Audio	32
Fuel Fill Door	33
Acura Owners.....	34
Safety Reminder	34
Fuel Recommendation.....	34

*if equipped










INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information. See your Owner's Manual for more information.










Malfunction Indicators

If an indicator remains on, there may be a problem; see your dealer.










- | | |
|---|--|
|  Charging system |  Malfunction indicator lamp (check engine light) |
|  Low brake fluid, Brake system |  Vehicle Stability Assist® (VSA) |
|  Low oil pressure |  Tire Pressure Monitoring System (TPMS) (blinks and stays on) |
|  Supplemental Restraint System (SRS) |  Electric Power Steering (EPS) |
|  Anti-lock Brake System (ABS) | |

Condition Indicators

Action is needed by driver.

- | | |
|---|--|
|  BRAKE Parking brake on: Release |  Low fuel: Refill |
|  Seat belt reminder: Fasten seat belt(s) |  Low tire pressure (stays on): Add air |
|  Door/tailgate open: Close door or tailgate |  Immobilizer (blinks): Use other vehicle key and see your dealer |
|  Message indicator: See MID | |

On/Off Indicators

- | | |
|--|--|
|  PASSENGER AIRBAG OFF (above audio panel) |  Exterior lights on |
|  SIDE AIRBAG OFF |  Turn signals/hazards on |
|  VSA OFF |  Fog lights on |
|  CRUISE MAIN on |  High beams on |
|  CRUISE CONTROL on | |

MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.


Accessing the MID

When you start the engine, the MID shows the last active lower display from the previous drive cycle.




To toggle between the different displays:

- Press either Info button (▲/▼) for the main displays.
- Press SEL/RESET for the lower displays.




Main Displays



*if a call is active (Base model only)

Lower Displays




Tire Pressure Monitoring System

Alerts you when one or more of your tires have significantly low pressure.


How It Works

If the tire pressure drops significantly below recommended levels:

- The low tire pressure indicator comes on.
- CHECK TIRE PRESSURE appears on the MID, along with an indicator of the tire(s) with low pressure.



Press either INFO button (▲/▼) to scroll to the tire pressure monitor display, then press SEL/RESET to view readings.



What to Do

1. Visually inspect the tires for damage.
2. Use a tire air pressure gauge (or check the MID) to check which tire(s) have low pressure.
3. Inflate the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.



Customizing Settings Using the MID


Four groups of settings can be programmed using the MID: Meter Setup, Position Setup, Lighting Setup, and Door Setup. See your Owner's Manual for a complete list of programmable settings.

Modifying the Auto Door Unlock Setting

As the default setting, only the driver's door unlocks when you shift to Park. Follow the steps below to change the setting. Make sure you are using the key you want to change settings for (Driver 1 or Driver 2).



Press and hold either INFO button (▲/▼) to enter customization mode, then press SEL/RESET to enter the menu.



1. Select CHG SETTING.



4. Select one of the options.



2. Select DOOR SETUP.



5. Once the setting has been saved, select EXIT.



3. Select AUTO DOOR UNLOCK.



Note: The driver's and front passenger's doors can be opened by pulling the inner front door handle, regardless of the settings. Changing the setting to "All Doors" is useful for rear passengers.

DRIVING POSITION MEMORY SYSTEM (DPMS)

Store driver's seat positions into memory for each corresponding remote transmitter (1 or 2).

Programming DPMS

1. Turn the ignition switch to ON (II). Shift into Park (P).



2. Adjust the seat to your preferred position.



3. Press SET. You will hear a beep.



4. Within 5 seconds, press the memory button corresponding to the remote (1 or 2) you are using. You will hear two beeps.



Note: Once set, stored positions can be recalled by pressing one of the memory buttons (1 or 2) on the door.

REVERSE TILT DOOR MIRROR

When you shift into Reverse (R), the passenger's outside door mirror tilts down slightly to improve your view as you parallel park. Shifting out of Reverse returns the tilted mirror to its original position.

How It Works



- To tilt the passenger's door mirror, move the mirror selector switch to the right (R) position when in Reverse.
- To turn the feature off, move the switch to the middle or left (L) position.



REARVIEW CAMERA (Technology Package)

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

How It Works


- When you shift into Reverse, a real-time image of the area behind your vehicle is shown in the navigation display.
- Yellow parking guidelines also appear to help you judge distance.
- Adjust the screen brightness by turning the Interface Dial.
- The display turns off when you shift out of Reverse.



HOMELINK®

Program your vehicle to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

Training a Button



If you have any problems programming HomeLink, see the owner's manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit www.homelink.com.

POWER TAILGATE (Technology Package)

There are multiple methods to operate the power tailgate.

Opening the Power Tailgate from Inside the Vehicle

The vehicle must be in Park (P) with all doors unlocked.



- Press and hold the tailgate button until a beep sounds. The tailgate begins to open.
- To close the tailgate, press the button again at any time.

Opening the Power Tailgate Using the Remote Transmitter

The vehicle must be off with the the remote in operating range.



In ANYTIME mode: **Press and hold** the tailgate button for about one second.



In WHEN UNLOCKED mode: **Press** the unlock button twice to unlock all doors and the tailgate. Then **press and hold** the tailgate button for about one second.

Use the MID to set the power tailgate keyless open mode to your preference. See your Owner's Manual for instructions, or see [page 7](#) for an example of how to change a setting.

VOICE RECOGNITION

To keep your eyes on the road and hands on the wheel, use the Talk button to say voice commands to operate certain vehicle features.

Functions by Voice Command

Control up to five different systems with the steering wheel buttons and the ceiling microphone.




Pick-Up button: Answer an incoming call, or go directly to the Cellular Phone screen.

Talk button: Give HFL, navigation, audio, climate control, or AcuraLink commands.

Back button: Cancel a command and return to the previous screen.

Hang-Up button: End a call or decline a call.



Voice Command Tips

- When using the Talk button, wait for a beep, then say a command. To bypass the system prompts, simply press the Talk button again to say your command.
- To turn off the system prompts: Press INFO, select Setup, select Other, select Basic Settings, and select OFF for Voice Recognition Tutor.
- When the Talk button is pressed, all available voice commands are highlighted in blue.
- Speak in a clear, natural voice, and reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling, and close the windows.
- To hear a list of available commands at any time, press and release the Talk button, then say "Help." For a full list of commands by category, say "Display information" followed by "Voice Info," or see your Navigation Manual.


NAVIGATION* p. 16



BLUETOOTH® HANDSFREELINK® p. 21



ACURALINK* p. 20



AUDIO* p. 15



CLIMATE* p. 15



* Voice commands for these systems are available on Technology Package only.

Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Talk button before you say a command.

General Commands (Accepted on most screens to change displays)



- Display map
- Display menu
- Information
- Display audio screen
- What time is it?

Find Place Commands (Accepted on Map screen)




- Find nearest:
 - ATM
 - gas station
 - Mexican restaurant
 - post office
 - bank
 - Acura dealer
 - airport
 - hospital

Display Commands (Accepted on Map screen)




- Display (or hide):
 - ATM
 - gas station
 - restaurant
 - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location

Navigation Commands (Accepted on Map screen after a destination is entered)



- How long/far to the destination?
- Display destination map
- Display entire route

Help Commands (Accepted on most screens)



- Help (list of available commands for current screen)
- Voice command help (from the INFO screen - list of all available navigation, audio, and climate control commands)

Press and release the Talk button before you say a command.

Audio Commands (Accepted on most screens)



- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM 1/2 preset 1/2/3/4/5/6
- CD play
- CD play track #
- CD skip forward/back
- iPod/USB/HDD play

Climate Control Commands (Accepted on most screens)




- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57-87)
- Temperature max hot/cold

Setup Commands (Accepted on Setup screen)



- Brightness up/down
- Volume up/down/min/max/off
- Interface dial feedback on/off

Traffic Commands* (Accepted on Map screen)



- Display traffic
- Display traffic speeds
- Display traffic icons
- Display traffic incidents/list

Weather Commands* (Accepted on map screen)



- Display weather
- Display weather icons
- Display weather warning icons

*subscription required

NAVIGATION (Technology Package)

Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

Entering a Destination Address Using Voice Control


Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the Talk button before you say a command.

1. Say "Display menu." Say "Address."




4. Say the entire street address number. For example, "1-2-3-4." If necessary, say "OK" to proceed.




2. Say "Street," then say the street name on the next screen. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).



5. If the street address is in more than one city, a list of city names appears. Say the number next to the city you want.



3. A list of street names appears. Say the number next to the street you want.



6. The system displays the "Calculate route to" screen. Say "OK" to set the route.




Using the "Find Nearest" Command


Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Talk button before you say a command.


1. From the map screen, say "Find nearest ATM."




3. Say the number next to the destination you want.



2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.



4. The system calculates and displays the route.



Map Screen Legend




Calculated Route

Direction of destination

Distance to go

Current vehicle location




AcuraLink Real-Time Traffic™* (if equipped)

Provides continuously updated information, including traffic speed, incidents, and construction in major metro areas.

Press and release the Talk button before you say a command.

Displaying Traffic Information

Say "Display traffic" to view traffic flow and incident icons.



Heavy traffic

Moderate traffic

Free-flow traffic

Note: Traffic flow and incident icons are only displayed on map scales of 5 miles or less.

Incident Icons



Incident



Road closed



Congestion



Weather




Construction


Traffic Rerouting™

When a destination is already set, you can create a detour to avoid traffic incidents or congestion.


1. Say "Display traffic list" to view a list of incidents on your route.




3. Say "Avoid," and the incident list returns.



2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



4. Say "Reroute" to set the new route.



* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

AcuraLink Real-Time Weather™* (if equipped)

Provides continuously updated weather conditions, warnings, and forecasts in major metro areas.

Press and release the Talk button before you say a command.

Displaying Weather Icons

Say "Display weather" to view weather icons for each city.



Weather Icons



Clear



Fog



Partly Cloudy



Rain



Cloudy



Snow

Displaying Weather Information

Say "Information," then "Weather information" for the following options:

Weather Forecast

Say "Weather forecast" to view a 1-day or 3-day forecast of your current position or city vicinity.




Radar Image Map

Say "Radar map" to view color-coded rain or snow systems.




Weather Warning List

Say "Warning list sorted by distance" to view a list of all U.S. weather warnings by distance.



Weather Warning Map

Say "Warning map" to view color-coded severe weather systems.




* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

ACURALINK® MESSAGES (Technology Package)

Acura periodically sends you messages on vehicle features, recall and safety information, maintenance reminders, and diagnostic information.

Types of Messages

There are six kinds of messages you can receive.



Feature Guide

Daily messages on features for the first 90 days of ownership.

Quick Tips

Additional or updated vehicle information.

Scheduled Dealer Appointments

Reschedule or cancel a dealer appointment. See your Owner's Manual for more information.

Diagnostic Info

Gives further information when a warning indicator or MID message appears.

Maintenance Minder


Gives information about what service items are due.

Recalls/Campaigns


Reminds you about recalls and safety information.

Viewing New Messages

1. When you receive a new message, an envelope icon appears on the map screen.




2. From the map screen, press ENTER and select New Messages.




To view all messages by category, press INFO and select AcuraLink Messages.

3. Select the message you want to hear.



Some messages allow you to call or locate a dealer for service or more information.



BLUETOOTH® HANDSFREELINK® (Base model)


Place and receive phone calls through your vehicle's audio system. Visit www.acura.com/handsfreelink to check if your phone is compatible.

Using HFL



HFL Talk button: Give HFL commands and answer incoming calls.

HFL Back button: Cancel a command and end or decline a call.



Pairing Your Phone

Press and release the HFL Talk button before you say a command.

1. Enable discovery mode on your compatible phone.
2. If no phone has been paired before, the system gives your instructions.
3. HFL gives you a four-digit code that also appears on the MID.
4. Search for HandsFreeLink from your phone, and enter the code when prompted. Connect to HFL.
5. HFL asks you to name the phone. For example, say "Mary's phone." The phone is now paired.

If you are pairing an additional phone, say "Phone setup," then say "Pair."



Making a Call

Press and release the HFL Talk button before you say a command.

1. Say "Call" and the phone number.



3. The call is connected and heard through the speakers.



2. Say "Call" or "Dial" to begin the call.




Receiving a Call


A notification is heard and the following screen appears on the MID:



Press the HFL Talk button to accept the call.



Press the HFL Back button to decline or end the call.



HFL Phonebook

Store up to 50 names and their phone numbers, which can be used as speed dial entries.

Press and release the HFL Talk button before you say a command.

1. Say "Phonebook."



3. Say the name of the contact, and then the phone number.



2. Say "Store."



4. To call a contact once an entry is stored, say "Call Mike."



BLUETOOTH® HANDSFREELINK® (Technology Package)

Place and receive phone calls through your vehicle's navigation and audio systems. Visit www.acura.com/handsfreelink to check if your phone is compatible.

Using HFL




Pick-Up button: Answer an incoming call, or go directly to the Cellular Phone screen.

Talk button: Give HFL commands.

Back button: Cancel a command and return to the previous screen.

Hang-Up button: End a call or decline a call.




Pairing Your Phone

Use this pairing method when no phone has ever been paired to the system. You can pair your phone only when the vehicle is stopped.


Press and release the Talk button before you say a command.

1. Press the Pick-Up button to go to the Cellular Phone screen. A prompt appears asking if you want to add a phone. Say "Yes."



2. Make sure your phone is in discovery mode. Search for HandsFreeLink from your phone, and select it when it appears.

3. When your phone prompts you, enter the 4-digit pass-key from HFL.



4. Follow your phone's prompts and connect to HFL.



Pairing Your Phone (continued)

Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

Press and release the Talk button before you say a command.

1. Press the Pick-Up button to go to the Cellular Phone screen.



If a prompt appears asking if you want to connect to a phone, say "No."

2. Say "Phone setup."



3. Say "Setup Bluetooth phone."




4. Say "Pair phone."




5. Make sure your phone is in discovery mode. Search for HandsFreeLink from your phone, and select it when it appears.

6. When your phone prompts you, enter the 4-digit pass-key from HFL.



7. Follow your phone's prompts and connect to HFL.



Making a Call

Dialing a Number

Press and release the Talk button before you say a command.


1. Press the Pick-Up button to go to the Cellular Phone screen.
3. Say the entire phone number.



2. Say "Dial."



4. Say "Dial" to begin the call.



Using the Imported Phonebook*

Press and release the Talk button before you say a command.

1. Press the Pick-Up button to go to the Cellular Phone screen.




HFL imports your phonebook if it is not already imported.



2. Say "Phonebook."



3. Say the number of the entry you want to call.



*Visit www.acura.com/handsfreelink to check if this feature is available on your phone.


Using Speed Dial and Voice Tags

Press and release the Talk button before you say a command.

1. Press the Pick-Up button to go to the Cellular Phone screen.



If an entry has a stored voice tag, say "Dial by voice tag," followed by the voice tag name and "Dial" from any screen.



2. Say the number next to one of the first four entries. For example, "One." For the complete list of speed dial entries, say "More speed dial."




3. The call is connected and heard through the speakers.



Note: See your Owner's Manual for instructions on storing speed dial entries and accompanying voice tags.

Receiving a Call

When you receive an incoming call, you hear a notification and see the following pop-up message:



Press the Pick-Up button to accept the call.



Press the Hang-Up button to end or decline the call.




iPod® or USB Flash Drive

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system. See your Owner's Manual for a list of compatible devices.

Connecting and Playing Audio

- 1. Open the center console, and pull out the USB adapter cable.
- 3. Press (⏮) (⏭) or (+) (-) to change tracks.



Connect the USB connector to your iPod dock connector or flash drive.

- 2. Press AUX until iPod or USB appears.



Note: Connect your device only when your vehicle is stopped.

iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

HARD DISC DRIVE (HDD) AUDIO (Technology Package)

Record CDs onto your vehicle's hard disc drive. Songs are automatically recorded once a CD is inserted into the disc slot.

Playing HDD Audio

- 1. Press DISC/HDD until HDD appears.
- 2. The first song of the last recorded album or the last song selected plays. Press (⏮) (⏭) or (+) (-) to change tracks.



Searching for Music

- 1. Press AUDIO.
- 3. Select one of the categories.



- 2. Push the interface dial up to select MUSIC SEARCH.
- 4. Select a track and press ENTER to begin playing.



SONG BY VOICE™ (SBV) (Technology Package)

Play songs from your iPod and HDD from most screens by using voice commands.

Playing Audio Files Using Voice Commands

Press and release the Talk button before you say a command.

Using the “Play” Command

Say “iPod search” or “HDD search.”




Say “Play” and one of the options on the Search Mode screen. For example, say “Play Artist XYZ.”




if exact match found

if exact match not found


The system provides voice feedback and lists possible matches.



Say the number of the corresponding selection you wish to play. For example, say “Four.”



The system plays the selection and returns to the Search Mode screen.



Playing Audio Files Using Voice Commands (continued)

Press and release the Talk button before you say a command.

Using the “List” Command

Say “iPod search” or “HDD search.”




Say “List” and one of the options on the Search Mode screen. For example, say “List Artist XYZ.”




if exact match found

if exact match not found

A list of tracks from the selected artist displays.




The system provides voice feedback and lists possible matches.



Say the number of the artist. For example, say “Four.”



Say the number of your selection. For example, say “One.”



The system plays the selection and returns to the Search Mode screen.




BLUETOOTH® AUDIO

Play audio files from your compatible phone through your vehicle's audio system. Visit www.acura.com/handsfreelink to check if this feature is compatible with your phone.

Playing Bluetooth Audio

1. Make sure your phone is on and paired to Bluetooth® HandsFreeLink® (see [page 21](#) or [page 24](#)).
2. Press AUX until Bluetooth Audio appears.
3. From your phone, open the desired audio player or app and begin playing. Sound is redirected to the audio system.
4. Press (⏮) (⏭) or (+) (-) to change tracks.



Notes:


- You may need to enable additional Bluetooth settings on your phone for playback.
- Remote audio controls and the play/pause function may not be supported on all phones.
- Operate your phone only when your vehicle is stopped.

FUEL FILL DOOR

Easy-to-use locking fuel door keeps your fuel cap covered.

Opening the Fuel Fill Door

When you unlock the driver's door with the master door lock switch or the remote transmitter, the fuel door unlocks.



To open, push and release the fuel door in the area shown until it pops open.




Closing the Fuel Fill Door

Push the fuel door until it is flush to the body.




When you lock the driver's door, the fuel door locks.



ACURA OWNERS

Visit owners.acura.com and register to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information.



SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace your seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

FUEL RECOMMENDATION

Use of unleaded premium gasoline of 91 octane or higher is recommended.

- Acura recommends TOP TIER Detergent Gasoline where available.
- Do NOT use gasoline containing more than 10% ethanol.
- Do NOT use gasoline containing methanol.
- Do NOT use gasoline containing MMT.
- See your Owner's Manual for more information.

Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emission control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under your new vehicle warranty.

TOP TIER Detergent Gasoline (recommended) never contains MMT and has detergent additives to keep your engine clean. For further information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit owners.acura.com.