



### **Multi-Information Display (MID)**

The MID consists of several displays that provide you with useful information.

1. Start your vehicle.



2. "ECON ON" or "ECON OFF" shows on the MID followed by the main screen.



 Toggle between the different displays using either INFO (▲/▼) button (see next page).










#### **MID Displays**

Once you press one of the INFO buttons, the MID shows the last active display from previous drive cycle.



Check your owner's manual for additional information and instructions.

Multi-Information Display

### Ecological Drive Assist System (Eco Assist™) -

The system monitors your driving style, then provides real-time feedback you can use to develop a style that maximizes fuel economy. It is always on and consists of the: ECO Guide (in the MID), Ambient Meter, ECON Mode button, and the ECON indicator.

#### **FCON On Mode**

Helps you further maximize your fuel economy by modifying some vehicle function.




Fuel Efficiency

High

Low

#### Driver Feedback



#### Goals:

- · Keep the Eco Drive bar near the center.
- Keep the Ambient Meter at GREEN.
- Develop a driving style that maximizes fuel efficiency.


#### **ECO Assist Scoring**

Eco Assist scoring monitors the fuel efficiency of your driving style in real time and converts results into leaves, which are displayed on a series of five "plant" icons on the MID screen.





you drive, you will earn leaves if you drive in a fuel efficient manner, and lose them if you drive inefficiently.



your drive cycle and lifetime

score are displayed on the MID.

Stage 3

Score

Eco Score
Each time you reach a new stage, a Stage Up Recognition
Up Recognition icon will briefly appear on the MID. When you reach the highest ranking, a Trophy icon will briefly appear.

Stage 2

Stage 1

### Auto Idle Stop -

Under certain conditions, the Auto Idle Stop system will shut the engine off at a stop in order to maximize fuel efficiency. Idle stop duration may vary depending upon the humidity outside.



**Note:** The Auto Idle Stop will not function if you come to a stop while driving with the transmission in a position other than "D".

### IMA Charge/Assist Gauge —

This gauge shows the status of the Integrated Motor Assist (IMA).

The gauge shows you when the IMA battery is assisting the engine or charging.

**Note:** The IMA assist and Auto Idle Stop may not operate if it is extremely hot or cold outside.





Check your owner's manual for additional information and instructions.

Eco Assist™/Auto Idle Stop/Charge Assist

# Advanced Audio Components

# Playing an iPod® or USB Flash Memory Device (EX and EX with navigation)

Some of the same controls used to operate your in-dash CD player are used to operate an iPod or USB flash memory device.

#### Connecting and Beginning Play

 Open the center console, and pull out the USB adapter cable.



Connect your USB connector to your flash drive or iPod dock connector.





3. **Push** the AUX button or **touch** the AUX icon to begin playing.



### PC Card Instructions

#### Connecting and Beginning Play

1. Press the OPEN button.



If necessary, insert your PC card into a PC card adapter.



3. **Insert** the PC card into the slot and **press** the CLOSE button.



 Press the AUDIO button beside the screen to show the audio display. Operate the PC card using your vehicle's audio unit.



Check your owner's manual for additional information and instructions.

Advanced Audio Components

#### **Voice Command**

#### Using the Voice Command System

A list of navigation, audio, and climate control voice commands is in the navigation system manual.



#### **Voice Control Tips:**


- Press and release the button, wait for a beep, then give a command.
- To hear a list of available commands, say "Help" at any time after you press and release the button.
- · Always speak in a clear, natural voice.


- · Reduce all background noise.
- Adjust the dashboard and side vents so air does not blow against the microphone in the ceiling.
- · Close the windows.

# 2010 Insight

#### Bluetooth® HandsFreeLink® (if equipped)

Pairing Your Phone





(On some phones, you may need to search for a Bluetooth device.) When HFL finds your phone, your phone will prompt you to connect to HFL.

Was connection successful? NO YES

Before pairing your phone, make sure it information or troubleshooting, call HFL consumer support at (888) 528-7876, visit handsfreelink.honda.com, or see your owner's manual for details.

#### Making a Call

 Press the HFL TALK button.



3. Press the **HFL TALK** button and say "Call" or "Dial" to continue.



2. Say "Call 310-555-1234."



 The call is connected; all communications will be heard through the speakers.



#### Receiving a Call



"INCOMING CALL" and the phone number will appear on the MID.



Press the **HFL TALK** button to accept the call.

Press the **HFL BACK** button to decline the call.



#### Navigation (if equipped)

**Entering a Destination Using Voice Control** 

#### Press and release the NAVI TALK button before giving each command.

- 1 Say "Display menu."
- 2 Say "Address."
- 3 Say "City" (or "Change state" if necessary).
- Say the name of the city you want, or say "Current city" to select the city currently shown.
- A list of city names will appear. Say the number listed next to the city you want to select.
- Say the street name. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).

- A list of street names will appear. Say the number listed next to the street you want to select.
  - 8 Say the entire street address number. For example, "1-2-5-0."
  - 9 The system will calculate the route and display the "Calculate route to" screen. Say "OK" to set the route.



#### Entering a Destination Using the "Find Nearest" Command

Try these simple steps to find a nearby point of interest, such as a gas station, movie theater, or restaurant.

#### Press and release the NAVI TALK button before giving each command.

1. Say "Find nearest ATM."



A list of the nearest ATMs in your area will be displayed by shortest distance to destination.



3. Say the number of the destination you want.



 The system will calculate the route and display the "Calculate route to" screen. Say "OK" to set the route.



### **Commonly Used Voice Commands**

### Navigation Commands



### **General Commands**

- Accepted on map screen
- Display menu
- Display setup
- Display information
- · Display audio screen
- Go home

Accepted on map screen (after a destination has been entered)

- · How long/far to the destination?
- Display destination
- · Display entire route

#### **Display Commands**

- Accepted on map screen
- Display or hide (choose one):
  - ATM/gas station/restaurant/etc.
- · Display north up/heading up
- · Zoom in/out

#### Find Nearest Commands

Accepted on map screen

- Find nearest (choose one):
  - Mexican restaurant
  - Gas station
  - ATM
  - Honda dealer

#### Information



#### Help Commands

- Accepted on most screens
- Help (The system reads and lists all available commands for the current screen.)
- Voice command help (The system reads and lists all navigation, audio, setup, and climate control commands.)

## Setup Commands

- Accepted on the setup screen
- Brightness up/down
- Volume up/down/min/max/off
- Guidance prompts min/normal/max

#### Audio/ Climate Control



#### Audio Commands

Accepted on most screens

- Radio on/off
- Radio # FM (# = frequency)
- Radio preset 1/2/3/4/5/6
- CD play
- AUX play

### **Climate Control Commands**

- Accepted on most screens
- Air conditioner on/off
- · Rear defrost on/off
- · Climate control recirculate/fresh air
- · Fan speed up/down
- Temperature # degrees (# = 57–87)
- Temperature up/down
- Temperature max hot/cold

Check your owner's manual for additional information and instructions.

#### **About This Technology Reference Guide**

This Technology Reference Guide has been prepared to help you get quickly acquainted with your new Honda, and to provide reference instructions on driving controls and convenience items.

However, this guide is not intended as a substitute for the Owner's Manual. For complete information on operating the vehicle safely, please refer to the Owner's Manual.

As with the Owner's Manual, this guide covers all models of the Honda Insight. Therefore, you may find descriptions of equipment and features that are not on your particular model.

#### Safety Reminder

Your vehicle is equipped with airbags. Airbags do not replace your seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but the do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

#### **Fuel Recommendation**

- Use only unleaded gasoline of 87 octane or higher.
- Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emissions control system. Always use MMT-free gasoline if alternatives exist. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- For further important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit Owner Link at www.hondacars.com.





2010 Honda Insight Technology Reference Guide
© 2009 American Honda Co., Inc. – All Rights Reserved