

# TECHNOLOGY REFERENCE GUIDE



[www.owners.honda.com](http://www.owners.honda.com)

31SVAQ50  
00X31-SVA-Q501

2011 Honda Civic Coupe Technology Reference Guide  
©2010 American Honda Motor Co., Inc. — All Rights Reserved

12345  
1234.5678.91.0  
Printed in U.S.A.



## 2011 CIVIC COUPE


# TECHNOLOGY REFERENCE GUIDE

The Technology Reference Guide is designed to help you get acquainted with your new Honda and provide basic instructions on some of the technology items.

This guide is not intended as a substitute for the Owner's Manual. For complete information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual.

As with the Owner's Manual, this guide covers all trim levels of the Civic Coupe. Therefore, you may find descriptions of equipment and features that are not on your particular vehicle.

Auto Door Locks .....	2
Instrument Panel Indicators .....	4
Information Display .....	6
Tire Pressure Monitoring System (TPMS).....	7
Voice Recognition (if equipped).....	8
Navigation (if equipped).....	14



Bluetooth® HandsFreeLink® (HFL) (if equipped) .....	16
iPod® or USB Flash Memory Device.....	19
PC Card (models with navigation).....	20
Owner Link.....	21
Safety Reminder .....	22
Fuel Recommendation.....	22

## AUTO DOOR LOCKS

### Default Lock Setting



The doors are preset to lock when your vehicle reaches about 10 mph.

### Default Unlock Setting



Only the driver's door is preset to unlock when you:

- **Shift** into Park (P) for automatic transmission vehicles.
- **Turn** the ignition switch to ACC (I) for manual transmission vehicles.

Program how and when the vehicle doors automatically lock and unlock.

### Programming the Auto Door Unlock Setting

To program all doors to unlock when you shift to Park:

1. **Close** the driver's door. **Shift** into Park.



2. **Turn** the ignition switch to ON (II).



3. **Press and hold** the unlock side of the master lock switch for about 10 seconds. In that time, you will hear three clicks.



4. Within 5 seconds, **turn** the ignition switch to LOCK (0).



### Programmable Auto Door Lock/Unlock Settings

Below are the options you can choose. See *Auto Door Locking/Unlocking* in your owner's manual for instructions on programming these settings.

AUTO DOOR LOCK		
Auto Lock		
	When you reach 10 mph	When you shift out of Park
Turn off Auto Lock		
	Operate manually	

AUTO DOOR UNLOCK		
Auto Unlock (all doors)		
	When you turn the ignition OFF	When you shift into Park
Auto Unlock (only driver's door)		
	When you turn the ignition OFF	When you shift into Park
Turn off Auto Unlock		
	Operate manually	











## INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information.









### Malfunction Indicators

If an indicator remains on, there may be a problem; see your dealer












	Charging system		ABS (anti-lock brake system)
	Low brake fluid		DRL (daytime running lights)
	Low oil pressure		Malfunction indicator lamp (check engine light)
	SRS (supplemental restraint system)		TPMS (tire pressure monitoring system)
	EPS (electric power steering)*		VSA (vehicle stability assist)*

### Condition Indicators

Action is needed by driver

	Parking brake on: <b>Release</b>		Low fuel: <b>Refill</b>
	Door/Trunk open: <b>Close door(s) / trunk</b>		Low tire pressure: <b>Add air</b>
	Seat belt reminder: <b>Fasten seat belt(s)</b>		Maintenance Minder™: <b>Make dealer appointment</b>

### On/Off Indicators

	PASSENGER AIRBAG <b>OFF</b> (above Hazard Warning button)		1st detent: parking lights <b>on</b> 2nd detent: headlights <b>on</b>
	SIDE AIRBAG <b>OFF</b>		Turn signals/hazards <b>on</b>
	VSA blinks: <b>active*</b> VSA solid: <b>OFF</b>		Fog lights <b>on*</b>
	CRUISE CONTROL <b>on*</b>		High beams <b>on</b>
	CRUISE MAIN <b>on*</b>		Rev limit indicator**
	Immobilizer Flashes: improperly coded key; <b>use correct key</b>		

\* if equipped  
\*\* Si model only

## INFORMATION DISPLAY

Consists of several displays that provide you with useful information.

### Accessing the Information Display




002300 TRIP A 1234

When you start the engine, the information display shows your last active selection from the previous drive cycle.

SEL  
RESET mph  
km/h

To toggle between the different displays, **press and release** the SEL/RESET button repeatedly.

### Information Displays



\* if equipped

## TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

### How It Works



Each tire valve stem contains a TPMS sensor.



When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on.

**TPMS**

If the TPMS indicator appears, there may be a problem with the system. See your dealer.

### What to Do

1. **Visually inspect** the tires for damage.
2. **Use** a tire air pressure gauge to check which tire(s) have low pressure.



3. **Inflate** the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.





## VOICE RECOGNITION (if equipped)

To keep your eyes on the road and hands on the wheel, use voice commands for hands-free calling, navigation, and audio. For a full list of commands, **say** "Information" and "Voice Command Help."

### Key Functions by Voice Command

Control three different systems with the steering wheel buttons and the ceiling microphone.



**HFL Talk button:** Give HFL commands or answer incoming calls.

**Navi Talk button:** Give navigation, audio, and climate control commands.

**Navi Back button:** Cancel a command or return to the previous screen.

**HFL Back button:** End a call, go back to the previous command, or cancel an operation.



### Voice Command Tips

- **Press and release** the HFL or Navi Talk button, wait for a beep, then give a command.
- For a list of available HFL commands, **press and release** the HFL Talk button and **say** "Hands-free help."
- For a list of available navigation commands, **press and release** the Navi Talk button and **say** "Help."
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.

### NAVIGATION p. 14



### BLUETOOTH® HANDSFREELINK® p. 16



### AUDIO p. 13



## Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.


Press and release the NaviTalk button before you give a command.

### Locate Points of Interest

**Say** a command like “Display restaurant” to see restaurant icons appear on the map.



**Say** a command like “Display gas stations” to see gas station icons appear on the map.




Press and release the NaviTalk button before you give a command.

### Get Navigation Route Information

After a destination is entered, **say** “How far to destination?” to hear the remaining distance.



**Say** “Display entire route” to see the routing method the system mapped for your destination.



Press and release the NaviTalk button before you give a command.

### Make Audio Selections

**Say** a command like “Radio 97.1 FM” to select that station.



**Say** a command like “CD play track 1” to hear that song on a currently inserted CD.



**Say** a command like “Card play” to begin playing an inserted PC card with audio files.



**Say** a command like “Auxiliary play” to begin playing a connected audio device (you cannot use voice commands to control the device).



## Commonly Used Voice Commands (continued)

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the NaviTalk button before you give a command.

### General Commands

(Accepted on most screens to change displays)


- Display map
- Display menu
- Information
- Display audio screen
- What time is it?



### Find Place Commands

(Accepted on Map screen)


- Find nearest:
  - ATM
  - gas station
  - Mexican restaurant
  - post office
  - Honda dealer
  - airport
  - hospital
  - bank



### Navigation Commands

(Accepted on Map screen)

- How long/far to destination?
- Display destination
- Display entire route



### Display Commands

(Accepted on Map screen)

- Display/Hide:
  - ATM
  - gas station
  - restaurant
  - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location



Press and release the NaviTalk button before you give a command.

### Audio Commands

(Accepted on most screens)


- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- CD play
- CD play track #
- CD skip forward/back
- Auxiliary (AUX) play



### Setup Commands

(Accepted on Setup screen)


- Brightness up/down
- Volume up/down/min/max/off
- Guidance prompts min/max/normal



### Help Commands

(Accepted on most screens)

- Help (list of available commands for current screen)
- Voice command help - from INFO screen (list of all available navigation and audio commands)





## NAVIGATION (if equipped)






Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

### Entering a Destination

#### Using Voice Control

Press and release the Navi Talk button before you give a command.

1. Say "Display menu" and "Address."
2. Say "Street" followed by the street name. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).
3. A list of street names appears. Say the number next to the street you want to select.
4. Say the entire street address number. For example, "1-2-3-4."
5. If the street address is in more than one city, a list of city names appears. Say the number next to the city you want to select.
6. The system calculates the route and displays the "Calculate route to" screen. Say "OK" to set the route.





#### Using the Find Nearest Command

Try these simple steps to find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Navi Talk button before you give a command.

1. Say "Find nearest ATM."
2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.
3. Say the number next to the destination you want to select.
4. The system calculates the route and displays the "Calculate route to" screen. Say "OK" to set the route.



#### Map Screen Legend

Direction of destination

Distance to go

Time to go

Calculated route

Current vehicle location



## BLUETOOTH® HANDSFREELINK® (HFL) (if equipped)

### Pairing Your Phone



**HFL Talk button:** Give HFL commands or answer incoming calls.

**HFL Back button:** End a call, go back to the previous command, or cancel an operation.




Press and release the HFL Talk button before you give a command.

1. **Enable** "Discovery" or "Search" mode on your compatible phone.
2. **Say** "Phone setup," then **say** "Pair."



3. HFL gives you a four-digit code and begins to search for your phone.



4. **Search** for a HandsFreeLink device from your phone, and connect to HFL.



5. **Enter** the four-digit code on your phone when prompted.
6. HFL asks you to name the phone. For example, **say** "Mary's phone."



Place and receive phone calls through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if your phone is compatible.

### Making a Call

Press and release the HFL Talk button before you give a command.

1. **Press** the HFL Talk button, and **say** "Call" or "Dial" and the desired phone number.



2. **Press** the HFL Talk button, and **say** "Call" or "Dial" to continue.




3. The call is connected and heard through the vehicle's speakers.



### Receiving a Call

1. A notification is heard and the HandsFreeLink display appears on the screen.



2. **Press** the HFL Talk button to accept the call.



3. **Press** the HFL Back button to end or decline the call.



## HFL Phonebook

Store up to 50 names and their phone numbers, which can be used as speed dials.

Press and release the HFL Talk button before you give a command.

1. **Say** "Phonebook."




3. **Say** the name of the contact, and then the phone number.



2. **Say** "Store."



4. To call a contact once an entry is stored, **say** "Call Mike."




## Cellular Phonebook\* (models with navigation)


Import your entire cell phone's address book to the navigation system.

Press and release the NaviTalk button before you give a command.

1. **Say** "Display Information" and "Cellular Phone."



3. HFL begins to import your contacts to the system.



2. **Say** "Import Cellular Phonebook."



4. To call a contact, **say** "Search Imported Phonebook" and select the name and number.



\*not available on all phones

## IPOD® OR USB FLASH MEMORY

Play audio files from your compatible iPod or USB flash memory device through your vehicle's audio system.

## Connecting Devices and Playing Audio Files

1. **Pull out** the USB adapter cable from the center console.



4. **Press** the SKIP buttons to change tracks.

without navigation



2. **Connect** the USB connector to your iPod dock connector or flash drive.



with navigation



3. **Push** AUX or **touch** the USB icon to begin playing.

without navigation



with navigation



iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

## PC CARD (models with navigation)

Play audio files from your compatible PC card through your vehicle's audio system.

### Connecting Devices and Playing Audio Files

#### 1. Press OPEN.



#### 3. Insert the PC card into the slot and press CLOSE.



#### 2. If necessary, insert your PC card into a PC card adapter.



#### 4. Press AUDIO to show the audio display. Press the << and >> buttons to skip through tracks on the card.



## OWNER LINK

Owner Link allows you to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information. Register at [www.owners.honda.com](http://www.owners.honda.com) to ensure that you continue to enjoy the experience of owning a Honda.

**HONDA | OWNER LINK®**

Now Live - 2010 Honda Insight Model Information Guide  
Learn All About Its Advanced Features

**MEMBER | BENEFITS**

**MANAGE YOUR VEHICLE**

Caring for your vehicle has never been easier. Now you can schedule service visits, view your maintenance schedule and shop for parts and accessories, all from the comfort of home. Plus, receive personalized special offers and tips designed to help you get the most from your Honda—right here on Owner Link. [Register today.](#)

- [View recall information](#)
- [View service information](#)
- [Schedule service](#)
- [Buy Genuine Parts/Accessories](#)
- [Receive special offers](#)
- [Retrieve Radio/Navi Code](#)

**MEMBER LOGIN**

Registered with another Honda site?  
Log in with your username and password  
Note: Username and password are case sensitive.

Username:  Password:  [LOGIN](#)

☐ Remember my username

[Forgot your username or password?](#)  
[Having trouble logging in?](#)

**NEW REGISTRATION**

Register now to get started on Owner Link. It's fast, it's easy.

**Are you a Honda owner?** [Register for Owner Link](#)

**Are you an Acura owner?** [Register for My Acura](#)

**MANAGE YOUR FINANCIAL SERVICES ACCOUNT**

Our commitment to service extends well beyond the dealership. With Owner Link, you can update your address, view your statement and make secure online payments to your financial services Account. It's easy to use. And, it's available 24 hours a day, 7 days a week. [Register today.](#)

- [Get secure online access to your lease or finance account, including statements, account history and free electronic bill payment.](#)

**REGISTRATION**

Questions about registration?  
[FIND HELP HERE.](#)

After registration, you can always click "My Profile" to edit or update your information.

Note: Username and password are case sensitive.

first name  last name

username  password (min. 6 char.)  confirm password

email address

confirm email address

VIN or Hull Identification Number (VIN)

promo :

[SUBMIT](#) [CANCEL](#)

[Need help with registration?](#)

Please Note: E-mail spam filters may block our e-mails from being delivered. If you have a spam blocker, please set it to accept e-mails from "ownerlink@ebizmail.honda.com".

Where can I find my VIN?  
[Benefits of entering VIN](#)

## SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

## FUEL RECOMMENDATION

- Only use unleaded gasoline of 87 octane or higher. For Civic Si models, unleaded gasoline of 91 octane or higher is required.
- Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emissions control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- "TOP TIER Detergent Gasoline" meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines. In most cases, qualifying gasoline retailers will identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. This helps avoid build-up of deposits in your engine and emission control system. Because the level of detergency and harmful metallic additives (such as MMT) in gasoline vary in the market, Honda endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. For more information, visit [www.toptiergas.com](http://www.toptiergas.com).
- For further important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit Owner Link at [www.owners.honda.com](http://www.owners.honda.com).