

owners.acura.com

2013 Acura RDX with Technology Package
Advanced Technology Guide

©2012 Honda Motor Co., Ltd. — All Rights Reserved

Printed in U.S.A.



2013 RDX with
Technology
Package
ADVANCED TECHNOLOGY GUIDE

31TX4B00
00X31-TX4-B001

ADVANCED TECHNOLOGY GUIDE

The Advanced Technology Guide is designed to help you get acquainted with your new Acura and provide basic instructions on some of its technology and convenience features. This guide covers the RDX with Technology Package.

This guide is not intended to be a substitute for the Owner's Manual. For more detailed information on vehicle controls and operation, please refer to the respective sections in the Owner's or Navigation Manual.

Keyless Access System	2
Instrument Panel Indicators	4
Multi-Information Display (MID)	6
Driving Position Memory System (DPMS)	10
Reverse Tilt Door Mirrors	10
Multi-View Rear Camera	11
One-Touch Turn Signal	12
Auto Headlights with Wiper Integration	12
Power Tailgate	13
Voice Recognition	14
Navigation	20
AcuraLink Real-Time Traffic™	22
AcuraLink Real-Time Weather™	23

**BLUETOOTH®
HANDSFREELINK®** p.24

NAVIGATION p.20

**MULTI-INFORMATION
DISPLAY** p. 6

**VOICE
RECOGNITION** p. 14

AUDIO p.31

Bluetooth® HandsFreeLink®	24
SMS Text Messaging	28
AcuraLink® Messages	30
Bluetooth® Audio	31
Hard Disc Drive (HDD) Audio	32
iPod® or USB Flash Drive	33
Song By Voice™	34
Pandora®	36
HomeLink®	37
My Acura	38
Safety Reminder	39
Fuel Recommendation	39

KEYLESS ACCESS SYSTEM

Operate certain functions of your vehicle by simply having the remote transmitter within operating range.

Unlocking the Doors



Grab either one of the front door handles when the vehicle is off.




Locking the Doors



Press the door lock button on either front door handle when the vehicle is off.



Opening the Tailgate



Press the tailgate release button under the tailgate handle when all doors are unlocked. The vehicle can be on or off.



See page 13 for more information on opening the tailgate.

Engine Start/Stop Button

Accessory Mode

Use audio, power sockets, etc., without turning the engine on.



Press the ENGINE START/STOP button once (without pressing the brake pedal).



Starting the Engine




Press and hold the brake pedal, then press the ENGINE START/STOP button.



Turning the Engine Off



Shift to Park, then press the ENGINE START/STOP button.















INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information.



Malfunction Indicators



If an indicator remains on, there may be a problem; see your dealer.

- | | |
|---|--|
|  Charging system |  AWD* (All-Wheel Drive) |
|  Low brake fluid |  Malfunction lamp (check engine light) |
|  Low oil pressure |  VSA® (Vehicle Stability Assist) |
|  SRS (Supplemental Restraint System) |  TPMS (blinks) (Tire Pressure Monitoring System) |
|  ABS (Anti-lock Brake System) |  Brake system |
|  Keyless Access System |  EPS (electric power steering) |

Condition Indicators

Action is needed by driver.

- | | |
|--|--|
|  Parking brake on: Release |  Message indicator: See MID |
|  Seat belt reminder: Fasten seat belt(s) |  Low fuel: Refill |

- | | |
|---|---|
|  Door/tailgate open indicator: Close door/tailgate |  Low tire pressure (stays on): Add air |
|---|---|

On/Off Indicators

- | | |
|---|--|
|  PASSENGER AIRBAG OFF (next to screen) |  Fog lights on |
|  SIDE AIRBAG off |  Immobilizer (flashes): improperly coded key; use correct key |
|  VSA off |  Headlights on |
|  CRUISE MAIN on |  Turn signals/hazards on |
|  CRUISE CONTROL on |  High beams on |

*if equipped

MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.

Accessing the MID


When you start the engine, the MID shows the last active lower display from the previous drive cycle.




- To toggle between the different displays:
- Press either Info button (▲/▼) for the main displays.
 - Press SEL/RESET for the lower displays.



Main Displays



Lower Displays



Customizing Settings Using the MID

Program various vehicle settings using the MID. One example is shown below. See your Owner's Manual for other customizable settings.

Programming the Auto Door Unlock Setting

Only the driver's door is preset to unlock when you shift into Park (P). You can change this to a different setting.



Press either Info button (▲/▼) on the steering wheel to toggle to the Customize Settings display, then press SEL/RESET to activate the menu.




1. Select DOOR SETUP.



2. Select AUTO DOOR UNLOCK.



3. Select the option you want.



4. The setting is displayed, and the display returns to the AUTO DOOR UNLOCK menu.



Note: The driver's and front passenger's door can be opened by pulling the inner front door handle, regardless of the setting. Changing the setting to "All Doors" is useful for rear passengers and opening the power tailgate.

Tire Pressure Monitoring System

Alerts you when one or more of your tires have significantly low pressure. Toggle to the tire pressure monitor display to view pressure readings on the MID.

How It Works




If the tire pressure drops significantly below recommended levels:

- The low tire pressure indicator comes on.
- A "CHECK TIRE PRESSURE" message appears on the MID, showing which tire(s) have low pressure.



What to Do

1. Visually inspect the tires for damage.
2. Use a tire air pressure gauge (or check the MID) to check which tire(s) have low pressure.



3. Inflate the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.



DRIVING POSITION MEMORY SYSTEM (DPMS)

Store up to two driver's seat and mirror positions into memory, which are activated by the corresponding remote transmitters.

How It Works

1. Turn the vehicle on. Shift into Park (P).




3. Press SET. You will hear a beep.



2. Adjust your preferred seat and outside mirror settings.



4. Press the memory button corresponding to the remote (1 or 2) you are using. You will hear two beeps.



Note: Each group of settings is activated by the corresponding remote transmitter (1 or 2) when it is used to unlock the doors. When activated, each item begins to adjust when you open the driver's door to enter the vehicle.

REVERSE TILT DOOR MIRRORS

When you shift into Reverse (R), either door mirror can be tilted downward to improve your view as you parallel park. Shifting out of Reverse returns the tilted mirror to its original position.

How It Works

- To tilt the driver's door mirror, push the mirror selector switch to the left (L) position when in Reverse.
- To tilt the passenger's door mirror, push the mirror selector switch to the right (R) position when in Reverse.
- To turn the feature off, push the switch to the middle position.



MULTI-VIEW REAR CAMERA

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the navigation display.
- Yellow parking guide lines also appear to help you judge distance.
- The rearview display turns off when you shift out of Reverse.



Adjusting the View

Turning the Guide Lines On or Off


Press and hold CANCEL for about 3 seconds. If the guide lines are turned off, they remain off until turned on again.



Switching Views

There are three rearview modes: wide, normal, and top down.

- Press ENTER to toggle between views.
- Rotate the Interface Dial to adjust the screen brightness.



ONE-TOUCH TURN SIGNAL

Use this quick and convenient method to signal a lane change.

How It Works

- Lightly push the turn signal lever up or down for a three-blink sequence.
- For a continuous signal, push the lever up or down until it locks into place.



AUTO HEADLIGHTS WITH WIPER INTEGRATION

For your safety and convenience, your vehicle's headlights automatically turn on when you activate the windshield wipers.

How It Works

- Make sure your headlights are in the AUTO position.
- Turn on your windshield wipers. The headlights also turn on.
- When you turn off the windshield wipers, the headlights turn off shortly after.




POWER TAILGATE

Use multiple methods to operate the power tailgate.

Opening the Power Tailgate from Inside the Vehicle

The vehicle must be in Park (P) with all doors unlocked.



- Press and hold the tailgate button until a beep sounds. The tailgate begins to open.
- To close the tailgate, press the button again at any time.

Opening the Power Tailgate Using the Remote Transmitter

The vehicle must be off with the remote in operating range.



In ANYTIME mode: Press and hold the tailgate button for about one second to unlock and open the tailgate.



In WHEN UNLOCKED mode: Press the unlock button twice to unlock all doors and the tailgate. Then press and hold the tailgate button for about one second.

Make sure the power tailgate keyless open mode is set to your preference using the MID. See your Owner's Manual for instructions, or see page 8 for an example of how to change a setting.

VOICE RECOGNITION

To keep your eyes on the road and hands on the wheel, use voice commands for navigation, hands-free calling, audio, climate control, and AcuraLink functions.

Functions by Voice Command

Control five different systems with the steering wheel buttons and the ceiling microphone.

To prevent driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.




Pick-Up button: Answer an incoming call, or go directly to the Phone screen.

Hang-Up button: End a call or decline a call.

Talk button: Give HFL, navigation, AcuraLink, audio, or climate control commands.

Back button: Cancel a command and return to the previous screen.



Voice Command Tips

- When using the Talk button, wait for a beep, then say a command.
- When the Talk button is pressed, all available voice commands are highlighted in blue.
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.
- To hear a list of available commands at any time, press and release the Talk button, then say "Help."
- For a list of full commands by category, say "Display information," followed by "Voice info." See your Navigation Manual for a complete list.

NAVIGATION p. 20



BLUETOOTH® HANDSFREELINK® p. 24



ACURALINK p. 30



AUDIO p. 19



CLIMATE p. 19



Commonly Used Voice Commands

Press and release the Talk button before you say a command.

Locate Points of Interest

Say a command like “Display restaurant” to see restaurant icons appear on the map.




Say a command like "Display gas stations" to see gas station icons appear on the map.




Press and release the Talk button before you say a command.

Get Navigation Route Information

After a destination is entered, say *"How far to the destination?"* to hear the remaining distance.



Say "Display entire route" to see the routing method the system mapped for your destination.




Press and release the Talk button before you say a command.

Make Audio Selections

Say a command like "Radio 97.1 FM" to select that station.




Say a command like "DISC play track 1" to hear that song on a currently inserted CD.



Press and release the Talk button before you say a command.

Adjust the Vehicle's Climate Setting

Say a command like *"Air conditioner on"* to adjust the climate setting.



Say a command like "Fan speed 4" to adjust the fan speed.



Commonly Used Voice Commands (continued)


Press and release the Talk button before you say a command.

General Commands (Accepted on most screens to change displays)



- Display map
- Display destination
- Display audio information
- Display audio
- What time is it?

Find Place Commands (Accepted on Map screen)




- Find nearest:
 - ATM
 - gas station
 - Mexican restaurant
 - post office
 - bank
 - Acura dealer
 - airport
 - hospital

Display Commands (Accepted on Map screen)




- Display (or hide):
 - ATM
 - gas station
 - restaurant
 - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location

Navigation Commands (Accepted on Map screen after a destination is entered)



- How long/far to the destination?
- Display destination
- Display entire route

Help Commands (Accepted on most screens)



- Help (list of available commands for current screen)
- Voice command help (from the INFO screen - list of all available navigation, audio, and climate control commands)

Press and release the Talk button before you say a command.

Audio Commands (Accepted on most screens)




- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM preset 1/2/3/4/5/6
- DISC play
- DISC play track #
- DISC skip forward/back
- iPod/USB/HDD/Pandora play

Climate Control Commands (Accepted on most screens)



- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57-87)
- Temperature max hot/cold

Phone Commands (Accepted on Cellular Phone screen)




- Call history
- Phonebook
- Dial
- Text message
- Redial
- Phone setup

(Accepted on any screen)


- Dial by voice tag
- Dial by number

Traffic Commands* (Accepted on Map screen)



- Display traffic
- Display traffic speeds
- Display traffic icons
- Display traffic incidents/list

Weather Commands* (Accepted on map screen)



- Display weather
- Display weather icons
- Display weather warning icons

*subscription required

NAVIGATION

Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

Entering a Destination Using Voice Commands


Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the Talk button before you say a command.



1. Say "Display destination."
Say "Address."
4. Say the entire street address number. For example, "1-2-3-4."
If necessary, say "OK" to proceed.



2. Say "Street," then say the street name on the next screen. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).
5. If the street address is in more than one city, a list of city names appears. Say the number next to the city you want to select.



3. A list of street names appears. Say the number next to the street you want.
6. The system displays the Calculate route to screen. Say "OK" to set the route.




NOTE: It is recommended that you enter your destination before driving or when the vehicle is stopped.

Using the "Find Nearest" Command



Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Talk button before you say a command.


1. From the map screen, say "Find nearest ATM."
3. Say the number next to the destination you want to select.



2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.
4. The system displays the "Calculate route to" screen. Say "OK" to set the route.



Map Screen Legend





ACURALINK REAL-TIME TRAFFIC™*

Provides continuously updated info, including traffic speed, incidents, and construction in major metro areas.

Press and release the Talk button before you say a command.

Displaying Traffic Information

Say "Display traffic" to view traffic flow and icons.



Heavy traffic

Moderate traffic



Free-flow traffic

Note: Traffic flow and incident icons are only displayed on map scales of 5 miles (8 km) or less.


Traffic Rerouting™

The system can automatically provide detours around traffic or incidents when a destination is set.


1. Say "Display traffic incidents" to view a list of incidents on your route.
3. Say "Avoid."



2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



4. Say "Reroute" to set the new route.



* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)


ACURALINK REAL-TIME WEATHER™*

Provides continuously updated weather conditions, warnings, and forecasts in major metro areas.

Press and release the Talk button before you say a command.

Displaying Weather Icons

Say "Display weather" to view weather icons for each city.



Weather Icons



Note: Weather icons are available on all map scales.

Displaying Weather Information

Say "Display information," then "Weather info" for the following options:

Weather Forecast

Say "Weather forecast" to view a 1-day or 3-day forecast of your current position or city vicinity.




Radar Image Map

Say "Radar map" to view color-coded rain or snow systems.



Weather Warning List

Say "Warning list sorted by distance" to view a list of all U.S. weather warnings by distance.



Weather Warning Map

Say "Warning map" to view color-coded severe weather systems.



* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

BLUETOOTH® HANDSFREELINK®

Make and receive phone calls through your vehicle's audio system. Visit www.acura.com/handsfreelink to check if your phone is Bluetooth-compatible.

To prevent driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.


Using HFL

Pick-Up button: Answer an incoming call, or go directly to the Cellular Phone screen.

Hang-Up button: End a call or decline a call.

Talk button: Give HFL commands.

Back button: Cancel a command and return to the previous screen.



Pairing Your Phone

Use this pairing method if no phone has ever been paired to the system. You can only pair your phone when the vehicle is stopped.

Press and release the Talk button before you say a command.


1. Press the Pick-Up button to access the Cellular Phone screen. A prompt appears. Say "Yes."



2. Make sure your phone is in discovery mode, and say "OK."




3. HFL searches for your phone. Say the number next to the phone when it appears on the list.



If your phone does not appear:

Say "Phone Not Found" and search for HandsFreeLink from your phone. Connect to HFL.




4. HFL gives you a four-digit code. Enter it on your phone when prompted. Say "OK" to complete.



Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

Press and release the Talk button before you say a command.

1. Press the Pick-Up button to access the Cellular Phone screen.




If a prompt appears asking to connect to a phone, say "No."

2. Say "Phone setup."




3. Say "Connection."




4. Say "Add New Phone."



5. Make sure your phone is in discovery mode, and say "OK."




6. HFL searches for your phone. Say the number next to the phone when it appears on the list.




If your phone does not appear:

Say "Phone Not Found" and search for HandsFreeLink from your phone. Connect to HFL.



7. HFL gives you a four-digit code. Enter it on your phone when prompted. Say "OK" to complete.




Making a Call


Dialing a Number

Press and release the Talk button before you say a command.


1. Press the Pick-Up button to access the Cellular Phone screen.




2. Say "Dial."



3. Say the entire phone number.



4. Say "Dial" to begin the call.




Using the Imported Phonebook*

Press and release the Talk button before you say a command.


1. Press the Pick-Up button to access the Cellular Phone screen.




2. Say "Phonebook."



3. Say "Up" or "Down" to find the name you want to call.



4. Say the number next to the entry to begin the call.




* Visit www.acura.com/handsfreelink to check if this feature is available on your phone.


Using Speed Dial and Voice Tags

Press and release the Talk button before you say a command.


1. Press the Pick-Up button to access the Cellular Phone screen.




2. Say the number next to one of the first three entries (for example, "One"). For the complete list of speed dial entries, say "More speed dial."



If an entry has a stored voice tag, say "Dial by voice tag," followed by the voice tag name and "Dial" from any screen.




3. The call is connected and heard through the speakers.



Note: See your Navigation Manual for instructions on storing speed dial entries and voice tags.

Receiving a Call

When you receive an incoming call, you hear a notification and see the following pop-up message:



Press the Pick-Up button to accept the call.



Press the Hang-Up button to end or decline the call.



SMS TEXT MESSAGING

Receive and send text messages from your paired and linked phone using Bluetooth® HandsFreeLink®. Visit www.acura.com/handsfreelink to see if this feature is compatible on your phone. Standard message rates apply. This feature is limited while the vehicle is moving.

Receiving Text Messages

Press and release the Talk button before you say a command.




1. A notification appears on the navigation screen when you receive a text message.
2. Say "Read" to open the message. The message is displayed, and the system reads it aloud.



Replying to Text Messages

Press and release the Talk button before you say a command.


1. With the message open, say "Reply."
2. Say the number next to one of the six available reply messages.
3. Say "Send" to send the message.
4. A notification appears after the message is sent.



Calling the Sender

Press and release the Talk button before you say a command.



1. With the message open, say "Call."
2. HFL begins dialing the number.



Displaying All Messages

Press and release the Talk button before you say a command.

1. Press the Pick-Up button to go to the Cellular Phone menu.
2. Say "Text Message." The 20 most recent text messages from your phone are displayed.
3. Say the number next to the message you want. The message is displayed, and the system reads it aloud.



ACURALINK® MESSAGES


Acura periodically sends you messages on vehicle features, recall and safety information, maintenance reminders, and diagnostic information.

Viewing New Messages


1. When you receive a new message, an envelope icon appears on the map screen.



3. Say the number of the message you want to hear.





2. Say "Messages," and a list of messages appears.



Scheduling a Dealer Appointment


To use this feature, you must register at My Acura (www.myacura.com), and make sure your Bluetooth-compatible phone is paired and correctly set up (see [page 24](#)).

1. Using the Interface Dial, open a maintenance or diagnostic message.
3. The system searches for the next available appointment at your dealer. Select "Confirm Appointment" if you are satisfied with the date.




Note: If you are not satisfied with the available date, use the Call option to call your dealer directly.

2. Select "Schedule Dealer Appt."



4. Select "OK" to set the appointment.



BLUETOOTH® AUDIO

Play audio files from your compatible phone through your vehicle's audio system. Visit www.acura.com/handsfreelink to check if this feature is available on your phone.

Playing Bluetooth Audio Files

1. Make sure your phone is on and paired to Bluetooth® HandsFreeLink® (see [page 24](#)).
4. Press (▶▶) or (◀◀) on the audio control panel or (+) or (-) on the steering wheel to change tracks.

2. Press HDD/AUX until Bluetooth Audio appears.



3. From your phone, open the desired audio player or app and begin playback. Sound is redirected to the audio system.



Notes:

- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional Bluetooth settings on your phone for playback.
- The play/pause function and remote audio controls may not be supported on all phones.

HARD DISC DRIVE (HDD) AUDIO

Record CDs onto your vehicle's hard disc drive. Songs are automatically recorded once a CD is inserted into the disc slot.

Playing HDD Audio Files

- 1. Press HDD/AUX until HDD appears.
- 2. The first song of the last recorded album plays. To change tracks, rotate the interface dial or press the SKIP (⏮) or (⏭) buttons.



iPod® or USB Flash Drive

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Connecting Devices and Playing Audio Files

- 1. Open the front console, and pull out the USB adapter cable.
- 3. Press (⏭) or (⏮) on the audio control panel or (+) or (-) on the steering wheel to change tracks.



Connect the cable to your iPod dock connector or flash drive.

- 2. Press HDD/AUX until iPod or USB appears.

Searching for Music

- 1. From the audio screen, push the interface dial up to select MUSIC SEARCH.
- 3. Select a track and press ENTER to begin playing.



iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

SONG BY VOICE™ (SBV)

Play songs from your iPod and HDD from most screens using simple voice commands.

Playing Audio Files Using Voice Commands


Press and release the Talk button before you say a command.

Using the “Play” Command

Say “iPod search” or “HDD search.”



Say “Play” and one of the options on the Search Mode screen. For example, say “Play Artist XYZ.”




if exact match found

if exact match not found


The system provides voice feedback and lists possible matches.



Say the number next to the selection you want to play. For example, say “Four.”



The system plays the selection and returns to the Search Mode screen.



Press and release the Talk button before you say a command.

Using the “List” Command

Say “iPod search” or “HDD search.”



Say “List” and one of the options on the Search Mode screen. For example, say “List Artist XYZ.”



if exact match found

if exact match not found

A list of tracks from the selected artist displays.



The system provides voice feedback and lists possible matches.




Say the number next to the selection you want to play. For example, say “Four.”



Say the number next to the selection you want to play. For example, say “One.”



The system plays the selection and returns to the Search Mode screen.



PANDORA®

Play and operate Pandora internet radio from your iPhone® through your vehicle's audio system. Standard data rates apply.

Playing Pandora

1. Open the front console, and pull out the USB adapter cable.



Connect the cable to your iPhone dock connector.

2. Open Pandora from your phone. Press HDD/AUX until Pandora appears and streaming begins.



Notes:

- If the Pandora app is not selected on your phone, iPod music is played.
- If you shut down the Pandora app, you must reopen it on your phone to resume play.
- If you cannot operate Pandora through the audio system, it may be streaming through Bluetooth® Audio. Make sure to select Pandora mode on the audio system.

3. From the audio screen, select items such as Station List, Like/Dislike, and Pause/Resume.*




*Menu functions not available on all phones
iPhone is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries.

HOMELINK®


Program your vehicle to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

Training a Button



If you have any problems programming HomeLink, see the owner's manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit www.homelink.com.

My Acura enhances your ownership experience by allowing you to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information.



Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat, as the force of a deploying airbag can seriously injure an infant.

- Use of unleaded premium gasoline of 91 octane or higher is recommended.
- Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emission control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- "TOP TIER Detergent Gasoline" meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines. In most cases, qualifying gasoline retailers will identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. This helps avoid build-up of deposits in your engine and emission control system. Because the level of detergency and harmful metallic additives (such as MMT) in gasoline vary in the market, Acura endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. For more information, visit www.toptiergas.com.
- For more important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit My Acura at www.myacura.com.