



owners.acura.com

2013 Acura ILX Hybrid with Technology Package Advanced Technology Guide ©2012 Honda Motor Co., Ltd. — All Rights Reserved

**MACURA** 

Printed in U.S.A.



# ADVANCED TECHNOLOGY GUIDE

The Advanced Technology Guide is designed to help you get acquainted with your new Acura and provide basic instructions on some of its technology and convenience features. This guide covers the ILX Hybrid with Technology Package.

This guide is not intended to be a substitute for the Owner's Manual. For more detailed information on vehicle controls and operation, please refer to the Owner's or Navigation Mar

operation, please refer to the respective sections in the  Owner's or Navigation Manual.		
ILX Hybrid (without Technology Package) shown on cover	ECON BUTTON p. 10  VOICE	
	RECOGNITION p. 16	
Keyless Access System	Bluetooth® HandsFreeLink®	
Instrument Panel Indicators	SMS Text Messaging	
Multi-Information Display (MID)6	AcuraLink® Messages	
Eco Assist <sup>TM</sup> 10	Bluetooth® Audio	3
One-Touch Turn Signal	Hard Disc Drive (HDD) Audio	4
Auto Headlights with Wiper Integration13	iPod® or USB Flash Drive	5
Multi-View Rear Camera	Song By Voice™	6
HomeLink®	Pandora®	8
Voice Recognition16	My Acura	
Navigation	Safety Reminder	
AcuraLink Real-Time Traffic™	Fuel Recommendation	
AcuraLink Real-Time Weather <sup>TM</sup>		

**BLUETOOTH®** 

HANDSFREELINK® p.26

MULTI-INFORMATION

DISPLAY p. 6

NAVIGATION p.22

# **KEYLESS ACCESS SYSTEM**

Operate certain functions of your vehicle by simply having the remote within operating range.

# Grab either one of the front door handles.

## Locking the Doors



Press the door lock button on either front door handle.



## Opening the Trunk



Press the trunk release button under the spoiler.



## **Engine Start/Stop Button**

#### Accessory Mode

Use audio, power sockets, etc., without turning the engine on.



Press the ENGINE START/STOP button once (without pressing the brake pedal).





#### Starting the Engine



Press and hold the brake pedal, then press the ENGINE START/STOP button.





## Turning the Engine Off



Shift to Park, then press the ENGINE START/STOP button.





## INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and areen indicators are used for general information.



## **Malfunction Indicators**

If an indicator remains on, there may be a problem; see your dealer.



Charging system



VSA<sup>®</sup> (Vehicle Stability Assist)



Low brake fluid



TPMS (blinks)
(Tire Pressure Monitoring System)



Low oil pressure



EPS (electric power steering)



SRS
(Supplemental Restraint System)



IMA system



ABS (Anti-lock Brake System)



Low temperature (stays on)



Keyless Access System



Brake system



Malfunction lamp (check engine light)

# Condition Indicators

Action is needed by driver.



Parking brake on: Release



Seat belt reminder: Fasten seat belt(s)



Door/trunk open indicator: Close door/trunk



Message indicator: See MID



Low tire pressure (stays on): Add air



Low fuel: Refill

## On/Off Indicators



PASSENGER AIRBAG OFF (next to screen)



Headlights on



SIDE AIRBAG off



Turn signals/hazards on



VSA off



Fog lights on



CRUISE MAIN on



Auto Idle Stop on (blinks)



CRUISE CONTROL on



ECON mode on



Immobilizer (flashes): improperly coded key; use correct key



High beams on

## MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.

## Accessing the MID

When you start the engine, the MID shows the last active display from the previous drive cycle.







To toggle between the different displays:

- Press either Info button (▲/▼) for the main displays.
- Press SEL/RESET for the lower displays.







## Customizing Settings Using the MID

Program various vehicle settings using the MID. One example is shown below. See your Owner's Manual for other customizable settings.

#### Programming the Auto Door Unlock Setting

Only the driver's door is preset to unlock when you shift into Park (P). You can change this to a different setting.



Press either Info button (▲/▼) on the steering wheel to toggle to the Customize Settings display, then press SEL/RESET to activate the menu.



1. Select DOOR SETUP.



2. Select AUTO DOOR UNLOCK.



3. Select the option you want.



4. The setting is displayed, and the display returns to the AUTO DOOR UNLOCK menu.



Note: The driver's and front passenger's door can be opened by pulling the inner front door handle, regardless of the setting. Changing the setting to "All Doors" is useful for rear passengers.

## Tire Pressure Monitoring System

Alerts you when one or more of your tires have significantly low pressure. Toggle to the tire pressure monitor display to view pressure readings on the MID.

#### How It Works



If the tire pressure drops significantly below recommended levels:

- The low tire pressure indicator comes on.
- A "CHECK TIRE PRESSURE" message appears on the MID.
- If a "CHECK TPMS SYSTEM" message appears, there may be a problem with the system. See your dealer.







#### What to Do

- 1. Visually inspect the tires for damage.
- 2. Use a tire air pressure gauge (or check the MID) to check which tire(s) have low pressure.



3. Inflate the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.







## ECO ASSISTIM

Provides various ways to monitor your fuel efficiency and driving style.

## **Activating ECON Mode**

Helps you further maximize your fuel efficiency by modifying some vehicle functions.





2. The ECON mode indicator comes on.





3. Check the MID.



Press ECON again to turn the system off.

NOTE: When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system is affected to achieve maximum fuel efficiency.

## Driver Feedback

Indicates instant fuel efficiency. Results are displayed on the MID, where sphere size increases or decreases based on your driving style.



Press either Info button ( $\triangle/\nabla$ ) to toggle to the Fuel Economy Indicator.



Driving Style	Fuel Economy Indicator (on the MID)
Smooth, steady acceleration maximizes fuel efficiency	
Smooth, steady deceleration maximizes fuel efficiency	
Moderate acceleration	

Real-time Fuel Efficiency Coach







#### **ECO Score**

Every time your vehicle is turned off, your lifetime driving score appears on the MID. Depending on your driving style, your lifetime points can increase or decrease.



eco score




Stage 2

Stage 3

## Auto Idle Stop

Shuts the engine off at a stop in order to maximize fuel efficiency. Idle stop duration varies depending on certain conditions, such as climate control operation, IMA battery level, and outside temperature.







While driving, the engine is on.

While at a stop, with the brake pedal pressed, the engine turns off.

When you take your foot off the brake pedal, the engine turns back on.

Note: Auto Idle Stop only functions if you come to a stop with the shift lever in the D or N position.

## Charge/Assist Gauge

Shows the status of the Integrated Motor Assist (IMA) system.

The gauge shows you when the IMA motor is assisting the engine or charging the battery.

Note: The IMA assist may not operate under certain conditions.





## ONE-TOUCH TURN SIGNAL

Use this guick and convenient method to signal a lane change.

#### How It Works

- Lightly push the turn signal lever up or down for a three-blink sequence.
- For a continuous signal, push the lever up or down until it locks into place.



# AUTO HEADLIGHTS WITH WIPER INTEGRATION

For your safety and convenience, your vehicle's headlights automatically turn on when you activate the windshield wipers.

## How It Works

• Make sure your headlights are in the AUTO position.



• Turn on your windshield wipers. The headlights also turn on.



• When you turn off the windshield wipers, the headlights turn off shortly after.







## **MULTI-VIEW REAR CAMERA**

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

#### How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the navigation display.
- Yellow parking guide lines also appear to help you judge distance.
- The rearview display turns off when you shift out of Reverse.



## Adjusting the View

#### Turning the Guide Lines On or Off

Press and hold CANCEL for about 3 seconds. If the guide lines are turned off, they remain off until turned on again.



#### Switching Views

There are three rearview modes: wide, normal, and top down.

- Press ENTER to toggle between views
- Rotate the Interface Dial to adjust the screen brightness.









## **HOMELINK®**

Program your vehicle to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

## Training a Button





Position the remote transmitter you wish to link 1–3 inches from the HomeLink button you want to program.

Press and hold the desired
HomeLink button and the button on
the remote transmitter.

NO

Does the HomeLink indicator (LED) blink at a faster rate after about 10 seconds?

Press and hold the button on the remote and the HomeLink button at the same time. Then, while continuing to hold the HomeLink button, press and release the button on the remote every 2 seconds.

Does the LED blink at a faster rate within 20

on the remote every 2 seconds.

Does the LED blink at a faster rate within 20 seconds?

NO

YES

Press and hold the programmed HomeLink button for about a second.

Does the device (garage door opener) work?

YĚS

Training

complete

Press and hold the HomeLink button again.

NO

HomeLink indicator HomeLink LED flashes for 2 seconds, remains on.

- The remote has a rolling code.

  Press the "learn" button on the remote-controlled device (e.g., garage door opener).
- Within 30 seconds, press and hold the programmed HomeLink button for 2 seconds.
- Press the programmed HomeLink button again; the remote-controlled device should operate.

If you have any problems programming HomeLink, see the owner's manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit www.homelink.com.

YĚS

## **VOICE RECOGNITION**

To keep your eyes on the road and hands on the wheel, use voice commands for navigation, hands-free calling, audio, climate control, and AcuraLink functions.

## **Functions by Voice Command**

Control five different systems with the steering wheel buttons and the ceiling microphone.

To prevent driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.





Pick-Up button: Answer an incoming call, or go directly to the Phone screen.

Hang-Up button: End a call or decline a - call.

Talk button: Give HFL, navigation, AcuraLink, audio, or climate control commands.

Back button: Cancel a command and return to the previous screen.



## **Voice Command Tips**

- When using the Talk button, wait for a beep, then say a command.
- When the Talk button is pressed, all available voice commands are highlighted in blue.
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.
- To hear a list of available commands at any time, press and release the Talk button, then say "Help."
- For a list of full commands by category, say "Display information," followed by "Voice info." See your Navigation Manual for a complete list.



## **Commonly Used Voice Commands**

Press and release the Talk button before you say a command.

#### Locate Points of Interest

Say a command like "Display restaurant" to see restaurant icons appear on the map.



Say a command like "Display gas stations" to see gas station icons appear on the map.



Press and release the Talk button before you say a command.

#### Make Audio Selections

Say a command like "Radio 97.1 FM" to select that station.



Say a command like "DISC play track 1" to hear that song on a currently inserted CD.



Press and release the Talk button before you say a command.

#### **Get Navigation Route Information**

After a destination is entered, say "How far to the destination?" to hear the remaining distance.



Say "Display entire route" to see the routing method the system mapped for your destination.



Press and release the Talk button before you say a command.

#### Adjust the Vehicle's Climate Setting

Say a command like "Air conditioner on" to adjust the climate setting.



Say a command like "Fan speed 4" to adjust the fan speed.

## Commonly Used Voice Commands (continued)

#### Press and release the Talk button before you say a command.

#### General Commands (Accepted on most screens to change displays)



- Display map
- Display audio
- Display destination What time is it?
- Display Information

#### Find Place Commands (Accepted on Map screen)



- Find nearest:
- ATM
- aas station
- Mexican
  - Acura dealer - airport
- restaurant - post office
- hospital

- bank

#### Display Commands (Accepted on Map screen)



- Display (or hide):
- ATM
- gas station
- restaurant
- post office
- Zoom in/out • Go home
- Display current location

• Display north up/

heading up

#### Navigation Commands (Accepted on Map screen after a destination is entered)



- How long/far to the destination?
- Display destination
- Display entire route

#### Help Commands (Accepted on most screens)



- Help (list of available commands for current screen)
- Voice command help (from the INFO) screen - list of all available navigation, audio, and climate control commands)

#### Press and release the Talk button before you say a command.

#### Audio Commands (Accepted on most screens)



- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM preset 1/2/3/4/5/6
- DISC play
- DISC play track #
- DISC skip
- forward/back
- iPod/USB/HDD/ Pandora play

#### Climate Control Commands (Accepted on most screens)



- Air conditioner on/off
- Climate control
- recirculate/fresh
- Fan speed up/down
- Rear defrost on/off Temperature # degrees (# = 57-87)
  - Temperature max hot/cold

#### Phone Commands (Accepted on Cellular Phone screen)



- Call history
- Phonebook
- Dial
- Text message
- Redial
- Phone setup
- (Accepted on any screen)
- Dial by voice tag
- Dial by number

## Traffic Commands\* (Accepted on Map screen)



- Display traffic
- Display traffic speeds
- Display traffic icons
- Display traffic incidents/list

#### Weather Commands\* (Accepted on map screen)



- Display weather
- Display weather icons
- Display weather warning icons

\*subscription required

## NAVIGATION

Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

## **Entering a Destination Using Voice Commands**

Set a destination using a street address. For other destination options, see your Navigation Manual.

#### Press and release the Talk button before you say a command.

 Say "Display destination." Say "Address."



 Say "Street," then say the street name on the next screen. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).



A list of street names appears. Say the number next to the street you want.



4. Say the entire street address number. For example, "1-2-3-4." If necessary, say "OK" to proceed.



 If the street address is in more than one city, a list of city names appears. Say the number next to the city you want to select.



6. The system displays the Calculate route to screen. Say "OK" to set the route.



NOTE: It is recommended that you enter your destination before driving or when the vehicle is stopped.

## Using the "Find Nearest" Command

Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

#### Press and release the Talk button before you say a command.

1. From the map screen, say "Find nearest ATM."



2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.




3. Say the number next to the destination you want to select.



4. The system displays the "Calculate route to" screen. Say "OK" to set the route.







#### ACURALINK REAL-TIME TRAFFICIM\*

Provides continuously updated info, including traffic speed, incidents, and construction in major metro areas.

#### Press and release the Talk button before you say a command.

#### Displaying Traffic Information

Say "Display traffic" to view traffic flow and icons.



au construction, on Traffic Flow data Incident icon

Heavy traffic

Free-flow traffic

Note: Traffic flow and incident icons are only displayed on map scales of 5 miles (8 km) or less.

#### Incident Icons







Congestion

Incident



Weather



Construction

## Traffic Rerouting™

The system can automatically provide detours around traffic or incidents when a destination is set.

1. Say "Display traffic incidents" to view a list of incidents on your route.



2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



3. Say "Avoid."



4. Say "Reroute" to set the new route.



\* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

#### ACURALINK REAL-TIME WEATHER™\*

Provides continuously updated weather conditions, warnings, and forecasts in major metro areas.

#### Press and release the Talk button before you say a command.

#### Displaying Weather Icons

Say "Display weather" to view weather icons for each city.











Fog







Cloudy



#### Displaying Weather Information

Say "Display information," then "Weather info" for the following options:

#### Weather Forecast

Note: Weather icons are

available on all map scales.

Say "Weather forecast" to view q 1-day or 3-day forecast of your current position or city vicinity.



#### Weather Warning List

Say "Warning list sorted by distance" to view a list of all U.S. weather warninas by distance.



#### Radar Image Map

Say "Radar map" to view colorcoded rain or snow systems.



## Weather Warning Map

Say "Warning map" to view colorcoded severe weather systems.



<sup>\*</sup> Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

# **BLUETOOTH®** HANDSFREELINK®

Make and receive phone calls through your vehicle's audio system. Visit www.acura.com/handsfreelink to check if your phone is Bluetooth-compatible.

To prevent driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.

## Using HFL

Pick-Up button: Answer an incoming call, or \_ go directly to the Cellular Phone screen.

Hang-Up button: End a call or decline a call.

Talk button: Give HFL commands.-

Back button: Cancel a command and return to the previous screen.



## **Pairing Your Phone**

Use this pairing method if no phone has ever been paired to the system. You can only pair your phone when the vehicle is stopped.

#### Press and release the Talk button before you say a command.

 Press the Pick-Up button to access the Cellular Phone screen. A prompt appears. Say "Yes."



Make sure your phone is in discovery mode, and say "OK."



3. HFL searches for your phone. Say the number next to the phone when it appears on the list.



If your phone does not appear:

Say "Phone Not Found" and search for HandsFreeLink from your phone. Connect to HFL.



 HFL gives you a four-digit code. Enter it on your phone when prompted. Say "OK" to complete.



Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

#### Press and release the Talk button before you say a command.

 Press the Pick-Up button to access the Cellular Phone screen.



If a prompt appears asking to connect to a phone, say "No."

2. Say "Phone setup."



3. Say "Connection."



4. Say "Add New Phone."



5. Make sure your phone is in discovery mode, and say "OK."



6. HFL searches for your phone. Say the number next to the phone when it appears on the list.



If your phone does not appear:

Say "Phone Not Found" and search for HandsFreeLink from your phone. Connect to HFL.



7. HFL gives you a four-digit code. Enter it on your phone when prompted. Say "OK" to complete.



## Making a Call

#### Dialing a Number

#### Press and release the Talk button before you say a command.

 Press the Pick-Up button to access the Cellular Phone screen.



2. Say "Dial."



3. Say the entire phone number.



4. Say "Dial" to begin the call.



## Using the Imported Phonebook\*

#### Press and release the Talk button before you say a command.

 Press the Pick-Up button to access the Cellular Phone screen.



2. Say "Phonebook."



3. Say "Up" or "Down" to find the name you want to call.



4. Say the number next to the entry to begin the call.



\* Visit www.acura.com/handsfreelink to check if this feature is available on your phone.

#### Using Speed Dial and Voice Tags

#### Press and release the Talk button before you say a command.


 Press the Pick-Up button to access the Cellular Phone screen.




 Say the number next to one of the first three entries (for example, "One"). For the complete list of speed dial entries, say "More speed dial."



If an entry has a stored voice tag, say "Dial by voice tag," followed by the voice tag name and "Dial" from any screen.



3. The call is connected and heard through the speakers.



Note: See your Navigation Manual for instructions on storing speed dial entries and voice tags.

## Receiving a Call

When you receive an incoming call, you hear a notification and see the following pop-up message:



Press the Pick-Up button to accept the call.



Press the Hang-Up button to end or decline the call.



## SMS TEXT MESSAGING

Receive and send text messages from your paired and linked phone using Bluetooth® HandsFreeLink®. Visit www.acura.com/handsfreelink to see if this feature is compatible on your phone. Standard message rates apply. This feature is limited while the vehicle is moving.

## **Receiving Text Messages**

#### Press and release the Talk button before you say a command.

1. A notification appears on the navigation screen when you receive a text message.



2. Say "Read" to open the message. The message is displayed, and the system reads it aloud.



## Replying to Text Messages

#### Press and release the Talk button before you say a command.

1. With the message open, say "Reply."



2. Say the number next to one of the six available reply messages.



3. Say "Send" to send the message.



4. A notification appears after the message is sent.



## Calling the Sender

#### Press and release the Talk button before you say a command.

1. With the message open, say "Call."



2. HFL begins dialing the number.



## Displaying All Messages

#### Press and release the Talk button before you say a command.

1. Press the Pick-Up button to go to the Cellular Phone menu.



 Say "Text Message." The 20 most recent text messages from your phone are displayed.



3. Say the number next to the message you want. The message is displayed, and the system reads it aloud.



30 \_\_\_\_\_\_\_ 31

## ACURALINK® MESSAGES

Acura periodically sends you messages on vehicle features, recall and safety information, maintenance reminders, and diagnostic information.

## Viewing New Messages

 When you receive a new message, an envelope icon appears on the map screen.



2. Say "Messages," and a list of messages appears.



3. Say the number of the message you want to hear.



## Scheduling a Dealer Appointment

To use this feature, you must register at My Acura (www.myacura.com), and make sure your Bluetooth-compatible phone is paired and correctly set up (see page 26).

1. Using the Interface Dial, open a maintenance or diagnostic message.



2. Select "Schedule Dealer Appt."



3. The system searches for the next available appointment at your dealer. Select "Confirm Appointment" if you are satisfied with the date.



Note: If you are not satisfied with the available date, use the Call option to call your dealer directly.

4. Select "OK" to set the appointment.



# BLUETOOTH® AUDIO

Play audio files from your compatible phone through your vehicle's audio system. Visit www.acura.com/handsfreelink to check if this feature is available on your phone.

## Playing Bluetooth Audio Files

- Make sure your phone is on and paired to Bluetooth® HandsFreeLink® (see page 26).
- 2. Press HDD/AUX until Bluetooth Audio appears.



3. From your phone, open the desired audio player or app and begin playback. Sound is redirected to the audio system.



 Press ()) or ()(4) on the audio control panel or (+) or (-) on the steering wheel to change tracks.





#### Notes:

- Make sure the volume on your phone is properly adjusted.
- You may need to enable additional Bluetooth settings on your phone for playback.
- The play/pause function and remote audio controls may not be supported on all phones.

32 — \_\_\_\_\_\_ 33

## HARD DISC DRIVE (HDD) AUDIO

Record CDs onto your vehicle's hard disc drive. Songs are automatically recorded once a CD is inserted into the disc slot.

## Playing HDD Audio Files

1. Press HDD/AUX until HDD appears.



 The first song of the last recorded album plays. To change tracks, rotate the interface dial or press the SKIP (M) or (M) buttons.







## Searching for Music

From the audio screen, push the interface dial up to select MUSIC SEARCH





2. Select one of the categories.



3. Select a track and press ENTER to begin playing.





## iPod® or USB Flash Drive

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

## Connecting Devices and Playing Audio Files

1. Open the front console, and pull out the USB adapter cable.





Connect the cable to your iPod dock connector or flash drive.

2. Press HDD/AUX until iPod or USB appears.



 Press ()) or ()(4) on the audio control panel or (+) or (-) on the steering wheel to change tracks.










 $iPod\ is\ a\ registered\ trademark\ of\ Apple\ Computer,\ Inc.,\ registered\ in\ the\ U.S.\ and\ other\ countries.\ iPod\ not\ included.$ 

34 \_\_\_\_\_\_\_ 35

# SONG BY VOICE™ (SBV)

Play songs from your iPod and HDD from most screens using simple voice commands.

#### Playing Audio Files Using Voice Commands Press and release the Talk button before you say a command. Using the "Play" Command Say "iPod search" or "HDD search." Say "Play" and HDD search mode one of the options on the Search Mode screen. For example, say "Play Artist XYZ." if exact if exact match match found not found The system provides voice 1 Artist M 2 Artist A 3 Artist L 4 Artist V 5 Artist I 6 Artist N feedback and lists possible matches. Say the number lect an artist next to the selection you want to play. For example, say "Four." The system □ HDD HDD search mode plays the selection and returns to the Search Mode screen.



# PANDORA®

Play and operate Pandora internet radio from your iPhone® through your vehicle's audio system. Standard data rates apply.

## **Playing Pandora**

1. Open the front console, and pull out the USB adapter cable.



Connect the cable to your iPhone dock connector.

Open Pandora from your phone.
 Press HDD/AUX until Pandora
 appears and streaming begins.



From the audio screen, select items such as Station List, Like/Dislike, and Pause/Resume.\*



#### Notes:


- If the Pandora app is not selected on your phone, iPod music is played.
- If you shut down the Pandora app, you must reopen it on your phone to resume play.
- If you cannot operate Pandora through the audio system, it may be streaming through *Bluetooth®* Audio. Make sure to select Pandora mode on the audio system.

\*Menu functions not available on all phones iPhone is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries.

# REGISTER AT MYACURA.COM

My Acura enhances your ownership experience by allowing you to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information.





38 — \_\_\_\_\_\_\_ 39

## SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat, as the force of a deploying airbag can seriously injure an infant.

## FUEL RECOMMENDATION

- Use of unleaded premium gasoline of 91 octane or higher is recommended.
- Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emission control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- "TOP TIER Detergent Gasoline" meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines. In most cases, qualifying gasoline retailers will identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. This helps avoid build-up of deposits in your engine and emission control system. Because the level of detergency and harmful metallic additives (such as MMT) in gasoline vary in the market, Acura endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. For more information, visit www.toptiergas.com.
- For more important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit My Acura at www.myacura.com.