

[owners.acura.com](http://owners.acura.com)

2014 Acura ILX Hybrid with Technology Package  
Advanced Technology Guide  
©2013 Honda Motor Co., Ltd. — All Rights Reserved

31TX8B10  
00X31-TX8-B100

Printed in U.S.A.

The word 'ILX' is displayed in a large, stylized, metallic font with a brushed metal texture and a 3D effect, set against a dark background with a subtle reflection.




2014 **ADVANCED TECHNOLOGY GUIDE**

## ADVANCED TECHNOLOGY GUIDE

This Advanced Technology Guide is designed to help you get acquainted with your new Acura ILX Hybrid with Technology Package and provide basic instructions on some of its technology and convenience features.

This guide is not intended to be a substitute for the Owner's Manual. For more detailed information on vehicle controls and operation, please refer to the respective sections in the Owner's or Navigation Manual.

Keyless Access System	.2
Instrument Panel Indicators	.4
Multi-Information Display (MID)	.6
Eco Assist™	.10
One-Touch Turn Signal	.13
Auto Headlights with Wiper Integration	.13
Multi-View Rear Camera	.14
HomeLink®	.15
Voice Recognition	.16
Navigation	.20
Bluetooth® HandsFreeLink®	.24



SMS Text Messaging	.28
AcuraLink® Messages	.30
Bluetooth® Audio	.31
Hard Disc Drive (HDD) Audio	.32
iPod® or USB Flash Drive	.33
Song By Voice™	.34
Pandora®	.36
Acura Owners	.37
Safety Reminder	.37
Fuel Recommendation	.37

# KEYLESS ACCESS SYSTEM

Operate certain functions of your vehicle by simply having the remote transmitter within operating range.

## Unlocking the Doors



Grab either one of the front door handles when the vehicle is off.



## Locking the Doors



Press the door lock button on either front door handle when the vehicle is off.



## Opening the Trunk



Press the trunk release button under the spoiler when all doors are unlocked. The vehicle can be on or off.




## Engine Start/Stop Button

### Accessory or On Mode

Operate audio or other electrical features without turning the engine on.



Press ENGINE START/STOP once without pressing the brake pedal for Accessory mode. Press it again for On mode.



### Starting the Engine



Press and hold the brake pedal, then press ENGINE START/STOP.



### Turning the Vehicle Off




Shift to Park, then press ENGINE START/STOP.



**Note:** If you press ENGINE START/STOP when the vehicle is stopped and the shift lever is not in Park, the vehicle goes into Accessory mode.














# INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information. See your Owner's Manual for more information.




## Malfunction Indicators






If an indicator remains on, there may be a problem; see your dealer.

- |   |  |
|---|--|
|  Charging system                              |  Vehicle Stability Assist® (VSA) system                       |
|  Low brake fluid                              |  Tire Pressure Monitoring System (TPMS) (blinks and stays on) |
|  Low oil pressure                             |  Electric Power Steering (EPS) system                         |
|  Supplemental Restraint System (SRS) system |  IMA Hybrid system  |
|  Anti-lock Brake (ABS) system               |  Low temperature (stays on)                                 |
|  Keyless Access System                      |  Brake system   |
|  Malfunction lamp (check engine light)      |  |












## Condition Indicators

Action is needed by driver.

- |  |   |
|--|---|
|  Parking brake on: Release |  Seat belt reminder: Fasten seat belt(s) |
|--|---|

- |   |  |
|---|--|
|  Door/trunk open indicator: Close door/trunk                     |  Message indicator: See MID |
|  Low tire pressure (stays on): Add air                           |  Low fuel: Refill           |
|  Immobilizer (blinks): Use other vehicle key and see your dealer |  |

## On/Off Indicators

- |  |  |
|--|--|
|  PASSENGER AIRBAG OFF (next to display) |  Exterior lights on         |
|  SIDE AIRBAG OFF                        |  Turn signals/hazards on    |
|  VSA OFF                                |  Fog lights on              |
|  CRUISE MAIN on                         |  High beams on              |
|  CRUISE CONTROL on                      |  Auto Idle Stop on (blinks) |
|  ECON mode on                           |  |

# MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.


## Accessing the MID

When you start the engine, the MID shows the last active display from the previous drive cycle.




To toggle between the different displays:


- Press either Info button (▲/▼) for the main displays.
- Press SEL/RESET for the lower displays.



## Main Displays



## Lower Displays



## Customizing Settings Using the MID


Program various vehicle settings using the MID. One example is shown below. See your Owner's Manual for other customizable settings.

### Programming the Auto Door Unlock Setting

Only the driver's door is preset to unlock when you shift into Park (P). You can change this to a different setting.



Press either Info button (▲/▼) on the steering wheel to toggle to the Customize Settings display, then press SEL/RESET to activate the menu.



1. Select DOOR SETUP.



2. Select AUTO DOOR UNLOCK.



3. Select the option you want.



4. The setting is displayed, and the display returns to the AUTO DOOR UNLOCK menu.



Press either INFO button to exit the menu.

**Note:** The driver's and front passenger's doors can be opened by pulling the inner front door handle, regardless of the setting. Changing the setting to "All Doors" is useful for rear passengers.

## Tire Pressure Monitoring System

Alerts you when one or more of your tires have significantly low pressure.

### How It Works




If the tire pressure drops significantly below recommended levels:

- The low tire pressure indicator comes on.
- A "CHECK TIRE PRESSURE" message appears on the MID.
- If a "CHECK TPMS SYSTEM" message appears, there may be a problem with the system. See your dealer.



### What to Do

1. Visually inspect the tires for damage.
2. Use a tire air pressure gauge to check which tire(s) have low pressure.



3. Inflate the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.





# ECO ASSIST™

Provides various ways to monitor your fuel efficiency and driving style.

## Activating ECON Mode

Helps you further maximize your fuel efficiency by modifying some vehicle functions.

1. Press ECON.



2. The ECON mode indicator comes on.



3. Check the MID.



Press ECON again to turn the system off.

**Note:** When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system are adjusted to maximize fuel efficiency.

## Driver Feedback

Indicates real-time fuel efficiency. Results are displayed on the MID, where sphere size increases or decreases based on your driving style.



Press either Info button (▲/▼) to toggle to the Fuel Economy Indicator.



Real-time Fuel Efficiency Coach	
Driving Style	Fuel Economy Indicator (on the MID)
Smooth, steady acceleration <b>maximizes fuel efficiency</b>	
Smooth, steady deceleration <b>maximizes fuel efficiency</b>	
Moderate acceleration	
Moderate deceleration	
Rapid acceleration <b>lowers fuel efficiency</b>	
Rapid deceleration <b>lowers fuel efficiency</b>	

### ECO Score

Every time your vehicle is turned off, your lifetime driving score appears on the MID. Depending on your driving style, your lifetime points can increase or decrease.



Stage 1




Stage 2



Stage 3

## Auto Idle Stop

Shuts the engine off at a stop in order to maximize fuel efficiency. Idle stop duration varies depending on certain conditions, such as climate control operation, hybrid battery level, and outside temperature.



While driving, the engine is on.

While at a stop, with the brake pedal pressed, the engine turns off.

When you take your foot off the brake pedal, the engine turns back on.

**Note:** Auto Idle Stop only functions if you come to a stop with the shift lever in the D or N position.

## Charge/Assist Gauge

Shows the status of the hybrid system.

The gauge shows you when the hybrid motor is assisting the engine or charging the battery.

**Note:** The hybrid assist may not operate under certain conditions.




## ONE-TOUCH TURN SIGNAL

Use this quick and convenient method to signal a lane change.

### How It Works

- Lightly push the turn signal lever up or down for a three-blink sequence.
- For a continuous signal, push the lever up or down until it locks into place.



## AUTO HEADLIGHTS WITH WIPER INTEGRATION

For your convenience, your vehicle's headlights automatically turn on when the windshield wipers operate.

### How It Works

- Make sure your headlights are in the AUTO position.
- Turn on your windshield wipers. The headlights also turn on.
- When you turn off the windshield wipers, the headlights turn off shortly after.





# MULTI-VIEW REAR CAMERA

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

## How It Works


- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the navigation display.
- Yellow parking guide lines also appear to help you judge distance.
- The rearview display turns off when you shift out of Reverse.



## Adjusting the View

### Turning the Guide Lines On or Off

Press and hold CANCEL for about 3 seconds. If the guide lines are turned off, they remain off until turned on again.



### Switching Views

There are three rearview modes: wide, normal, and top down.


- Press ENTER to toggle between views.
- Rotate the Interface Dial to adjust the screen brightness.



# HOMELINK®

Program your vehicle to operate up to three remote-controlled devices around your home, such as garage doors, lighting, or home security systems.

## Training a Button



If you have any problems programming HomeLink, see the owner's manual included with the device you are trying to program, call HomeLink at (800) 355-3515, or visit [www.homelink.com](http://www.homelink.com).

# VOICE RECOGNITION

To keep your eyes on the road and hands on the wheel, use the Talk button to say voice commands to operate certain vehicle features.

## Functions by Voice Command

Control five different systems with the steering wheel buttons and the ceiling microphone.

To reduce the potential for driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.




**Pick-Up button:** Answer an incoming call, or go directly to the Phone screen.

**Hang-Up button:** End a call or decline a call.

**Talk button:** Give HFL, navigation, AcuraLink, audio, or climate control commands.

**Back button:** Cancel a command and return to the previous screen.



## Voice Command Tips

- When using the Talk button, wait for a beep, then say a command. To bypass the system prompts, simply press the Talk button again to say your command.
- To turn off the system prompts: Press INFO, select Setup, select Other, select Basic Settings, and select OFF for Voice Recognition Tutor.
- When the Talk button is pressed, all available voice commands are highlighted in blue.
- Speak in a clear, natural voice, and reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling, and close the windows.
- To hear a list of available commands at any time, press and release the Talk button, then say "Help." For a full list of commands by category, say "Display information," followed by "Voice info," or see your Navigation Manual.

## NAVIGATION p. 20



## BLUETOOTH® HANDSFREELINK® p. 24



## ACURALINK p. 30



## AUDIO p. 19



## CLIMATE p. 19




## Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.


Press and release the Talk button before you say a command.

### General Commands (Accepted on most screens to change displays)



- Display map
- Display destination
- Display Information
- Display audio
- What time is it?

### Find Place Commands (Accepted on Map screen)




- Find nearest:
  - ATM
  - gas station
  - Mexican restaurant
  - post office
  - bank
  - Acura dealer
  - airport
  - hospital

### Display Commands (Accepted on Map screen)




- Display (or hide):
  - ATM
  - gas station
  - restaurant
  - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location

### Navigation Commands (Accepted on Map screen after a destination is entered)



- How long/far to the destination?
- Display destination
- Display entire route

### Help Commands (Accepted on most screens)



- Help (list of available commands for current screen)
- Voice command help (from the INFO screen - list of all available navigation, audio, and climate control commands)

Press and release the Talk button before you say a command.

### Audio Commands (Accepted on most screens)



- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- XM channel #
- XM preset 1/2/3/4/5/6
- DISC play
- DISC play track #
- DISC skip forward/back
- iPod/USB/HDD/Pandora play

### Climate Control Commands (Accepted on most screens)




- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57-87)
- Temperature max hot/cold

### Phone Commands (Accepted on Cellular Phone screen)



- Call history
  - Phonebook
  - Dial
  - Text message
  - Redial
  - Phone setup
- (Accepted on any screen)
- Dial by voice tag
  - Dial by number

### Traffic Commands\* (Accepted on Map screen)



- Display traffic
- Display traffic speeds
- Display traffic icons
- Display traffic incidents/list

### Weather Commands\* (Accepted on map screen)



- Display weather
- Display weather icons
- Display weather warning icons

\*subscription required

# NAVIGATION

Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

## Entering a Destination Using Voice Commands


Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the Talk button before you say a command.


1. Say "Display destination."  
Say "Address."
4. Say the entire street address number. For example, "1-2-3-4."  
If necessary, say "OK" to proceed.



2. Say "Street," then say the street name on the next screen. Do not include the direction designators (N, S, E, W) or type (St., Ave., Blvd., etc.).
5. If the street address is in more than one city, a list of city names appears. Say the number next to the city you want to select.



3. A list of street names appears. Say the number next to the street you want.
6. The system displays the Calculate route to screen. Say "OK" to set the route.



**Note:** It is recommended that you enter your destination before driving or when the vehicle is stopped.

## Using the "Find Nearest" Command



Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Talk button before you say a command.

1. From the map screen, say "Find nearest ATM."
3. Say the number next to the destination you want to select.



2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.
4. The system displays the "Calculate route to" screen. Say "OK" to set the route.



## Map Screen Legend



Direction of destination

Distance to go

Time to go

Calculated route

Current vehicle location






## AcuraLink Real-Time Traffic™\*

Provides continuously updated information, including traffic speed, incidents, and construction in major metro areas.

Press and release the Talk button before you say a command.

### Displaying Traffic Information

Say "Display traffic" to view traffic flow and icons.



Heavy traffic

Moderate traffic

Free-flow traffic

**Note:** Traffic flow and incident icons are only displayed on map scales of 5 miles (8 km) or less.

### Incident Icons



Incident



Road closed



Congestion



Weather




Construction


### Traffic Rerouting™

When a destination is already set, you can create a detour to avoid traffic incidents or congestion.


1. Say "Display traffic list" to view a list of incidents on your route.




3. Say "Avoid."



2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



4. Say "Reroute" to set the new route.



\* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)


## AcuraLink Real-Time Weather™\*

Provides continuously updated weather conditions, warnings, and forecasts in major metro areas.

Press and release the Talk button before you say a command.

### Displaying Weather Icons

Say "Display weather" to view weather icons for each city.



### Weather Icons



Clear



Fog



Partly Cloudy



Rain



Cloudy



Snow

**Note:** Weather icons are available on all map scales.

### Displaying Weather Information

Say "Display information," then "Weather info" for the following options:

#### Weather Forecast

Say "Weather forecast" to view a 1-day or 3-day forecast of your current position or city vicinity.




#### Radar Image Map

Say "Radar map" to view color-coded rain or snow systems.



#### Weather Warning List

Say "Warning list sorted by distance" to view a list of all U.S. weather warnings by distance.



#### Weather Warning Map

Say "Warning map" to view color-coded severe weather systems.



\* Subscription-based service through Sirius XM Radio® (free 90-day trial upon vehicle purchase)

# BLUETOOTH® HANDSFREELINK®

Make and receive phone calls through your vehicle's audio system. Visit [www.acura.com/handsfreelink](http://www.acura.com/handsfreelink) to check this feature is compatible with your phone.

To reduce the potential for driver distraction, certain manual functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.


## Using HFL

**Pick-Up button:** Answer an incoming call, or go directly to the Cellular Phone screen.

**Hang-Up button:** End a call or decline a call.

**Talk button:** Give HFL commands.

**Back button:** Cancel a command and return to the previous screen.



## Pairing Your Phone

Use this pairing method if no phone has ever been paired to the system. You can pair your phone only when the vehicle is stopped.

Press and release the Talk button before you say a command.


1. Press the Pick-Up button to go to the Cellular Phone screen. A prompt appears. Say "Yes."



2. Make sure your phone is in discovery mode, and say "OK."



3. HFL searches for your phone. Say the number next to the phone when it appears on the list.



*If your phone does not appear:*  
Say "Phone Not Found" and search for HandsFreeLink from your phone. Connect to HFL.


4. HFL gives you a four-digit code. Enter it on your phone when prompted. Say "OK" to complete.



Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

Press and release the Talk button before you say a command.

1. Press the Pick-Up button to go to the Cellular Phone screen.




If a prompt appears asking to connect to a phone, say "No."

2. Say "Phone setup."



3. Say "Connection."




4. Say "Add New Phone."



5. Make sure your phone is in discovery mode, and say "OK."




6. HFL searches for your phone. Say the number next to the phone when it appears on the list.



*If your phone does not appear:*  
Say "Phone Not Found" and search for HandsFreeLink from your phone. Connect to HFL.

7. HFL gives you a four-digit code. Enter it on your phone when prompted. Say "OK" to complete.





## Making a Call

### Dialing a Number\*

Press and release the Talk button before you say a command.

1. Press the Pick-Up button to go to the Cellular Phone screen.




2. Say "Dial."



3. Say the entire phone number.




4. Say "Dial" to begin the call.



### Using the Imported Phonebook\*

Press and release the Talk button before you say a command.


1. Press the Pick-Up button to go to the Cellular Phone screen.




2. Say "Phonebook."



3. Say "Up" or "Down" to find the name you want to call.



4. Say the number next to the entry to begin the call.




\*Manual operation is limited while the vehicle is moving. Voice commands are always available.

### Using Speed Dial and Voice Tags

Press and release the Talk button before you say a command.


1. Press the Pick-Up button to go to the Cellular Phone screen.




2. Say the number next to one of the first three entries (for example, "One"). For the complete list of speed dial entries, say "More speed dial."



If an entry has a stored voice tag, say "Dial by voice tag," followed by the voice tag name and "Dial" from any screen.




3. The call is connected and heard through the speakers.




**Note:** See your Navigation Manual for instructions on storing speed dial entries and voice tags.

## Receiving a Call


When you receive an incoming call, you hear a notification and see the following pop-up message:



Press the Pick-Up button to accept the call.



Press the Hang-Up button to end or decline the call.





# SMS TEXT MESSAGING

Receive and send text messages from your paired and linked phone using Bluetooth® HandsFreeLink®. Visit [www.acura.com/handsfreelink](http://www.acura.com/handsfreelink) to check if this feature is compatible with your phone. Standard message rates apply. This feature is limited while the vehicle is moving.

## Receiving Text Messages

Press and release the Talk button before you say a command.



1. A notification appears on the navigation screen when you receive a text message.
2. Say "Read" to open the message. The message is displayed, and the system reads it aloud.



## Replying to Text Messages

Press and release the Talk button before you say a command.

1. With the message open, say "Reply."
2. Say the number next to one of the six available reply messages.
3. Say "Send" to send the message.
4. A notification appears after the message is sent.



## Calling the Sender

Press and release the Talk button before you say a command.



1. With the message open, say "Call."
2. HFL begins dialing the number.



## Displaying All Messages

Press and release the Talk button before you say a command.

1. Press the Pick-Up button to go to the Cellular Phone menu.
2. Say "Text Message." The 20 most recent text messages from your phone are displayed.
3. Say the number next to the message you want. The message is displayed, and the system reads it aloud.




## ACURALINK® MESSAGES

Provides a direct communication link between Acura and your vehicle to send you important messages. Register at [owners.acura.com](http://owners.acura.com) for more information.

### Types of Messages

There are six kinds of messages you can receive.



#### Feature Guide

Daily messages on features for the first 90 days of ownership.

#### Quick Tips

Additional or updated vehicle information.

#### Scheduled Dealer Appointments

Reschedule or cancel a dealer appointment. See your Owner's Manual for more information.

#### Diagnostic Info

Gives further information when a warning indicator or MID message appears.

#### Maintenance Minder

Gives information about what service items are due.

#### Recalls/Campaigns


Reminds you about recalls and safety information.

### Viewing New Messages

1. When you receive a new message, an envelope icon appears on the map screen.




2. From the map screen, press ENTER and select New Messages.




To view all messages by category, press INFO and select AcuraLink Messages.

3. Select the message you want to hear.



Some messages allow you to call or locate a dealer for service or more information.



## BLUETOOTH® AUDIO

Play audio files from your compatible phone through your vehicle's audio system. Visit [www.acura.com/handsfreelink](http://www.acura.com/handsfreelink) to check if this feature is compatible with your phone.

### Playing Bluetooth Audio

1. Make sure your phone is on and paired to Bluetooth® HandsFreeLink® (see [page 24](#)).
2. Press HDD/AUX until Bluetooth Audio appears.
4. Press (⏮) (⏭) or (+) (-) to change tracks.



3. From your phone, open the desired audio player or app and begin playback. Sound is redirected to the audio system.

Make sure the volume on your phone is properly adjusted.

#### Notes:

- You may need to enable additional Bluetooth settings on your phone for playback.
- Remote audio controls and the play/pause function may not be supported on all phones.
- Operate your phone only when your vehicle is stopped.

## HARD DISC DRIVE (HDD) AUDIO


Record CDs onto your vehicle's hard disc drive. Songs are automatically recorded once a CD is inserted into the disc slot.

### Playing HDD Audio

1. Press HDD/AUX until HDD appears.




2. The first song of the last recorded album plays. Press (⏮) (⏭) or (+) (-) to change tracks.




### Searching for Music



1. From the audio screen, push the interface dial up to select MUSIC SEARCH.



3. Select a track, and press ENTER to begin playing.



2. Select one of the categories.



## iPod® or USB Flash Drive

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

### Connecting Devices and Playing Audio

1. Open the front console, and pull out the USB adapter cable.



3. Press (⏮) (⏭) or (+) (-) to change tracks.



Connect the cable to your iPod dock connector or flash drive.

2. Press HDD/AUX until iPod or USB appears.



**Note:** Connect your device only when your vehicle is stopped.

*iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.*

Play songs from your iPod and HDD from most screens using simple voice commands.

Playing Audio Files Using Voice Commands

Press and release the Talk button before you say a command.

Using the “Play” Command

Say “iPod search” or “HDD search.”



Say “Play” and one of the options on the Search Mode screen. For example, say “Play Artist XYZ.”



if exact match found

if exact match not found

The system provides voice feedback and lists possible matches.



Say the number next to the selection you want to play. For example, say “Four.”



The system plays the selection and returns to the Search Mode screen.




Press and release the Talk button before you say a command.

Using the “List” Command

Say “iPod search” or “HDD search.”



Say “List” and one of the options on the Search Mode screen. For example, say “List Artist XYZ.”




if exact match found

if exact match not found


A list of tracks from the selected artist displays.



The system provides voice feedback and lists possible matches.




Say the number next to the selection you want to play. For example, say “Four.”



Say the number next to the selection you want to play. For example, say “One.”



The system plays the selection and returns to the Search Mode screen.





## PANDORA®

Play and operate Pandora from your iPhone® through your vehicle's audio system. Visit [www.acura.com/handsfreelink](http://www.acura.com/handsfreelink) to check if this feature is compatible with your phone. Standard data rates apply.

### Playing Pandora

1. Open the front console, and pull out the USB adapter cable.



Connect the cable to your iPhone dock connector.

2. Open Pandora from your phone. Press HDD/AUX until Pandora appears and streaming begins.




#### Notes:

- If the Pandora app is not selected on your phone, iPod music is played.
- A pop-up may appear on your phone requesting you to allow access for Pandora to be launched.
- If you shut down the Pandora app, you must reopen it on your phone to resume play.
- If you cannot operate Pandora through the audio system, it may be streaming through Bluetooth® Audio. Make sure to select Pandora mode on the audio system. If Pandora still does not operate, you may have to reconnect the cable.
- Connect your phone only when your vehicle is stopped.

*\*Menu functions not available on all phones*


*iPhone is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries.*

3. From the audio screen, select items such as Station List, Like/Dislike, and Pause/Resume.\*



## ACURA OWNERS

Visit [owners.acura.com](http://owners.acura.com) and register to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information.



## SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat, as the force of a deploying airbag can seriously injure an infant.

## FUEL RECOMMENDATION

Use of unleaded premium gasoline of 91 octane or higher is recommended.

- Acura recommends TOP TIER Detergent Gasoline where available.
- Do NOT use gasoline containing more than 15% ethanol.
- Do NOT use gasoline containing methanol.
- Do NOT use gasoline containing MMT.
- See your Owner's Manual for more information.

Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emission control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under your new vehicle warranty.

TOP TIER Detergent Gasoline (recommended) never contains MMT and has detergent additives to keep your engine clean. For further information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit [owners.acura.com](http://owners.acura.com).