

This section explains why it is important to keep your vehicle well maintained and how to follow basic maintenance safety precautions.

This section also includes instructions on how to read the maintenance messages, a maintenance record, and instructions for simple maintenance tasks you may want to take care of yourself.

If you have the skills and tools to perform more complex maintenance tasks on your vehicle, you may want to purchase the service manual. See page 281 for information on how to obtain a copy, or see your dealer.

- Maintenance Safety 192
- Maintenance Minder..... 193
- Maintenance Record 200
- Fluid Locations..... 202
- Adding Engine Oil 204
 - Recommended Engine Oil..... 204
 - Synthetic Oil..... 205
 - Engine Oil Additives 205
- Changing the Oil and Filter..... 206
- Windshield Washers 208
- Engine Coolant..... 209
 - Adding Engine Coolant..... 209
- Transmission Fluid..... 211
 - Automatic
 - Transmission..... 211
 - Manual
 - Transmission..... 214
- Brake and Clutch Fluid..... 215
 - Brake Fluid..... 216
 - Clutch Fluid..... 216
- Power Steering Fluid..... 216
- Timing Belt..... 217
- Lights 218
- Seat Belts..... 224
- Floor Mats 224
- Wiper Blades 225

- Tires 227
 - Inflation Guidelines 227
 - Recommended Tire
 - Pressures 228
 - Tire Inspection 229
 - Tire Maintenance 229
 - Tire Rotation 230
 - Replacing Tires 231
 - Wheels and Tires..... 231
 - Winter Driving 232
 - Snow Tires..... 232
 - Tire Chains..... 232
- Checking the Battery 234
- Vehicle Storage 235