

A

Accessories and Modifications	163
Accessories.....	163
Additional Safety Precautions..	164
Modifications	164
ACCESSORY (Ignition Key Position)	84
Accessory Power Socket	104
Additives, Engine Oil.....	202
Airbag (SRS)	10, 49
Air Cleaner Element.....	217
Air Conditioning System.....	110
Maintenance.....	226
Usage	110
Air Outlets (Vents).....	112
Air Pressure, Tires	230
High Speed Driving.....	231
Normal Driving.....	231
Alcohol in Gasoline.....	292
Antifreeze	205
Anti-lock Brakes (ABS)	
Indicator.....	65, 183
Operation.....	181
Anti-theft, Audio System.....	149

Anti-theft Steering Column

Lock.....	83
Appearance Care	249
Audio System	118, 130
Automatic Seat Belt Tensioners....	47
Automatic Speed Control.....	151
Automatic Transmission.....	174
Capacity, Fluid	288
Checking Fluid Level.....	212
Shifting.....	175
Shift Lever Position Indicator ..	174
Shift Lever Positions	175
Shift Lock Release.....	178

B

Battery

Charging System	
Indicator.....	65, 272
Jump Starting	266
Maintenance.....	222
Specifications	289
Before Driving	155
Belts, Seat	8, 46
Beverage Holder	102
Body Repairs	256

Brakes

Anti-lock System (ABS).....	181
Break-in, New Linings	156
Bulb Replacement	242
Fluid	214
Parking.....	100
System Indicator.....	65, 275
Wear Indicators	180
Braking System.....	180
Break-in, New Car	156
Brightness Control, Instruments..	74
Brights, Headlights	73
Bulb Replacement	
Back-up Lights	243
Brake Lights.....	242
Ceiling Light.....	246
Front Parking Lights.....	240
Front Side Marker Lights.....	240
Headlights	239
High-mount Brake Light	243
License Plate Lights.....	244
Rear Side Marker Lights.....	242
Specifications	289
Spotlights.....	247
Trunk Light	245

CONTINUED

Index

Bulb Replacement	
Turn Signal Lights.....	240
Bulbs, Halogen.....	239

C

Capacities Chart.....	288
Carbon Monoxide Hazard.....	55
Carrying Cargo.....	165
Cassette Player	
Care.....	148
Operation.....	124, 145
CAUTION, Explanation of.....	ii
CD Changer.....	127, 141
CD Player.....	127, 139
Ceiling Light.....	105
Certification Label.....	286
Chains.....	236
Changing a Flat Tire.....	259
Changing Engine Coolant.....	207
Changing Oil	
How to.....	203
When to.....	192
Charging System Indicator	65, 272
Checklist, Before Driving.....	170
Child Safety.....	22

Child Seats	
LATCH Anchorage System	44
Lower Anchors	44
Tether Anchorage Points	42
Childproof Door Locks	89
Cleaner Element, Air.....	217
Cleaning	
Exterior.....	250
Interior.....	252
Seat Belts.....	253
Vinyl.....	253
Windows.....	254
Clock, Setting the.....	123, 135
Clutch Fluid.....	215
CO in the Exhaust.....	294
Coat Hook.....	105
Cold Weather, Starting in.....	171
Compact Spare.....	258
Consumer Information*.....	300
Controls, Instruments and.....	59
Coolant	
Adding.....	205
Checking.....	161
Proper Solution	205
Replacing.....	207
Temperature Gauge.....	71

Corrosion Protection.....	255
Crankcase Emissions Control	
System.....	294
Cruise Control Operation.....	151
Customer Relations Office.....	300

D

DANGER, Explanation of.....	ii
Dashboard.....	2, 60
Daytime Running Lights.....	74
Defects, Reporting Safety.....	302
Defog and Defrost.....	115
Defogger, Rear Window.....	78
Defrosting the Windows.....	115
Dimensions.....	288
Dimming the Headlights.....	73
Dipstick	
Automatic Transmission.....	212
Engine Oil.....	160
Directional Signals.....	75
Disc Brake Wear Indicators.....	180
Disposal of Used Oil.....	204
Doors	
Locking and Unlocking.....	84
Power Door Locks.....	85

DOT Tire Quality Grading.....	290
Downshifting, 5-speed Manual Transmission.....	172
Drive Belts.....	229
Driver and Passenger Safety.....	5
Driving.....	169
Economy.....	162
In Bad Weather.....	184
In Foreign Countries.....	293
Dust and Pollen Filter.....	227

E

Economy, Fuel.....	162
Emergencies on the Road.....	257
Battery, Jump Starting.....	266
Brake System Indicator.....	275
Changing a Flat Tire.....	259
Charging System Indicator.....	272
Checking the Fuses.....	278
Low Oil Pressure Indicator.....	271
Malfunction Indicator Lamp.....	273
Manually Closing Moonroof.....	276
Overheated Engine.....	268
Emergency Brake.....	100
Emergency Flashers.....	78

Emergency Towing.....	282
Emergency Trunk Opener.....	90
Emissions Controls.....	294
Emissions Testing, State.....	297
Engine	
Coolant Temperature Gauge.....	71
Drive Belts.....	229
Engine Speed Limiter.....	173, 177
Malfunction Indicator Lamp.....	66, 273
Oil Pressure Indicator.....	65, 271
Oil, What Kind to Use.....	201
Overheating.....	268
Specifications.....	288
Starting.....	171
Ethanol in Gasoline.....	292
Evaporative Emissions Controls..	294
Exhaust Fumes.....	55
Expectant Mothers, Use of Seat Belts by.....	20
Exterior, Cleaning the.....	250

F

Fabric, Cleaning.....	253
Fan, Interior.....	110

Features, Comfort and Convenience.....	109
Filling the Fuel Tank.....	157
Filters	
Air Cleaner.....	217
Dust and Pollen.....	227
Oil.....	203
5-speed Manual Transmission	
Checking Fluid Level.....	213
Shifting the.....	172
Flashers, Hazard Warning.....	78
Flat Tire, Changing a.....	259
Fluids	
Automatic Transmission.....	212
Brake.....	214
Clutch.....	215
Manual Transmission.....	213
Power Steering.....	216
Windshield Washer.....	211
FM Stereo Radio	
Reception.....	137
Folding Rear Seat.....	94
Foreign Countries, Driving in.....	293
Four-way Flashers.....	78

CONTINUED

Index

Front Airbags.....	10, 49
Fuel.....	156
Fill Door and Cap.....	157
Gauge.....	70
Octane Requirement.....	156
Oxygenated.....	292
Reserve Indicator.....	66
Tank, Filling the.....	157
Fuses, Checking the.....	278

G

Gas Mileage, Improving.....	162
Gasohol.....	292
Gasoline.....	156
Fuel Reserve Indicator.....	66
Gauge.....	70
Octane Requirement.....	156
Tank, Filling the.....	157
Gas Station Procedures.....	157
Gauges	
Engine Coolant Temperature	71
Fuel.....	70
Speedometer.....	69
Tachometer.....	69

Gearshift Lever Positions	
Automatic Transmission.....	175
5-speed Manual	
Transmission.....	172
Glass Cleaning.....	254
Glove Box.....	101

H

Halogen Headlight Bulbs.....	239
Hazard Warning Flashers.....	78
Headlights	
Aiming.....	239
Daytime Running Lights.....	74
High Beam Indicator.....	66
Reminder Beeper.....	73
Replacing Halogen Bulbs.....	239
Turning on.....	73
Head Restraints.....	92
Heating and Cooling.....	110
High Altitude, Starting at.....	171
High-Low Beam Switch.....	73
High-mount Brake Light.....	243
Hood Latch.....	218
Hood, Opening the.....	158
Horn.....	72

Hydraulic Clutch.....	215
Hydroplaning.....	185

I

Identification Number, Vehicle....	286
Ignition	
Keys.....	80
Switch.....	83
Timing Control System.....	295
Important Safety Precautions.....	6
Indicators, Instrument Panel.....	62
Infant Restraint.....	31
Infant Seats	
LATCH Anchorage System.....	44
Lower Anchors.....	44
Tether Anchorage Points.....	42
Inflation, Proper Tire.....	230
High Speed Driving.....	231
Normal Driving.....	231
Inside Mirror.....	99
Inspection, Tire.....	232
Instrument Panel.....	2, 60
Instrument Panel Brightness.....	74
Interior Cleaning.....	252
Interior Lights.....	105

Introduction..... **i**

J

Jacking up the Car..... **260**
 Jack, Tire **259**
 Jump Starting **266**

K

Keys..... **80**

L

Label, Certification..... **286**
 Lane Change, Signaling..... **75**
 Lap/Shoulder Belts..... **16, 46**
 LATCH Anchorage System..... **44**
 Lights
 Bulb Replacement **239**
 Indicator..... **62**
 Parking..... **73**
 Turn Signal..... **75**
 Load Limit **166**
 LOCK (Ignition Key Position) **83**

Locks
 Anti-theft Steering Column **83**
 Fuel Fill Door **157**
 Power Door **85**
 Trunk **89**
 Low Coolant Level..... **161**
 Low Fuel Indicator **66**
 Lower Anchors..... **44**
 Lower Gear, Downshifting to a... **173**
 Low Oil Pressure Indicator ... **65, 271**
 Lubricant Specifications Chart ... **288**
 Luggage **165**

M

Maintenance..... **187**
 Owner Maintenance Checks... **199**
 Record..... **197-198**
 Required Indicator..... **67**
 Safety..... **188**
 Schedule **190-196**
 Malfunction Indicator Lamp .. **66, 273**
 Manual Transmission..... **172**
 Manual Transmission Fluid **213**
 Meters, Gauges..... **69**
 Methanol in Gasoline **292**

Mirrors, Adjusting..... **99**
 Moonroof **98**
 Closing Manually..... **276**
 Operation..... **98**

N

Neutral Gear Position..... **176**
 New Car Break-in **156**
 Normal Shift Speeds..... **173**
 NOTICE, Explanation of..... **i**
 Numbers, Identification..... **286**

O

Octane Requirement, Gasoline... **156**
 Odometer..... **69**
 Odometer, Trip **70**
 Oil
 Change, How to **203**
 Change, When to **192**
 Checking Engine **160**
 Pressure Indicator **65, 271**
 Selecting Proper Viscosity
 Chart **202**

CONTINUED

Index

ON (Ignition Key Position)	84
Onboard Refueling Vapor Recovery	294
Operation in Foreign Countries...	293
Outside Mirrors	99
Overheating, Engine	268
Owner Maintenance Checks.....	199
Oxygenated Fuels.....	292

P

Paint Touch-up.....	251
Panel Brightness Control	74
Park Gear Position.....	175
Parking.....	179
Parking Brake	100
Parking Brake and Brake System Indicator.....	65
Parking Lights.....	73
Parking Over Things that Burn...	296
PGM-FI System.....	295
Polishing and Waxing	251
Pre-Drive Safety Checklist	12
Pregnancy, Using Seat Belts.....	20
Protecting Adults.....	13
Additional Safety Precautions....	20

Advice for Pregnant Women.....	20
Protecting Children.....	22
Protecting Infants.....	31
Protecting Larger Children.....	38
Protecting Small Children	35
Using Child Seats with Tethers.....	42
Using LATCH	44

R

Radiator Overheating.....	268
Radio/CD/Cassette Sound System.....	118, 130
Readiness Codes.....	274, 297
Rear Lights, Bulb Replacement.....	242, 243
Rear Seat, Folding	94
Rear View Mirror.....	99
Rear Window Defogger	78
Reclining the Seat Backs	91
Recommended Shift Speeds	173
Reminder Lights	62
Remote Transmitter.....	86
Replacement Information Air Cleaner Element.....	227

Dust and Pollen Filter	227
Engine Coolant.....	207
Engine Oil and Filter.....	203
Fuses	278
Light Bulbs	239
Schedule	190
Spark Plugs.....	219
Timing Belt.....	229
Tires	234
Wiper Blades	224
Replacing Seat Belts After a Crash.....	48
Reserve Tank, Engine Coolant.....	161, 205
Restraint, Child	22
Reverse Gear Position.....	176
Rotation, Tire	233

S

Safety Belts.....	8, 46
Safety Defects, Reporting*	302
Safety Features	7
Airbags.....	10
Door Locks.....	11
Head Restraints	11

- Seat Belts 8
 Seats and Seat-Backs..... 11
 Safety Labels, Location of 56
 Safety Messages ii
 Seat Belts 8, 46
 Additional Information..... 46
 Automatic Seat Belt
 Tensioners..... 47
 Cleaning..... 253
 Lap/Shoulder Belt..... 16, 46
 Maintenance..... 48
 Reminder Light and Beeper..... 64
 System Components..... 46
 Use During Pregnancy..... 20
 Wearing a Lap/Shoulder Belt.... 16
 Seats, Adjusting the..... 91
 Serial Number 286
 Service Intervals 190
 Service Manual* 303
 Service Station Procedures 157
 Setting the Clock 123, 135
 Shift Lever Position Indicator 174
 Shift Lock Release..... 178
 Side Airbags 10, 51
 Cutoff Indicator 53, 64
 Side Marker Lights, Bulb
 Replacement..... 240, 242
 Signaling Turns..... 75
 Snow Tires..... 235
 Solvent-type Cleaners..... 250
 Sound System..... 118, 130
 Spare Tire
 Inflating..... 258
 Specifications 289
 Spark Plugs, Replacing 219
 Specifications Charts..... 289
 Speed Control..... 151
 Speedometer 69
 Spotlights 106
 SRS, Additional Information..... 49
 Additional Safety Precautions.... 54
 Airbag Service..... 54
 How the Side Airbag Cutoff
 Indicator Light Works 53
 How the SRS Indicator
 Works..... 52
 How Your Front Airbags
 Work..... 49
 How Your Side Airbags Work.... 51
 SRS Components 49
 SRS Indicator..... 52, 64
 START (Ignition Key Position) 84
 State Emissions Testing 297
 Starting the Engine..... 171
 In Cold Weather at High
 Altitude 171
 With a Dead Battery 266
 Steam Coming from Engine..... 268
 Steering Wheel
 Adjustment 79
 Anti-theft Column Lock 83
 Stereo Sound System 118, 130
 Storing Your Car..... 248
 Supplemental Restraint
 System..... 10, 49
 Servicing 54
 SRS Indicator..... 52, 64
 System Components..... 49
 Synthetic Oil..... 202
- T**
- Tachometer 69
 Taillights, Changing
 Bulbs 242, 243

CONTINUED

Index

Taking Care of the Unexpected .. 257
Tape Player 124, 145
Technical Descriptions
 DOT Tire Quality Grading..... 290
 Emissions Control Systems..... 294
 Oxygenated Fuels..... 292
 Three Way Catalytic
 Converter..... 296
Temperature Gauge 71
Tether Anchorage Points 42
Theft Protection..... 149
Three Way Catalytic Converter... 296
Time, Setting the 123, 135
Timing Belt..... 229
Tire Chains 236
Tire, How to Change a Flat 259
Tires 230
 Air Pressure 230
 Checking Wear 232
 Compact Spare 258
 DOT Tire Quality Grading 290
 Inflation..... 230
 Inspection 232
 Maintenance..... 232
 Replacing 234
 Rotating..... 233

 Snow 235
 Specifications 289
 Tire Chains..... 236
Tools, Tire Changing 259
Towing
 A Trailer..... 185
 Emergency Towing..... 282
Traction Devices..... 236
Transmission
 Checking Fluid Level,
 Automatic 212
 Checking Fluid Level,
 Manual 213
 Fluid Selection 212, 213
 Identification Number..... 287
 Shifting the Automatic..... 175
 Shifting the Manual..... 172
Treadwear 290
Trip Meter 70
Trunk..... 89
 Opening..... 89
 Open Monitor Light 66
Turn Signals 75

U

Underside, Cleaning..... 255
Unexpected, Taking Care
 of the 257
Uniform Tire Quality Grading 290
Unleaded Gasoline..... 156
Upholstery Cleaning..... 252
Used Oil, How to Dispose of 204

V

Vanity Mirror 104
Vehicle Capacity Load 166
Vehicle Dimensions..... 288
Vehicle Identification Number.... 286
Vehicle Storage 248
Ventilation 113
VIN 286
Vinyl Cleaning..... 253
Viscosity, Oil..... 202

W

WARNING, Explanation of ii
Warning Labels, Location of 56

Warranty Coverages*	301	* : U.S. and Canada only
Washer, Windshield		
Checking the Fluid Level	211	
Indicator	66	
Operation	77	
Washing	250	
Waxing and Polishing	251	
Wheels		
Adjusting the Steering	79	
Alignment and Balance	232	
Compact Spare	258	
Wrench	260	
Windows		
Cleaning	254	
Operating the Power	96	
Rear, Defogger	78	
Windshield		
Cleaning	77	
Defroster	115	
Washers	77	
Wipers, Windshield		
Changing Blades	224	
Operation	76	
Worn Tires	232	
Wrecker, Emergency Towing	282	