

## A

Accessories and Modifications ....	191
Accessories.....	191
Additional Safety Precautions..	192
Modifications .....	192
ACCESSORY (Ignition Key Position) .....	87
Accessory Power Sockets.....	122
Additives, Engine Oil.....	248
Airbag (SRS) .....	10, 54
Air Cleaner Element.....	265
Air Conditioning System.....	128
Maintenance.....	274
Usage .....	128
Air Outlets (Vents).....	130
Air Pressure, Tires .....	278
High Speed Driving .....	279
Normal Driving .....	279
Alcohol in Gasoline.....	346
Antifreeze .....	251
Anti-lock Brakes (ABS) Indicator.....	68, 214
Operation.....	212
Anti-theft, Audio System.....	178

## Anti-theft Steering Column

Lock.....	87
Appearance Care .....	297
Audio System .....	137
Automatic Seat Belt Tensioners....	52
Automatic Speed Control.....	179
Automatic Transmission.....	204
Capacity, Fluid .....	342
Checking Fluid Level.....	260
Shifting.....	205
Shift Lever Position Indicator ..	204
Shift Lever Positions .....	205
Shift Lock Release.....	209

## B

### Battery

Charging System Indicator.....	66, 326
Jump Starting .....	320
Maintenance.....	269
Specifications .....	343
Before Driving .....	183
Belts, Seat .....	8, 50
Beverage Holders.....	116
Body Repairs .....	305

### Brakes

Anti-lock System (ABS).....	212
Break-in, New Linings .....	184
Bulb Replacement .....	290
Fluid .....	263
Parking.....	82
System Indicator.....	66, 329
Wear Indicators .....	211
Braking System.....	211
Break-in, New Vehicle .....	184
Brightness Control, Instruments... 77	
Brights, Headlights .....	76
Built-in Table.....	117
Bulb Replacement Back-up Lights .....	290
Brake Lights.....	290
Cargo Area Light .....	293
Ceiling Light.....	293
Front Parking Lights.....	289
Front Side Marker Lights.....	288
Headlights .....	287
High-mount Brake Light .....	292
Interior Lights.....	293
License Plate Light.....	291

CONTINUED

# Index

---

Bulb Replacement	
Rear Side Marker Lights .....	290
Specifications .....	343
Spotlights .....	293
Turn Signal Lights.....	288
Bulbs, Halogen.....	287

## C

Capacities Chart.....	342
Carbon Monoxide Hazard .....	60
Cargo Area Light.....	125
Cargo Hooks .....	195
Carrying Cargo .....	193
Cassette Player	
Care .....	168
Operation.....	151, 164
CAUTION, Explanation of .....	ii
CD Changer .....	149, 169
CD Player.....	146
Center Pocket .....	119
Center Table.....	115
Certification Label.....	340
Chains .....	284
Changing a Flat Tire .....	308
Changing Engine Coolant.....	253

Changing Oil .....	249
How to.....	249
When to.....	238
Charging System Indicator ...	66, 326
Checklist, Before Driving.....	199
Child Safety .....	24
Child Seats.....	29
LATCH Anchorage System .....	47
Lower Anchors .....	47
Tether Anchorage Point .....	46
Childproof Door Locks .....	93
Cleaner Element, Air.....	265
Cleaning	
Aluminum Wheels.....	299
Carpeting .....	301
Exterior .....	298
Fabric .....	302
Interior .....	301
Leather.....	302
Seat Belts.....	302
Vinyl .....	302
Windows .....	303
Clock, Setting the .....	144, 162
Clutch Fluid.....	264
CO in the Exhaust .....	348
Cold Weather, Starting in.....	201

Consumer Information* .....	354
Controls, Instruments and.....	63
Coolant	
Adding.....	251
Checking.....	189
Proper Solution .....	251
Replacing .....	253
Temperature Gauge.....	74
Corrosion Protection.....	304
Crankcase Emissions Control	
System.....	348
Cruise Control Operation .....	179
Customer Relations Office .....	354

## D

DANGER, Explanation of .....	ii
Dashboard .....	64
Daytime Running Lights.....	77
Defects, Reporting Safety.....	356
Defog and Defrost.....	134
Defogger, Rear Window .....	81
Defrosting the Windows.....	134
Detachable Anchor.....	108
Dimensions.....	342
Dimming the Headlights .....	76

Dipstick	
Automatic Transmission.....	260
Engine Oil.....	188
Directional Signals.....	77
Disc Brake Wear Indicators.....	211
Disposal of Used Oil.....	250
Doors	
Locking and Unlocking.....	88
Power Door Locks.....	88
DOT Tire Quality Grading.....	344
Downshifting, 5-speed Manual Transmission.....	202
Drive Belt.....	277
Driving.....	197
Economy.....	190
In Bad Weather.....	215
In Foreign Countries.....	347
Driving Guidelines.....	198
Dust and Pollen Filter.....	275

## E

Economy, Fuel.....	190
Emergencies on the Road.....	307
Battery, Jump Starting.....	320
Brake System Indicator.....	329

Changing a Flat Tire.....	308
Charging System Indicator.....	326
Checking the Fuses.....	332
Low Oil Pressure Indicator.....	325
Malfunction Indicator Lamp.....	327
Manually Closing Moonroof.....	330
Overheated Engine.....	323
Emergency Brake.....	82
Emergency Flashers.....	81
Emergency Towing.....	337
Emissions Controls.....	348
Emissions Testing, State.....	351
Engine	
Coolant Temperature Gauge.....	74
Drive Belt.....	277
Engine Speed Limiter.....	203, 208
Malfunction Indicator Lamp.....	66, 327
Oil Pressure Indicator.....	66, 325
Oil, What Kind to Use.....	247
Overheating.....	323
Specifications.....	342
Starting.....	200
Ethanol in Gasoline.....	346
Evaporative Emissions Controls..	348
Exhaust Fumes.....	60

Expectant Mothers, Use of Seat Belts by.....	21
Exterior, Cleaning the.....	298

## F

Fabric, Cleaning.....	302
Fan, Interior.....	128
Features, Comfort and Convenience.....	127
Filling the Fuel Tank.....	185
Filters	
Air Cleaner.....	265
Dust and Pollen.....	275
Oil.....	249
5-speed Manual Transmission	
Checking Fluid Level.....	261
Shifting the.....	202
Flashers, Hazard Warning.....	81
Flat Tire, Changing a.....	308

CONTINUED

# Index

---

Fluids	
Automatic Transmission.....	260
Brake.....	263
Clutch.....	264
Manual Transmission.....	261
Power Steering.....	264
Rear Differential.....	262
Windshield Washer.....	258
FM Stereo Radio	
Reception.....	161
Folding Rear Seat.....	104
Foreign Countries, Driving in.....	347
Four-way Flashers.....	81
Front Airbags.....	10, 54
Fuel.....	184
Fill Door and Cap.....	185
Gauge.....	74
Octane Requirement.....	184
Oxygenated.....	346
Reserve Indicator.....	69
Tank, Filling the.....	185
Fuses, Checking the.....	331

## G

Gas Mileage, Improving.....	190
-----------------------------	-----

Gasohol.....	346
Gasoline.....	184
Fuel Reserve Indicator.....	69
Gauge.....	74
Octane Requirement.....	184
Tank, Filling the.....	185
Gas Station Procedures.....	185
Gauges	
Engine Coolant Temperature....	74
Fuel.....	74
Speedometer.....	72
Tachometer.....	72
Gearshift Lever Positions	
Automatic Transmission.....	204
5-speed Manual Transmission.....	203
Glass Cleaning.....	303
Glove Box.....	96

## H

Halogen Headlight Bulbs.....	287
Hatch Glass.....	94
Hazard Warning Flashers.....	81
Headlights	
Aiming.....	287

Daytime Running Lights.....	77
High Beam Indicator.....	69
Reminder Beeper.....	76
Replacing Halogen Bulbs.....	287
Turning on.....	76
Head Restraints.....	99
Heating and Cooling.....	128
High Altitude, Starting at.....	201
High-Low Beam Switch.....	76
High-mount Brake Light.....	292
Hood Latch.....	266
Hood, Opening the.....	186
Horn.....	3, 75
Hydraulic Clutch.....	264
Hydroplaning.....	216

## I

Identification Number, Vehicle....	340
Ignition	
Keys.....	84
Switch.....	86
Timing Control System.....	349
Immobilizer System.....	85
Important Safety Precautions.....	6
Indicators, Instrument Panel.....	65

Infant Restraint .....	34
Infant Seats .....	34
LATCH Anchorage System .....	47
Lower Anchors .....	47
Tether Anchorage Points .....	46
Inflation, Proper Tire .....	278
High Speed Driving .....	279
Normal Driving .....	279
Inside Mirror .....	114
Inspection, Tire .....	280
Instrument Panel .....	65
Instrument Panel Brightness .....	77
Interior Cleaning .....	301
Interior Lights .....	124
Introduction .....	i

## J

Jacking up the Vehicle .....	312
Jack, Tire .....	309
Jump Starting .....	320

## K

Keys .....	84
------------	----

## L

Label, Certification .....	340
Lane Change, Signaling .....	77
Lap/Shoulder Belts .....	17, 50
LATCH Anchorage System .....	47
Lights	
Bulb Replacement .....	287
Indicator .....	65
Parking .....	76
Turn Signal .....	77
Load Limit .....	194
LOCK (Ignition Key Position) .....	87
Locks	
Anti-theft Steering Column .....	87
Fuel Fill Door .....	185
Glove Box .....	96
Power Door .....	88
Tailgate .....	93
Low Coolant Level .....	189
Low Fuel Indicator .....	69
Low Oil Pressure Indicator ....	66, 325
Lower Anchors .....	47
Lubricant Specifications Chart ....	342
Luggage .....	193

## M

Maintenance .....	233
Owner Maintenance Checks ...	245
Record .....	243-244
Required Indicator .....	70
Safety .....	234
Schedule .....	238-242
Malfunction Indicator Lamp ..	66, 327
Manual Transmission .....	202
Manual Transmission Fluid .....	261
Meters, Gauges .....	65, 72
Methanol in Gasoline .....	346
Mirrors, Adjusting .....	114
Moonroof .....	113
Closing Manually .....	330
Operation .....	113

CONTINUED

# Index

---

## N

Neutral Gear Position.....	206
New Vehicle Break-in .....	184
Normal Shift Speeds.....	203
NOTICE, Explanation of.....	i
Numbers, Identification.....	340

## O

Octane Requirement, Gasoline ....	184
Odometer.....	73
Odometer, Trip .....	73
Off-Highway Guidelines .....	226
Oil	
Change, How to .....	249
Change, When to .....	238
Checking Engine .....	188
Pressure Indicator .....	66, 325
Selecting Proper Viscosity Chart .....	248
ON (Ignition Key Position) .....	87
Onboard Refueling Vapor Recovery .....	348
Operation in Foreign Countries...	347
Outside Mirrors .....	114

Outside Temperature Indicator .....	73
Over Drive .....	207
Overheating, Engine .....	323
Owner Maintenance Checks.....	245
Oxygenated Fuels.....	346

## P

Paint Touch-up.....	300
Panel Brightness Control .....	77
Park Gear Position.....	205
Parking.....	210
Parking Brake .....	82
Parking Brake and Brake System Indicator .....	66, 329
Parking Lights.....	76
Parking Over Things that Burn ...	210
PGM-FI System.....	349
Polishing and Waxing .....	299
Pre-Drive Safety Checklist .....	12
Pregnancy, Using Seat Belts .....	21
Protecting Adults .....	13
Additional Safety Precautions....	22
Advice for Pregnant Women.....	21
Protecting Children .....	24
Protecting Infants .....	34

Protecting Larger Children .....	42
Protecting Small Children .....	38
Using Child Seats with Tethers.....	46
Using LATCH .....	47

## R

Radiator Overheating.....	323
Radio/Cassette/CD Sound System.....	137
Readiness Codes.....	328
Rear Differential Fluid .....	262
Rear Lights, Bulb Replacement... ..	290
Rear Seat, Folding .....	104
Rear View Mirror.....	114
Rear Window Defogger .....	81
Rear Window Wiper and Washer..	80
Reclining the Seat Backs .....	97
Recommended Shift Speeds .....	203
Reminder Lights .....	65
Remote Transmitter.....	89



# Index

---

SRS, Additional Information..... 54  
  Additional Safety Precautions... 59  
  Airbag Service..... 59  
  How the Side Airbag Cutoff  
    Indicator Light Works ..... 58  
  How the SRS Indicator Works... 57  
  How Your Front Airbags  
    Work..... 54  
    How Your Side Airbags Work... 56  
  SRS Components ..... 54  
SRS Indicator..... 57, 67  
START (Ignition Key Position) .... 87  
State Emissions Testing ..... 351  
Starting the Engine..... 200  
  In Cold Weather at High  
    Altitude ..... 201  
  With a Dead Battery ..... 320  
Steam Coming from Engine ..... 323  
Steering Wheel  
  Adjustment ..... 83  
  Anti-theft Column Lock ..... 87  
Stereo Sound System ..... 137  
Storage Box ..... 119  
Storing Your Vehicle ..... 295  
Sunglasses Holder ..... 121

Supplemental Restraint  
  System..... 10, 54  
  Servicing ..... 59  
  SRS Indicator..... 57, 67  
  System Components..... 54  
Synthetic Oil..... 248

## T

Tachometer ..... 72  
Tailgate  
  Hatch Glass ..... 94  
  Open Indicator ..... 70  
  Opening the ..... 93  
Taillights, Changing Bulbs ..... 290  
Taking Care of the Unexpected .. 307  
Tape Player ..... 151, 164  
Technical Descriptions  
  DOT Tire Quality Grading ..... 344  
  Emissions Control Systems..... 348  
  Oxygenated Fuels..... 346  
  Three Way Catalytic  
    Converter..... 350  
Temperature Gauge ..... 74  
Tether Anchorage Points ..... 46  
Theft Protection..... 178

Three Way Catalytic Converter... 350  
Time, Setting the ..... 144, 162  
Tire Chains ..... 284  
Tire, How to Change a Flat ..... 308  
Tires ..... 278  
  Air Pressure ..... 279  
  Checking Wear ..... 280  
  DOT Tire Quality Grading ..... 344  
  Inflation..... 278  
  Inspection ..... 280  
  Maintenance..... 280  
  Replacing ..... 282  
  Rotating..... 281  
  Snow ..... 283  
  Specifications ..... 343  
  Tire Chains..... 284  
Tools, Tire Changing ..... 308  
Towing  
  A Trailer..... 217  
  Behind a Motorhome ..... 224  
  Emergency ..... 337



Transmission	
Checking Fluid Level,	
Automatic .....	260
Checking Fluid Level,	
Manual .....	261
Fluid Selection .....	260, 261
Identification Number .....	341
Shifting the Automatic .....	204
Shifting the Manual .....	202
Treadwear .....	344
Trip Meter .....	73
Turn Signals .....	77

## U

Underside, Cleaning .....	304
Unexpected, Taking Care	
of the .....	307
Uniform Tire Quality Grading .....	344
Unleaded Gasoline .....	184
Upholstery Cleaning .....	301
Used Oil, How to Dispose of .....	250

## V

Vehicle Capacity Load .....	194
Vehicle Dimensions .....	342
Vehicle Identification Number .....	340
Vehicle Storage .....	295
Ventilation .....	131
VIN .....	340
Vinyl Cleaning .....	302
Viscosity, Oil .....	248

## W

WARNING, Explanation of .....	ii
Warning Labels, Location of .....	61
Warranty Coverages* .....	355
Washers, Windshield	
Checking the Fluid Level .....	258
Operation .....	79
Washing .....	298
Waxing and Polishing .....	299
Wheels	
Adjusting the Steering .....	83
Alignment and Balance .....	280
Wrench .....	311

Windows	
Cleaning .....	303
Operating the Power .....	110
Rear, Defogger .....	81
Windshield	
Cleaning .....	78
Defroster .....	134
Washers .....	258
Wipers, Windshield	
Changing Blades .....	271
Operation .....	78
Worn Tires .....	280
Wrecker, Emergency Towing .....	337

\* : U.S. and Canada only