



Seat Adjustment



Fore/Aft Seat Adjustment

See pages 10-11 for important safety information and warnings about how to properly position seats and seat-backs.

The front seats may be adjusted forward or backward by pulling up on the lever at the front of the seat and then using body pressure to move the seat to the desired position.




Let go of the lever and the seat will lock into the desired position.

After adjusting the seat, use your body weight to try to move it forward and backward. Seat movement indicates that at least one of the seat adjusters did not latch. Lift the lever and readjust the seat. If the seat will not latch firmly in position after several attempts, take the vehicle to your dealer for service. An unlatched seat could increase your chance of injury in an accident.

Always adjust the seat before you start driving. Trying to move the seat while the vehicle is moving could cause you to lose control.

Reclining Adjustment

The front seat-backs can be tilted backward if so desired, using the lever on the door side of each front seat.



Raise the lever and use body pressure to move the seat-back to the desired position. Let go of the lever and the seat-back will lock into the desired position.


Keep the seat belt's webbing and latch clear of the seat parts when you tilt the folding seats forward or backward. This helps to prevent damage to the seat belt system.

Adjust the seat-back before you start driving. Trying to adjust the seat-back with the vehicle in motion could cause you to lose control.

Head Restraints


See page 12 for important safety information and warnings about how to properly position the head restraints.

Head restraints are designed to help reduce the risk of neck injuries.



They are most effective when you adjust them so the back of the occupant's head rests against the center of the restraint. A taller person should adjust the restraint as high as possible.

Push the lock knob to unlock the head restraint. Move the restraint up or down as required.



Adjust the head restraint before you start driving. Trying to adjust it while driving could cause you to lose control of the vehicle.


To remove a head restraint for cleaning or repair, push the release button and pull the restraint out of the seat-back.

Rear Seat


The rear seat can be folded forward to provide additional cargo area.

Folding


1. Pull the strap toward the outside of the seat and fold the seat cushion up.




2. To remove a head restraint, press the release knob and pull up on the restraint.




3. Fold the seat-back down by pulling the release knob, and pulling the seat-back forward.



4. Unsnap the strap on the seat bottom. Thread it through the buckle on the seat-back and pull it tight.



5. Insert the head restraints between the seat-back and seat cushion.



Make sure the head restraints are secured properly between the seat-back and seat cushion.

Never let passengers ride in the cargo area or on top of the folded-down seat. Carry passengers in the rear only when they are sitting on the locked, upright seat and properly restrained by seat belts.

Unfolding

1. To raise the seat-back, pull it up to the locked upright position. Pull on the seat-back to verify both latches are locked.
2. When latching the rear seat cushion to the floor, push the cushion with enough force to lock it.

After this, confirm it is locked by pulling the seat belt buckle upward.

3. Make sure that the head restraints are properly reinstalled on the top of the seat-backs.

▲ WARNING


Driving your vehicle without head restraints can lead to serious injury to you and your passenger in a crash.

Make sure the head restraints are in place and adjusted properly before driving.

4. Verify that the seat belts are routed properly and not twisted.

Reclining Adjustment

The angle of each section of the rear seat-back can be adjusted through three positions.



Pull up on the release knob, move the seat-back to the desired position, then release the knob. Push and pull on the seat-back to make sure it is locked in position.