

TECHNOLOGY REFERENCE GUIDE



www.owners.honda.com

31TR3B00
00X31-TR3-B000

2012 Honda Civic Sedan LX and Civic Sedan HF
Technology Reference Guide
©2011 American Honda Motor Co., Inc. — All Rights Reserved

Printed in U.S.A.



2012 CIVIC SEDAN LX
and CIVIC SEDAN HF


TECHNOLOGY REFERENCE GUIDE

The Technology Reference Guide is designed to help you get acquainted with your new Honda and provide basic instructions on some of its technology and convenience features. This guide covers the Civic Sedan LX and HF trim levels*.

This guide is not intended as a substitute for the Owner's Manual. For complete information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual.

Civic Sedan LX shown throughout guide


Auto Door Locks	2
Instrument Panel Indicators	4
Econ Button/Ambient Meter	6
Tire Pressure Monitoring System (TPMS).....	7
Multi-Information Display (MID)	8



iPod® or USB Flash Drive	10
Owner Link.....	11
Safety Reminder	12
Fuel Recommendation.....	12

AUTO DOOR LOCKS

Default Lock Setting



The doors are preset to lock when your vehicle reaches about 10 mph.

Default Unlock Setting



Only the driver's door is preset to unlock when you:

- **Shift** into Park (P) for automatic transmission vehicles.
- **Turn** the ignition switch to LOCK (0) for manual transmission vehicles.

Program how and when the vehicle doors automatically lock and unlock.


Programming the Auto Door Unlock Setting

Press the (+/-) buttons on the steering wheel to scroll through the menu options. **Press** SOURCE to select an option. See [page 9](#) for more information on the multi-information display and its controls.


1. **Press MENU.**



2. **Select Customize Settings.**



3. **Select Door Setup.**



4. **Select Auto Door Unlock.**



5. **Select All Doors with Shift to P.**



6. **Press MENU to exit.**



Programmable Auto Door Lock/Unlock Settings

Below are the options you can choose. See *Auto Door Locking/Unlocking* in your owner's manual for instructions on programming these settings.

AUTO DOOR LOCK			AUTO DOOR UNLOCK		
Auto Lock		When you reach 10 mph	Auto Unlock (all doors)		When you turn the ignition OFF
		When you shift out of Park			When you shift into Park
Turn off Auto Lock		Operate manually	Auto Unlock (only driver's door)		When you turn the ignition OFF
					When you shift into Park
Turn off Auto Unlock		Operate manually	Turn off Auto Unlock		Operate manually
					











INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information.



Malfunction Indicators

If an indicator remains on, there may be a problem; see your dealer

	Charging system		ABS (anti-lock brake system)
	Low brake fluid, Brake system		EPS (electric power steering)
	Low oil pressure		Malfunction indicator lamp (check engine light)
	SRS (supplemental restraint system)		VSA® (vehicle stability assist)
	Transmission (blinking) (automatic transmission)		Low temperature











Condition Indicators

Action is needed by driver

	Parking brake on: Release		Seat belt reminder: Fasten seat belt(s)
	Door/Trunk open: Close door(s) / trunk		Maintenance Minder™: Make dealer appointment

	Low fuel: Refill		Message indicator: See MID
	Low tire pressure: Add air		High temperature: Drive slowly or pull over

On/Off Indicators

	PASSENGER AIRBAG OFF (next to multi-information display)		Immobilizer Flashes: improperly coded key; use correct key
	SIDE AIRBAG OFF		1st detent: parking lights on 2nd detent: headlights on
	VSA OFF		Turn signals/hazards on
	CRUISE CONTROL on		High beams on
	CRUISE MAIN on		
	ECON on		

ECON BUTTON

When turned on, the vehicle's engine performance, transmission, and air conditioning system are adjusted for maximum fuel economy.


Turning the ECON Mode On/Off

Helps you further maximize your fuel economy by modifying some vehicle functions.


1. Press **ECON**.



2. The **ECON** mode indicator comes on.



3. **Check** the multi-information display for the system status.




4. Press **ECON** again to turn the system off.

AMBIENT METER

Indicates instant fuel efficiency using color-coded bars.

Ambient Meter Color-Coded Bars



TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

How It Works



Each tire valve stem contains a TPMS sensor.



When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on.



If a message also appears on the multi-information display, there may be a problem with the system. See your dealer.

What to Do

1. **Visually inspect** the tires for damage.

2. **Use** a tire air pressure gauge to check which tire(s) have low pressure.



3. **Inflate** the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.



MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.


Accessing the MID



Press the INFO button to change main displays.



Sub-displays




Press the SEL/RESET button to change sub-displays.



Main Displays

Main display




Trip computer



Clock
(or wallpaper)




Audio display



A warning or indicator message may appear as necessary. Press the INFO button to clear it.



Steering Wheel Controls



(+) Button:


Press to scroll upward.

(◀) Button:

Press to go back to the previous display.

(-) Button:

Press to scroll downward.



Display/Information Button:

Change main displays.

SOURCE Button:

Press to enter your selection.

(▶) Button:

Press to go to the next display.

MENU Button:

Press to go to "Vehicle Menu" for customization and other settings.

iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Connecting Devices and Playing Audio Files

1. **Pull out** the USB adapter cable from the center console.



2. **Connect** the USB connector to your iPod dock connector or flash drive.



3. **Press** SOURCE or AUX until iPod or USB mode appears. Audio begins to play.




4. **Press** the (⏮) or (⏭) buttons to change tracks, or use the (◀) or (▶) buttons on the steering wheel.



iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

OWNER LINK

Owner Link allows you to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information. Register at www.owners.honda.com to ensure that you continue to enjoy the experience of owning a Honda.



REGISTRATION

Questions about registration?
[FIND HELP HERE.](#)

After registration, you can always click "My Profile" to edit or update your information.

[Need help with registration?](#)

◆ * required field
Note: Username and password are case sensitive.

◆ first name ◆ last name

◆ username ◆ password (min. 6 char.) ◆ confirm password

◆ email address

◆ confirm email address

VIN or Hull Identification Number (HIN)

promo :

Please Note: E-mail spam filters may block our e-mails from being delivered. If you have a spam blocker, please set it to accept e-mails from "ownerlink@ebizmail.honda.com".

[Where can I find my VIN? Benefits of entering VIN](#)

SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

FUEL RECOMMENDATION

- Only use unleaded gasoline of 87 octane or higher.
- Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emissions control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- "TOP TIER Detergent Gasoline" meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines. In most cases, qualifying gasoline retailers will identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. This helps avoid build-up of deposits in your engine and emission control system. Because the level of detergency and harmful metallic additives (such as MMT) in gasoline vary in the market, Honda endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. For more information, visit www.toptiergas.com.
- For further important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit Owner Link at www.owners.honda.com.