TECHNOLOGY
REFERENCE
GUIDE







# TECHNOLOGY REFERENCE GUIDE

The Technology Reference Guide is designed to help you get acquainted with your new Honda and provide basic instructions on some of the technology items.

This guide is not intended as a substitute for the Owner's Manual. For complete information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual.

As with the Owner's Manual, this guide covers all trim levels of the Fit. Therefore, you may find descriptions of equipment and features that are not on your particular vehicle.

Auto Door Locks	2
Instrument Panel Indicators	4
Information Display	6
Tire Pressure Monitoring System (TPMS)	7
Voice Recognition (models with navigation)	8
Navigation (if equipped)	14





Pod® or USB Flash Memory	16
PC Card (models with navigation)	17
Owner Link	18
Safety Reminder	19
-uel Recommendation	19

## AUTO DOOR LOCKS

# Default Lock/Unlock Setting

#### Default Lock Setting

All doors are preset to lock when your vehicle reaches about 10 mph.







## Default Unlock Setting

Only the driver's door is preset to unlock when you shift into Park (P).







# Programmable Auto Door Lock/Unlock Settings

Below are the options you can choose. See Auto Door Locking/Unlocking in your owner's manual for instructions on programming these settings.

## **AUTO DOOR LOCK**

**Auto Lock** 

















Turn off **Auto Lock** 



reach 10 mph





Operate manually

#### **AUTO DOOR UNLOCK**

Auto Unlock (all doors)





When you shift into Park











When you shift into Park

Turn off **Auto Unlock** 

Auto Unlock

(only driver's

door)





Operate manually

Program how and when the vehicle doors automatically lock and unlock.

## Programming the Auto Door Unlock Setting

To program all doors to unlock when you shift to Park:

I. Close the driver's door. Shift into Park.





3. Press and hold the unlock side of the master lock switch for about 10 seconds. In that time, you will hear three clicks.





2. Turn the ignition switch to ON (II).



4. Within 5 seconds, turn the ignition switch to LOCK (0).



## INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information.



## Malfunction Indicators If an indicator remains on, there may be a problem; see your dealer






ABS (anti-lock brake system)





DRL (daytime running lights)






Malfunction lamp (check engine light)





VSA\* (vehicle stability assist)





(tire pressure monitoring system)

EPS (electronic power steering)

\* Sport model only

## **Condition Indicators** Action is needed by driver





Seat belt reminder: Fasten seat belt(s)



Door/Tailgate open: Close door(s)/tailgate



High temperature: Slow down or pull over



Low tire pressure: **Add air** 



Maintenance Minder<sup>TM</sup>: Make dealer appointment



Low fuel:

# On/Off Indicators



PASSENGER AIRBAG OFF (located on center panel)



Fog lights on\*



SIDE AIRBAG OFF



Immobilizer Flashes: improperly coded key; use correct key



VSA OFF\*



CRUISE MAIN on\*



CRUISE CONTROL on\*



Turn signals/hazards on



High beams on

Headlights on

\* Sport model only

## INFORMATION DISPLAY

Consists of several displays that provide you with useful information.

## Accessing the Information Display






When you start the engine, the display shows your last active selection from the previous drive cycle.



To toggle between the different displays, **press and release** the select/reset knob repeatedly.

# Information Displays



# TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

## How It Works





Each tire valve stem contains a TPMS sensor.





When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on.




If the TPMS indicator appears, there may be a problem with the system. See your dealer.

## What to Do

- 1. Visually inspect the tires for damage.
- 2. **Use** a tire air pressure gauge to check which tire(s) have low pressure.



3. Inflate the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.







 $^{\circ}$ 


# VOICE RECOGNITION (models with navigation)

To keep your eyes on the road and hands on the wheel, use voice commands for hands-free calling, navigation, audio, and climate control. For a full list of commands, say "Information" and "Voice Command Help."

## Key Functions by Voice Command

Control two different systems with the steering wheel buttons and the ceiling microphone.





**Navi Talk button:** Give navigation and audio commands.

Navi Back button: Cancel a command or return to the previous screen.



## Voice Command Tips

- Press and release the Navi Talk button, wait for a beep, then give a command.
- For a list of available navigation commands, **press and release** the Navi Talk button and **say** "Help."
- Speak in a clear, natural voice.
- · Reduce all background noise.
- · Adjust the dashboard and side vents away from the microphone in the ceiling.
- · Close the windows.

# NAVIGATION P. 14



# AUDIO p. 13



## Commonly Used Voice Commands

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

#### Press and release the Navi Talk button before you give a command.

#### Locate Points of Interest

**Say** a command like "Display restaurant" to see restaurant icons appear on the map.



**Say** a command like "Display gas stations" to see gas station icons appear on the map.



### Press and release the Navi Talk button before you give a command.

## Get Navigation Route Information

After a destination is entered, say "How far to destination?" to hear the remaining distance.



**Say** "Display entire route" to see the routing method the system mapped for your destination.



#### Press and release the Navi Talk button before you give a command.

#### Make Audio Selections

**Say** a command like "Radio 97.1 FM" to select that station.



**Say** a command like "CD play track I" to hear that song on a currently inserted CD.



**Say** a command like "Card play" to begin playing audio files from an inserted PC card.



**Say** a command like "Auxiliary play" to begin playing a connected audio device (you cannot use voice commands to control the device).



## Commonly Used Voice Commands (continued)

Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

#### Press and release the Navi Talk button before you give a command.

#### General Commands (Accepted on most screens to change displays)

- Display map
- Display menu
- Information
- Display audio screen
- What time is it?



#### Find Place Commands (Accepted on Map screen)

- Find nearest:
  - ATM
- Honda dealer
- gas station airport
- Mexican - hospital restaurant - bank
- post office



#### Navigation Commands (Accepted on Map screen)

- How long/far to destination?
- Display destination
- · Display entire route



# Display Commands (Accepted on Map screen)

- Display/Hide:
  - ATM
- gas station
- restaurant
- post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location





#### Press and release the Navi Talk button before you give a command.

#### Audio Commands (Accepted on most screens)

- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- CD play
- CD play track #
- CD skip forward/back
- Auxiliary (AUX) play

#### Setup Commands (Accepted on Setup screen)

- Brightness up/down
- Volume up/down/min/max/off
- Guidance prompts min/max/normal



97.1

FM1 Fiet art de team aux

9.59 va. 4 # 1 steren



#### Help Commands (Accepted on most screens)

- Help (list of available commands for current screen)
- · Voice command help from INFO screen (list all available navigation and audio commands)



# NAVIGATION (if equipped)

Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

## **Entering a Destination**

## **Using Voice Control**

Press and release the Navi Talk button before you give a command.

1. Say "Display menu" and "Address."




4. **Say** the entire street address number. For example, "1-2-3-4."



 Say "Street" followed by the street name. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).



 If the street address is in more than one city, a list of city names appears. Say the number next to the city you want to select.



 A list of street names appears.
 Say the number next to the street you want to select.



6. The system calculates the route and displays the "Calculate route to" screen. **Say** "OK" to set the route



## Using the Find Nearest Command

Try these simple steps to find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Navi Talk button before you give a command.

1. Say "Find nearest ATM."



 A list of the nearest ATMs in your area is displayed by shortest distance to destination.



3. **Say** the number next to the destination you want to select.



4. The system calculates the route and displays the "Calculate route to" screen. **Say** "OK" to set the route.





## IPOD® OR USB FLASH MEMORY

Play audio files from your compatible iPod or USB flash memory device through your vehicle's audio system.

# Connecting Devices and Playing Audio Files

1. **Pull out** the USB adapter cable from the upper glove box.





2. **Connect** the USB connector to your iPod dock connector or flash drive.





3. **Push** AUX or **touch** the USB icon to begin playing.

without navigation



with navigation



4. **Press** the SEEK or SKIP buttons to change tracks.

without navigation





with navigation



iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

# PC CARD (models with navigation)

Play audio files from your compatible PC card through your vehicle's audio system.

# Connecting Devices and Playing Audio Files

I. Press OPEN.





3. **Insert** the PC card into the slot and **press** CLOSE.



2. If necessary, **insert** your PC card into a PC card adapter.




4. **Press** AUDIO to show the audio display. **Press** |◀◀ and ▶▶| to skip through tracks on the card.



 $\sim$  17

## **NWNFRIINK**

Owner Link allows you to explore features and technologies specific to your vehicle, schedule service appointments, obtain and update maintenance and service records, manage your financial services account, and access other useful information. Register at www.owners.honda.com to ensure that you continue to enjoy the experience of owning a Honda.





## SAFFTY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passengers wear seat belts, and that young children are properly secured in a child seat or booster in the rear seat. Never place an infant seat in the front passenger's seat as the force of a deploying airbag can seriously injure an infant.

## FIIFI RECOMMENDATION

- Only use unleaded gasoline of 87 octane or higher.
- Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emission control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under warranty.
- "TOP TIER Detergent Gasoline" meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines. In most cases, qualifying gasoline retailers will identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. This helps avoid build-up of deposits in your engine and emission control system. Because the level of detergency and harmful metallic additives (such as MMT) in gasoline vary in the market, Honda endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. For more information, visit www.toptiergas.com.
- For further important information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit Owner Link at www.owners.honda.com.