

TECHNOLOGY REFERENCE GUIDE



owners.honda.com

31S2TQ20
00X31-SZT-Q200

2013 Honda CR-Z Technology Reference Guide
©2012 American Honda Motor Co., Inc. — All Rights Reserved

Printed in Japan



2013 CR-Z

TECHNOLOGY REFERENCE GUIDE

The Technology Reference Guide is designed to help you get acquainted with your new Honda and provide basic instructions on some of its technology and convenience features.

This guide is not intended to be a substitute for the Owner's Manual. For more detailed information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual or Navigation Manual.

As with the Owner's Manual, this guide covers all trims of the CR-Z. Therefore, you may find descriptions of equipment and features that are not on your particular vehicle.

Auto Door Locks	2
Fuel Fill Door	3
Instrument Panel Indicators	4
Multi-Information Display (MID)	6
Tire Pressure Monitoring System (TPMS)	8
Paddle Shifting*	9
3-Mode Drive System	10
Plus Sport System	11
Eco Assist™	12
Rearview Camera*	16
Multi-View Rear Camera*	17



Voice Recognition*	18
Navigation*	22
Bluetooth® HandsFreeLink® (HFL)	25
SMS Text Messaging*	32
iPod® or USB Flash Drive	34
Bluetooth® Audio*	35
Pandora*	36
Owner Link	37
Safety Reminder	37
Fuel Recommendation	38

*if equipped

AUTO DOOR LOCKS

Program how and when the vehicle doors automatically lock and unlock.

Default Lock/Unlock Setting


Default Lock Setting

All doors and hatch are preset to lock when your vehicle reaches about 10 mph.



Default Unlock Setting

Only the driver's door and hatch are preset to unlock when you shift into Park (P)*.



*In manual transmission vehicles, when you turn the ignition to LOCK (0).

Programmable Auto Door Lock/Unlock Settings

Below are the different programmable options you can choose. See your Owner's Manual for additional instructions on programming these settings.

AUTO DOOR LOCK			AUTO DOOR UNLOCK		
Auto Lock	 When you reach 10 mph	 When you shift out of Park*	Auto Unlock (all doors and hatch)	 When you turn the ignition OFF	 When you shift into Park*
Turn off Auto Lock	 Operate manually		Auto Unlock (only driver's door and hatch)	 When you turn the ignition OFF	 When you shift into Park*
Turn off Auto Unlock	 Operate manually			 When you turn the ignition OFF	 When you shift into Park*

* Does not apply to manual transmission vehicles.

Modifying the Auto Door Unlock Setting

Press either Info (▲/▼) button to toggle to the "Customize Settings" display on the MID, then **press** SEL/RESET to activate the menu.

1. Select CHG SETTING.



4. Select SHIFT TO P (or IGN OFF for manual transmission).



2. Select DOOR SETUP.



5. Select ALL DOORS.



3. Select AUTO DOOR UNLOCK.



6. Select EXIT to save the setting and exit the menu.





FUEL FILL DOOR



Easy-to-open fuel door keeps your fuel cap covered.

Opening and Closing the Fuel Fill Door

To open, **push and release** the fuel door in the area shown until you hear a click and it pops open.



To close, **push** the fuel door flush with the body.




INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information. See your Owner's Manual for more information.

Manual Transmission Shift Indicators



Note: Indicators do not come on in SPORT mode.



Malfunction Indicators

If an indicator remains on, there may be a problem; see a dealer

	Charging system		ABS (anti-lock brake system)
	Low brake fluid, Brake system		IMA System
	Low oil pressure		Malfunction lamp (check engine light)
	SRS (supplemental restraint system)		VSA® (vehicle stability assist)
	EPS (electronic power steering)		TPMS (blinks and stays on) (tire pressure monitoring system)
	Low engine temperature (stays on)		Transmission (blinks)

Condition Indicators

Action is needed by driver

	Parking brake on: Release		Seat belt reminder: Fasten seat belt(s)
	Door/Hatch open: Close door(s) / hatch		Low fuel: Refill

Low tire pressure **on**:
Add air

Message indicator:
See MID

High temperature indicator:
Pull over for engine cooling

Immobilizer (blinks):
Use other vehicle key

On/Off Indicators


	SIDE AIRBAG OFF		NORMAL mode on
	PASSENGER AIRBAG OFF (center audio panel)		ECON mode on
	VSA OFF		Plus Sport System on
	Auto Idle Stop on (blinking)		Fog lights on (if equipped)
	CRUISE MAIN on		Exterior lights on
	CRUISE CONTROL on		Turn signals/hazards on
	SPORT mode on		High beams on

MULTI-INFORMATION DISPLAY (MID)

Accessing the Multi-Information Display



When you start the engine, the MID shows the main display.




To toggle between the MID displays:

- Press either Info button (▲/▼) for the main displays.
- Press SEL/RESET for the sub-displays.



Consists of several displays that provide you with useful information.

MID Main Displays



*if a call is active

TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

How It Works



When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on and CHECK TIRE PRESSURE appears on the MID.

If there is a problem with the system, CHECK TPMS SYSTEM appears on the MID. See a dealer.

What to Do

1. **Visually inspect** the tires for damage.
2. **Use** a tire air pressure gauge to check which tire(s) have low pressure.



3. **Inflate** the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.




PADDLE SHIFTING*


While in the D position, 7-Speed Manual Shift Mode allows you to manually shift your vehicle's speeds up or down. Useful for engine braking or when driving in hilly terrain or cornering.

Paddle Modes

Pull (-) to shift down.




Pull (+) to shift up.




NORMAL or ECON Mode

- **Pull (+)** or **(-)** to temporarily switch from automatic to manual shift mode.
- The speed number is displayed on the shift indicator display.
- When the vehicle's speed is constant, the mode returns to automatic.




SPORT Mode

- **Pull (+)** or **(-)** to switch to manual shift mode.
- The M indicator and speed number are displayed on the shift indicator display.
- **Pull (+)** or **(-)** to change transmission speeds.
- **Pull and hold (+)** to cancel this mode.



L (Low) Mode

- **Pull and hold (+)** and **(-)** at the same time until L is displayed on the shift indicator display.
- Use this mode to get higher torque when climbing steep hills.
- **Pull and hold** again to cancel this mode.



*in automatic transmission vehicles

3-MODE DRIVE SYSTEM

Select one of three different modes of driving styles.


Driving Modes

When a mode is selected, a message briefly appears on the MID and the mode indicator turns on.




Sport Mode

- Enhanced steering, handling, and performance response.
- Reduced fuel economy.
- Ambient meter turns red.




Normal Mode

- Achieves the best balance of driving performance and fuel economy.
- This is the default mode at engine start.
- Ambient meter changes from blue to green.



Econ Mode

- Fuel economy is prioritized over engine response and climate control.
- Ambient meter changes from blue to green.




PLUS SPORT SYSTEM

Helps the vehicle briefly accelerate by increasing power and electric motor assist when you depress the gas pedal. Works in any driving mode.

How It Works

When the vehicle speed is over 20 mph and the IMA battery charge level shows at least four segments, the Plus Sport System indicator appears. The system is now ready for activation.



Activating the System

- When the Plus Sport System indicator is on, **press** the S+ button.
- S+ begins to blink. **Depress** the gas pedal to activate the system.
- S+ blinks, READY disappears, and the ambient meter turns red when the system is in operation.
- To cancel the system during operation, **release** the gas pedal or **press** the S+ button again.



ECO ASSIST™

Provides real-time feedback on your driving style so you can learn how to maximize fuel efficiency. It consists of the Ecological Drive Display (on the MID), Ambient Meter, ECON Mode button, and ECON indicator.

Activating the ECON Mode

1. Press the **ECON** mode button.



3. Check the MID.



2. The **ECON** mode indicator comes on.




4. Press either INFO (▲/▼) button and **toggle** to the Ecological Drive Display.



Note: When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system are adjusted to achieve maximum fuel efficiency.

Driver Feedback



Real-time Fuel Efficiency Coach

Driving Style	Eco Drive Bar (on the MID)	Ambient Meter Background Color Changes	Fuel Efficiency
Smooth, steady acceleration maximizes fuel efficiency			High
Smooth, steady deceleration maximizes fuel efficiency			
Moderate acceleration			
Moderate deceleration			
Rapid acceleration lowers fuel efficiency			Low
Rapid deceleration lowers fuel efficiency			

Goals:

- Keep the Eco Drive bar near the center.
- Keep the Ambient Meter at **GREEN**.
- Develop a driving style that maximizes fuel efficiency.

NORMAL/ECON mode shown

ECO Assist Scoring

Monitors the fuel efficiency of your driving style in real time and converts results into leaves, which are displayed in a series of five “plant” icons on the MID.

Once you start your vehicle, make sure the MID shows the Ecological Drive Display on the display to view your Eco Assist score in real time.



As you drive, you earn leaves if you drive in a fuel-efficient manner, or lose them if you drive inefficiently.




When you turn the ignition off, your drive cycle and lifetime score are displayed on the MID.



Eco Score


Each time you reach a new stage, a Stage Up Recognition icon briefly appears on the MID. When you reach the highest ranking, a trophy icon briefly appears.



Auto Idle Stop

Shuts the engine off at a stop to maximize fuel efficiency. Idle stop occurrence and duration varies depending on the selected drive mode, ambient conditions, and IMA battery condition. See your Owner's Manual for more information.

How It Works



AUTOMATIC TRANSMISSION

While driving, the engine is on.

At a stop with the brake pedal pressed, the engine turns off.

When you take your foot off the brake pedal, the engine turns back on.

Note: Auto Idle Stop only functions if you come to a stop while driving with the transmission in D or N position.

MANUAL TRANSMISSION

While driving, the engine is on.

At a stop with the brake pedal pressed and the transmission in neutral, the engine turns off.

When you take your foot off the brake pedal and **fully depress** the clutch, the engine turns back on.

IMA Gauge

Shows when the IMA motor is assisting the engine or charging the battery.



Note: IMA assist may not operate in extreme temperatures, or if the battery is low on charge.

REARVIEW CAMERA (models without navigation)

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the rearview mirror, along with helpful parking guide lines.
- The display turns off when you shift out of Reverse.
- **Press and hold** the power button for 3 seconds to turn the guide lines off. **Repeat** to turn back on.



MULTI-VIEW REAR CAMERA (models with navigation)

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up.

How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the navigation display.
- The rearview display turns off when you shift out of Reverse.



Parking Guide Lines

- Yellow parking guide lines also appear to help you judge distance. They can be turned on or off.
- **Press and hold** CANCEL until the guide lines turn on or off. They remain off until you turn them on again.



Switching Views

There are three rearview modes: wide (default view), normal, and top down.

- **Select** the corresponding icon to change views.
- **Press** ZOOM (▲) or (▼) to adjust the screen brightness.



VOICE RECOGNITION

Key Functions by Voice Command

Control four different systems with the steering wheel buttons and the ceiling microphone.

To reduce the potential for driver distraction, certain manual and touchscreen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.



Pick-Up button: Answer an incoming call, or go directly to the Phone screen.

Talk button: Give navigation, HFL, audio, and climate control commands.

Hang-Up button: End a call or decline a call.

Back button: Cancel a command or return to the previous screen.



Voice Command Tips

- **Press and release** the Talk button, wait for a beep, then say a command.
- All available voice commands are highlighted in blue when you press the Talk button.
- For a list of available commands, **press and release** the Talk button and say "Help."
- Speak in a clear, natural voice.
- Reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.
- The system also uses a touchscreen display. You can select options by touching them on the screen. This is limited while the vehicle is moving.

To keep your eyes on the road and hands on the wheel, use voice commands for hands-free calling, navigation, audio, and climate control. For a full list of all system commands, say "Display information" and "Voice Info."

NAVIGATION p. 22



BLUETOOTH® HANDSFREELINK® p. 28



AUDIO p. 21



CLIMATE p. 21



Commonly Used Voice Commands


Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the Talk button before you say a command.

General Commands

(Accepted on most screens to change displays)

- Display map
- Display menu
- Display information
- Display audio
- What time is it?
- Next/previous (to change pages)
- Left/right (to change tabs)
- Up/down (to scroll lists up to three pages)



Find Place Commands

(Accepted on Map screen)

- Find nearest:
 - ATM
 - gas station
 - Mexican restaurant
 - Honda dealer
 - airport
 - hospital
 - bank
 - post office



Navigation Commands

(Accepted on Map screen)


- How long/far to the destination?
- Display destination map
- Display entire route



Display Commands

(Accepted on Map screen)

- Display/Hide:
 - ATM
 - gas station
 - restaurant
 - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location



Press and release the Talk button before you say a command.

Audio Commands

(Accepted on most screens)

- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- DISC/USB/iPod play
- DISC/USB/iPod skip forward/back
- Auxiliary (AUX) play




Phone Commands

(Accepted on Phone screen)

- Dial
- Speed Dial 1 (or 2)
- Redial
- Phonebook
- Phone setup

(Accepted on any screen)

- Dial by number
- Dial by voice tag



Climate Control Commands

(Accepted on most screens)


- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57-87)
- Temperature max hot/cold



Help Commands

(Accepted on most screens)

- Help (list of available commands for current screen)
- Voice info - from INFO screen (list of all available commands by category)




NAVIGATION (if equipped)

Entering a Destination Using Voice Commands


Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the Talk button before you say a command.


1. **Say** "Display menu." **Say** "Address."



4. **Say** the entire street address number. For example, "1-2-3-4." If necessary, **say** "OK" to proceed.



2. **Say** "Street," then **say** the street name on the next screen. Do not include the direction (N, S, E, W) or type (St., Ave., Blvd., etc.).




5. If the street address is in more than one city, a list of city names appears. **Say** the number next to the city you want to select.



3. A list of street names appears. **Say** the number next to the street you want to select.



6. The system displays the "Calculate route to" screen. **Say** "Set as destination" to set the route.



Note: If menu options are grayed out, they are only available using voice commands. It is recommended that you enter your destination before driving or when the vehicle is stopped.

Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination.

Using the "Find Nearest" Command


Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the Talk button before you say a command.

1. From the map screen, **say** "Find nearest ATM."




3. **Say** the number next to the destination you want to select.




2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.



4. The system displays the "Calculate route to" screen. **Say** "Set as destination" to set the route.



Map Screen Legend





FM Traffic

Provides continuously updated information, including traffic speed, incidents, and construction in major metro areas. Works in cities where a clear FM traffic signal is available.

Press and release the Talk button before you say a command.

Displaying Traffic Information

Say "Display traffic" to view highway flow data.



Heavy traffic

Moderate traffic

Note: Traffic flow and incident icons are only displayed on map scales of 5 miles (8 km) or less.

Traffic Icons:



Incident



Road closed



Construction




Weather


Traffic Rerouting

When a destination is already set, you can create a detour to avoid traffic incidents or congestion.


1. Say "Display traffic list" to view a list of incidents on your route.




3. Say "Avoid," and the incident list returns.



2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



4. Say "Reroute" to set the new route.



BLUETOOTH® HANDSFREELINK® (models without navigation)

Make and receive phone calls through your vehicle's audio system. Visit handsfreelink.honda.com to check if your phone is Bluetooth-compatible.

How to Use HFL



HFL Talk button: Give HFL commands or answer incoming calls.

HFL Back button: End a call, go back to the previous command, or cancel an operation.



Pairing Your Phone

You can pair your phone only when your vehicle is stopped.

Press and release the HFL Talk button before you say a command.

1. **Enable** discovery mode on your compatible phone.


2. If no phone has been paired before, the system gives you instructions.

If you are pairing an additional phone, say "Phone setup," then say "Pair."

3. HFL gives you a four-digit code that appears on the MID.

PAIR
0000

4. **Search** for HandsFreeLink from your phone, and **enter** the code when prompted. **Connect** to HFL.




5. HFL asks you to name the phone. For example, say "Mary's phone." The phone is now added.

Making a Call

Press and release the HFL Talk button before you say a command.


1. **Say** “Call” or “Dial” and the desired phone number.



3. The call is connected and heard through the vehicle's speakers.



2. **Say** “Call” or “Dial” to continue.




HFL Phonebook


Store up to 50 names and their phone numbers, which can be used as speed dials.

Press and release the HFL Talk button before you say a command.


1. **Say** “Phonebook.”




3. **Say** the name of the contact, and then the phone number.



2. **Say** “Store.”




4. To call a contact once an entry is stored, **say** “Call Mike.”



Receiving a Call

A notification is heard and the incoming phone number appears on the MID.



Press the HFL Talk button to accept the call.



Press the HFL Back button to end or decline the call.



BLUETOOTH® HANDSFREELINK® (models with navigation)

Make and receive phone calls through your vehicle's audio system. Visit handsfreelink.honda.com to check if your phone is compatible.

To reduce the potential for driver distraction, certain manual and touch screen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.

How to Use HFL

Pick-Up button: Answer an incoming call, or go directly to the Phone screen.

Talk button: Give HFL commands.

Hang-Up button: End a call or decline a call.

Back button: Cancel a command or return to the previous screen.




Pairing Your Phone


Use this pairing method when no phone has ever been paired to the system. You can pair your compatible phone only when the vehicle is stopped.

Press and release the Talk button before you say a command.


1. **Press** the Pick-Up button to go to the Phone screen. A prompt appears. **Say "Yes."**



2. Make sure your phone is in discovery mode, and **say "OK."**




3. HFL searches for your phone. **Say** the number next to the phone when it appears on the list.



If your phone does not appear:
Say "Find Another Phone" and **search** for a HandsFreeLink device from your phone. **Connect** to HFL.



4. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.




Pairing Your Phone (continued)

Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.


Press and release the Talk button before you say a command.

1. **Press** the Pick-Up button to go to the Phone screen.



If a prompt appears asking to connect to a phone, **say "No."**


2. **Say "Phone setup."**




3. **Say "Add a new phone."**




4. **Say "Search."**




5. Make sure your phone is in discovery mode, and **say "OK."**




6. HFL searches for your phone. **Say** the number next to the phone when it appears on the list.



If your phone does not appear:
Say "Find Another Phone" and **search** for HandsFreeLink from your phone. **Connect** to HFL.



7. HFL gives you a four-digit code. **Enter** it on your phone when prompted. The phone is now paired.




Dialing a Number


Enter a 10-digit phone number to call.

Press and release the Talk button before you say a command.


1. **Press** the Pick-Up button to go to the Phone screen.
3. **Say** the entire phone number, then **say** "Dial" to call.



2. **Say** "Dial."




4. The call is connected and heard through the vehicle speakers.



Receiving a Call

A notification is heard and the following screen appears:



Press the Pick-Up button to accept the call.



Press the Hang-Up button to end or decline the call.





Using the Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system.



Press and release the Talk button before you say a command.

1. **Press** the Pick-Up button to go to the Phone screen.
3. **Scroll** through the list to find the name and number you want to call. **Say** "Dial," or **press** the Pick-Up button to call.



2. **Say** "Phonebook."

4. The call is connected and heard through the vehicle speakers.





Using Speed Dial

Store up to 15 numbers for quick calling. See your Navigation Manual for instructions on storing voice tags.



Press and release the Talk button before you say a command.

1. **Press** the Pick-Up button to go to the Phone screen.
- If an entry has a stored voice tag, **say** "Dial by voice tag," followed by the voice tag name and "Dial" from any screen.



2. **Say** "Speed Dial 1" (or "Speed Dial 2") and the number next to the entry. For example, "One." **Say** "Call," or **press** the Pick-Up button to call.

3. The call is connected and heard through the vehicle speakers.





SMS TEXT MESSAGING (models with navigation)

Receive and send text messages from your paired and linked compatible phone. Visit handsfreelink.honda.com to see if this feature is compatible on your phone. Standard message rates apply. This feature is limited while the vehicle is moving.

Receiving Text Messages

Press and release the Talk button before you say a command.




1. A notification appears on the navigation screen when you receive a text message.
2. **Say "Read"** to open the message. The message is displayed, and the system reads it aloud.



Displaying Messages

Press and release the Talk button before you say a command.



1. **Press** the Pick-Up button to go to the Phone screen.
2. **Say "Text Message."** The 20 most recent text messages from your phone are displayed.
3. **Say** the number next to the message you want. The message is displayed, and the system reads it aloud.





Replying to Text Messages

Press and release the Talk button before you say a command.

1. With the message open, **say "Reply."**
3. **Say "Send"** to send the message.





2. **Say** the corresponding number of one of the six available reply messages.
4. A notification appears after the message is sent.



Calling the Sender

Press and release the Talk button before you say a command.

1. With the message open, **say "Call."**
2. HFL begins dialing the number.



iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

Connecting Devices and Playing Audio

1. **Pull out** the USB adapter cable from the front console.
3. **Press** (⏮) (⏭) or (+) (-) to change tracks.



Connect the USB adapter cable to your iPod dock connector or flash drive.

2. **Press** AUX or CD/AUX until iPod or USB mode appears. Audio begins to play.



Note: Connect your device only when your vehicle is stopped.

Model with navigation shown
iPod is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. iPod not included.

BLUETOOTH® AUDIO (models with navigation)

Play stored or streaming audio files from your compatible phone through your vehicle's audio system. Visit handsfreelink.honda.com to check if this feature is available on your phone.

Playing Bluetooth Audio

1. Make sure your phone is on and paired to *Bluetooth® HandsFreeLink®* (see page 28).
2. **Press** CD/AUX until *Bluetooth Audio* mode appears.
4. **Press** (⏮) (⏭) or (+) (-) to change tracks.



3. From your phone, **open** the desired audio player or app and begin playing. Sound is redirected to the audio system.

Make sure the volume on your phone is properly adjusted.

Notes:



- You may need to enable additional *Bluetooth* settings on your phone for playback.
- Remote audio controls and the play/pause function may not be supported on all phones.
- Operate your phone only when your vehicle is stopped.

PANDORA® (models with navigation)

Play and operate Pandora streaming radio from your iPhone® through your vehicle's audio system. Standard data rates apply.

Playing Bluetooth Audio

1. **Pull out** the USB adapter cable from the front console. **Connect** your phone using a USB dock connector.
2. **Open** Pandora from your phone. **Press** CD/AUX until Pandora mode appears and streaming begins.
3. From the audio screen, select items such as Station List, Like/Dislike, and Pause/Resume.*
4. **Press** (⏮) or (+) to change tracks.



Notes:

- If Pandora is not selected from your phone, iPod music is played.
- Press the Home button on your iPhone to switch from Pandora to iPod. To play Pandora again, you must reopen the app from your phone.
- If you cannot operate Pandora through the audio system, it may be streaming through Bluetooth® Audio. Make sure Pandora mode on your audio system is selected. If Pandora still does not operate, you may have to reconnect the cable.
- Connect your phone only when your vehicle is stopped.

*Menu functions not available on all phones

iPhone is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries.

OWNER LINK

Owner Link allows you to explore features and technologies specific to your vehicle, obtain and update maintenance and service records, and access other useful information. Register at owners.honda.com to ensure that you continue to enjoy the experience of owning a Honda. For added convenience, Owner Link can also be accessed on a mobile device.



SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passenger wear seat belts.

Never carry an infant in a rear-facing child seat in this vehicle; a deploying airbag could seriously injure or kill them.

Further, the National Highway Traffic Safety Administration (NHTSA) and Transport Canada both recommend that all children age 12 and under be properly restrained in a back seat. Since this vehicle does not have a back seat, we strongly recommend that you do not carry a child aged 12 or under in this vehicle.

Honda further recommends that you do not carry any child who is not large enough or mature enough to ride in the front passenger seat for the following reasons:

- An inflating front or side airbag can injure or kill a child sitting in the front passenger seat.
- A child in the passenger seat is more likely to interfere with the driver's ability to safely control the vehicle.

FUEL RECOMMENDATION

- Only use unleaded gasoline of 87 octane or higher.
- Some gasoline in North America contains manganese-based fuel additives. Prolonged and consistent use of gasoline containing such additives can deteriorate your vehicle's performance, fuel economy, and the emissions control system. Always use gasoline without such additives if available. Failures caused by use of gasoline containing such additives may not be covered under warranty.
- For further important information on fuel and lubricants for your vehicle and information on gasoline that works best for your vehicle, contact your dealer or visit Owner Link at owners.honda.com.

